

Manuals+


[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Night Cat](#) /

› [Night Cat Upgraded Pop up Tent with Trekking Poles Instruction Manual](#)

Night Cat Upgraded Pop up Tent with Trekking Poles Combo Set



PRODUCT OVERVIEW

The Night Cat Upgraded Pop up Tent with Trekking Poles is designed for quick and easy setup, providing comfortable shelter for 2-4 persons. This combo set includes both the instant pop-up tent and two versatile trekking poles, enhancing your outdoor experience with convenience and functionality.



Image: The Night Cat Pop up Tent fully set up with the included trekking poles, demonstrating its compact folded state and quick deployment.

WHAT'S INCLUDED

- 1 x Night Cat Pop up Tent
- 2 x Night Cat Trekking Poles
- Tent Stakes and Guy Ropes (pre-attached or included separately)
- Carrying Bag for Tent
- Carrying Bag for Trekking Poles



Image: A detailed view of the two Night Cat trekking poles along with their various interchangeable tips and a mesh carrying bag.

SETUP INSTRUCTIONS

1. Pop-up Tent Setup

1. **Unpack the Tent:** Remove the tent from its carrying bag. It will be in a compact, folded state.
2. **Release and Unfold:** Gently toss the tent onto a clear, flat surface. The tent's frame is designed to spring open instantly. Spread out the poles to fully extend the tent.
3. **Secure the Tent:** Use the included stakes to secure the tent to the ground through the corner loops. For added stability, especially in windy conditions, deploy the guy ropes and secure them to the ground with additional stakes.
4. **Set up Porch (Optional):** The tent doors can be set up as a front porch using the Night Cat Trekking Poles. Extend

the trekking poles to the desired height and use them to prop up the door fabric, securing the corners with guy ropes and stakes.





Image: The Night Cat Pop up Tent set up on a beach, demonstrating the use of trekking poles to create a shaded front porch area.

2. Trekking Pole Assembly and Adjustment

- Assemble Sections:** The trekking poles typically come in collapsed sections. Pull the sections apart until they click into place or are fully extended.
- Adjust Length:** Locate the quick-locking system on each pole. Open the lever, adjust the pole to your desired length (typically 45-54 inches for general use, or longer for porch setup), and then firmly close the lever to lock it in place. Ensure the pole is securely locked before use.
- Attach Tips:** Select the appropriate tip for your terrain (e.g., rubber tips for pavement, basket tips for snow or soft ground) and attach it to the bottom of the pole.

Adjustable Length & Quick Locking System



Length after stretching: 45"-54"



Image: Visual guide demonstrating the steps to open, adjust, tighten, and close the quick-locking system on the trekking poles for length adjustment.

OPERATING AND USAGE

Tent Usage

- Ventilation:** The tent features 2 large doors and 2 wide windows to allow for excellent airflow. Keep them open when possible to ensure good ventilation and reduce condensation.
- Capacity:** The inner size of 9.5x6.6x4 ft is designed to comfortably accommodate 2 adults, with additional space for 1 to 2 children or extra camping gear. It fits a queen-size air mattress.
- Weather Protection:** The tent is designed with water-resistant materials. While it offers good protection from rain, avoid touching the inner walls during wet conditions to prevent water from seeping through.



Image: The Night Cat Pop up Tent in a rainy outdoor setting, highlighting its water-resistant properties with visible water droplets on the fabric.



Image: A view of the spacious interior of the tent, showing room for sleeping pads and gear. Insets show details of an interior hook, a zipper pull, and the fine mesh of the tent's windows.

Trekking Pole Usage

- **Ergonomic Grip:** The poles feature an ergonomic EVA foam grip designed to mold to the shape of your hand, providing comfort and reducing fatigue during use.
- **Wrist Straps:** Utilize the adjustable breathable wrist straps to prevent chafing and provide additional support and security while trekking.
- **Terrain Adaptability:** The extended soft foam grip allows for comfortable handling on various terrains, including steep inclines or declines.

Ergonomic Handle Design



Keep dry



Absorbs
Sweat



Soft
comfortable



No odors



Anti-Slip

Ergonomics EVA Foam Grip

Mold to the shape of your hand



Adjustable Breathable Wrist Strap

Prevent chafing on hands

Extended Soft Foam Grip

Handle extreme terrains

Image: A close-up of the trekking pole handle, illustrating its ergonomic EVA foam grip, adjustable wrist strap, and extended soft foam grip for various terrains.

CARE AND MAINTENANCE

Cleaning

- Tent:** Hand wash the tent with mild soap and water. Do not machine wash or use harsh detergents, as this can damage the waterproof coating. Air dry completely before storing.
- Trekking Poles:** Wipe poles clean with a damp cloth. Ensure all sections are dry before collapsing and storing to prevent corrosion.

Folding and Storage

Folding the pop-up tent is a key step for compact storage. Please refer to the following instructions:

- Collapse the Tent:** Ensure all doors and windows are zipped closed. Lay the tent flat on the ground.
- Form an '8':** Hold two opposite corners of the tent. Gently twist the tent into a figure '8' shape.
- Fold Twice:** Bring the two circles of the '8' together, then fold the resulting shape in half again. This will create a compact, four-circle disc.
- Secure and Store:** Use the attached elastic band or strap to secure the folded tent. Place it back into its carrying bag. The upgraded design allows for a 40% smaller package size compared to traditional pop-up tents.

Comparison

	Night Cat Ungraded Popup Tent	Traditional Popup Tent
How Easy to Fold	5 thumbs up	2 thumbs up
Number of Foldable Circle	4 Circles	3 Circles
Folding Type	Like Number "8"	Like Number "O"
Time of Folding Back	30 Sec	60 Sec or more if it pops up constantly when folding, and it gets you crazy
Inner Size	9.5x6.6x4 ft	9.2x6.6x4.3 ft
Weight	3 kg / 6.6 lb	4.6 kg / 10 lb
Package Size	28x28x2.8 in	36x36x2.5 in
Package Image	 <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> </div>	

Image: A comparison chart illustrating the folding process and package size difference between the Night Cat Upgraded Pop up Tent (folding into 4 circles, like an '8') and a traditional pop-up tent (folding into 3 circles, like an 'O').

TROUBLESHOOTING

- Difficulty Folding:** If you are having trouble folding the tent, ensure you are following the 'figure 8' and double-fold method precisely. Practice may be required. Refer to the instructional video if available (no video provided in current data).
- Water Seepage:** While the tent is waterproof, touching the inner fabric during rain can cause water to wick through. Avoid contact with the inner walls when wet. Ensure all zippers are fully closed.

- Poles Not Extending/Collapsing:** Check the quick-locking mechanisms on the trekking poles. Ensure they are fully open when adjusting and fully closed when locked. Clean any dirt or debris from the pole sections.

PRODUCT SPECIFICATIONS

Feature	Specification
Brand	Night Cat
Product Dimensions (L x W x H)	114" x 79" x 48"
Inner Size (L x W x H)	9.5 x 6.6 x 4 ft
Item Weight	6.6 Pounds (approx. 3 kg)
Occupancy	2-4 Person
Seasons	4 Season
Water Resistance Technology	600 mm (Waterproof)
Material	Polyester, Fiberglass, Polyurethane, Taffeta, Fabric
Pole Material Type	Aluminum or Carbon Fiber
Number of Doors	2
Number of Windows	2
Package Size (Folded)	28" x 28" x 2.8"

SUPPORT INFORMATION

For further assistance, product inquiries, or to report any issues, please contact Night Cat customer support through the retailer's platform where you purchased the product or visit the official Night Cat brand store online.

Online Store: [Night Cat Amazon Store](#)

Please have your product model and purchase details ready when contacting support.