

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FIMEI](#) /

› [FIMEI Split Floor Lamp User Manual - Modern LED Rotatable Floor Lamp \(Model: 03662e1d-088f-48eb-9ff7-298832fa1e39\)](#)

## FIMEI 03662e1d-088f-48eb-9ff7-298832fa1e39

# FIMEI Split Floor Lamp User Manual

Model: 03662e1d-088f-48eb-9ff7-298832fa1e39

## INTRODUCTION

The FIMEI Split Floor Lamp is a modern LED lighting solution designed for versatile use in various indoor environments. It features dual semicircular ring lights that rotate independently, offering a super-wide and uniform lighting range. This lamp provides stepless adjustment for both color temperature (from 3000K warm light to 6000K cool white light) and brightness (5% to 100%). Control is convenient via a touch-sensitive panel on the pole or a magnetic remote control, which also includes a smart memory function to recall your last settings.



Figure 1: FIMEI Split Floor Lamp showcasing its rotatable dual light sources.

## PACKAGE CONTENTS

Please verify that all components are present before beginning assembly:

- Lamp Body (with integrated LED rings)
- Lamp Pole Sections (multiple screw-together segments)
- Base
- US Plug (Power Adapter)

- Remote Control
- User Manual



Figure 2: Overview of all included components in the FIMEI Split Floor Lamp package.

## SETUP & ASSEMBLY

Assembly of the FIMEI Split Floor Lamp is tool-free and straightforward. Follow these steps for quick installation:

1. **Connect Lamp Pole Sections:** Carefully screw the lamp pole sections together in sequence. Ensure each section is securely tightened to form a stable vertical pole. The internal wiring will guide the connection.
2. **Attach Lamp Head:** Screw the lamp head assembly onto the top of the assembled lamp pole.
3. **Secure to Base:** Place the heavy-duty base on a flat, stable surface. Carefully screw the bottom of the assembled lamp pole into the threaded receiver on the base. Rotate clockwise until firmly secured.
4. **Connect Power Adapter:** Connect the lamp's power cable to the provided US plug (power adapter).
5. **Plug In:** Insert the power adapter into a standard electrical outlet.
6. **Remote Control Setup:** Insert 2 AAA batteries (not included) into the remote control.

For a visual guide on the assembly process, please refer to the video below:

Video 1: Assembly and demonstration of the FIMEI Split Floor Lamp, including connecting pole sections, attaching the head, and initial power-up.

## OPERATING INSTRUCTIONS

### 1. Rotatable Dual Light Source

The FIMEI Split Floor Lamp features two independent semicircular LED rings. Each ring can be rotated up to 330 degrees horizontally and vertically. This allows you to precisely direct light to specific areas, creating a super-wide, uniform, and non-dazzling illumination.



Figure 3: Illustration of the separately rotatable semi-rings for wide-area illumination.

### 2. Stepless Color Temperature & Brightness Adjustment

Customize your lighting experience with stepless adjustments:

- **Color Temperature:** Adjust from a cozy 3000K warm light to a crisp 6000K cool white light.
- **Brightness:** Smoothly dim or brighten the lamp from 5% to 100%.

These adjustments can be made using either the touch-sensitive panel on the lamp pole or the remote control.

# Separately Rotatable Semi-rings

Illuminate a broader space and precisely choose areas to brighten.



Figure 4: Visual representation of adjustable color temperature and stepless dimming.

### 3. Convenient Dual Control & Smart Memory Function

The lamp offers two methods of control:

- **Touch-pad Control (on pole):** Long-press to adjust brightness, tap to switch color temperature, and tap to turn On/Off.
- **Remote Control:** The magnetic remote control attaches to the lamp pole for easy storage. It provides full control over power, brightness, color temperature, and includes one-key switches for different light modes (e.g., Leisure, Reading, Working, Nursing, Night Light, Entertainment).

The intelligent memory function recalls your last lighting setting (brightness and color temperature) when the lamp is turned on, ensuring your preferred ambiance is ready instantly.



Figure 5: Dual control options: touch-pad on the pole and magnetic remote control.

### FEATURES & BENEFITS

- **Eye-Protection:** Designed to provide bright yet non-dazzling illumination, reducing eye strain and offering gentle light for extended use.
- **Versatile Lighting Modes:** Pre-set modes on the remote control cater to various activities and moods, including Leisure, Night Light, Nursing, Working, Reading, and Entertainment modes.
- **One-Hour Timer:** The remote control includes a convenient 1-hour timer function, allowing the lamp to automatically switch off after a set period.



Figure 6: The lamp's eye-caring feature provides gentle illumination.

# Memory Function & Eyes Caring

Brighten up the dark without hurting your eyes.



Figure 7: The lamp adapts to different activities with its versatile lighting modes.

## MAINTENANCE

---

To ensure the longevity and optimal performance of your FIMEI Split Floor Lamp, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power outlet before cleaning. Use a soft, dry cloth to wipe down the lamp pole, base, and LED rings. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electronic components.
- **Dust Removal:** Regularly dust the lamp to prevent accumulation, which can affect light output and aesthetics.
- **Inspection:** Periodically check the power cord and connections for any signs of damage. If any damage is found, discontinue use and contact customer support.

## TROUBLESHOOTING

---

If you encounter any issues with your FIMEI Split Floor Lamp, please refer to the following common troubleshooting steps:

- **Lamp Not Turning On:**

- Ensure the power adapter is securely plugged into both the lamp and a working electrical outlet.
- Check if the outlet is functional by plugging in another device.
- Verify that the lamp pole sections are tightly screwed together, ensuring proper electrical contact.

- **Remote Control Not Working:**

- Check and replace the AAA batteries in the remote control.
- Ensure there are no obstructions between the remote and the lamp's receiver.
- Try re-pairing the remote control with the lamp according to the instructions in the user manual (if applicable).

- **Inconsistent Brightness/Color:**

- Ensure you are using the stepless adjustment correctly by long-pressing the touch-pad or using the brightness/color buttons on the remote.
- If the issue persists, try unplugging the lamp for a few minutes and then plugging it back in to reset.

If these steps do not resolve the issue, please contact FIMEI customer support for further assistance.

## SPECIFICATIONS

Specification	Value
Brand	FIMEI
Model Number	03662e1d-088f-48eb-9ff7-298832fa1e39
Product Dimensions	9.8"D x 9.8"W x 69"H
Item Weight	9.75 pounds (4.43 Kilograms)
Material	Metal
Finish Type	Coated
Light Source Type	LED
Wattage	22 watts
Brightness	1400 Lumen
Color Temperature	3000K-6000K (Adjustable)
Control Method	Remote, Touch
Special Features	Adjustable Color Temperature, Dimmable, Memory Function, Remote Control, Timer
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor

## WARRANTY & SUPPORT

---

FIMEI is committed to the quality of its products. The FIMEI Split Floor Lamp comes with a quality assurance policy that protects against any manufacturing defects in materials, workmanship, or electrical function. For any inquiries, technical support, or warranty claims, please contact FIMEI customer support. Your satisfaction is our priority.

For additional information or to explore other FIMEI products, please visit the [FIMEI Store](#).