

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Kibiy](#) /

› [Kibiy Unisex Body Hair Trimmer RFCD-8105 User Manual](#)

## Kibiy RFCD-8105

# Kibiy Unisex Body Hair Trimmer RFCD-8105 User Manual

## INTRODUCTION

---

This manual provides detailed instructions for the safe and effective use of your Kibiy Unisex Body Hair Trimmer, model RFCD-8105. Please read this manual thoroughly before operation and retain it for future reference.

## SAFETY INFORMATION

---

Avoid use near water sources. Do not submerge in water. Keep away from electrical sources while charging. Do not use on infants or children. Always keep blades away from eyes and face. Follow recommended cleaning and maintenance procedures to prevent skin irritation.

## PACKAGE CONTENTS

---

Verify that all items are present in your package:

- Kibiy Body Hair Trimmer Unit
- Charging Dock
- USB Charging Cable
- Replacement Blade (for sensitive areas)
- Adjustable Guard Comb (3mm, 5mm, 7mm settings)
- Cleaning Brush
- Lubricating Oil
- User Manual



Image: Complete Kibiy Body Hair Trimmer kit with all included accessories.

## SETUP

### Charging the Trimmer

Before first use, fully charge the trimmer. The trimmer can be charged using the provided USB cable directly or via the charging dock. A full charge provides up to 90 minutes of cordless operation. The LED display on the trimmer indicates the battery life.



## 2 USB CHARGING METHODS

The power can be used continuously for 90 minutes



Image: Trimmer being charged via USB cable and placed in its charging dock.

### **Attaching and Changing Blades**

To remove a blade, gently push it forward until it detaches from the trimmer head. To attach a blade, align it with the trimmer head and press it down until it clicks into place.

## 2 REPLACEABLE BLADES

### **Blade For Ball Shaving**

The serrated chamfer design has a cushioning and blocking effect to make shaving safer



### **Blade For Body Trimming**

Quick and clean shaving of unwanted body hair, making body hair trimming easier



Image: Two replaceable blades, one designed for sensitive areas and another for general body trimming.

### **Attaching and Adjusting the Guard Comb**

The adjustable guard comb slides onto the trimmer head. Use the slider on the comb to select your desired trimming length: 3mm, 5mm, or 7mm. Ensure the comb is securely attached before use.

## **OPERATING INSTRUCTIONS**

### **Turning On/Off and Using the LED Light**

Press the power button to turn the trimmer on or off. The integrated LED light illuminates the trimming area for improved visibility. The LED display shows the remaining battery percentage.



Image: The trimmer's LED light activated, providing illumination for precise trimming.

### **Trimming Techniques**

For optimal results, hold the trimmer flat against the skin and move it slowly against the direction of hair growth. The trimmer is designed for both wet and dry use.




Image: Illustrations demonstrating safe trimming on various body parts.

## Official Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the features and use of the Kibiy Full Body Hair Trimmer, including its cordless design, adjustable guard comb, LED lighting, and suitability for various body areas.

## MAINTENANCE

### Cleaning

The trimmer is IPX7 waterproof, allowing for easy cleaning under running water. After each use, remove the blade and rinse both the blade and the trimmer head thoroughly. Use the provided cleaning brush to remove any trapped hairs.

IPX7 waterproof, the trimmer is splash-proof, and you can use it immediately after shower.



**WATERPROOF**



Image: The trimmer being cleaned under running water, highlighting its waterproof design.

### **Lubrication**

Periodically apply a small drop of the included lubricating oil to the blades to maintain optimal performance and extend blade life.

### **Blade Replacement**

Replace blades as needed to ensure a clean and comfortable trim. Replacement blades can be purchased separately.

### **TROUBLESHOOTING**

- **Trimmer not turning on:** Ensure the trimmer is fully charged.
- **Poor trimming performance:** Clean the blades thoroughly, apply lubricating oil, or replace the

blade if it is dull.

- **Skin irritation:** Ensure the blade is clean and sharp. Use the appropriate guard comb for sensitive areas.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	1.38 x 1.18 x 5.91 inches
Item Model Number	RFCD-8105
Date First Available	March 10, 2023
Recommended Uses	Beard, Body, Shaving, Trimming
Color	Dark Black
Item Weight	120 Grams
Brand	Kibiy
Power Source	Battery Powered, Corded Electric

## WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or the official Kibiy website.

## LEGAL DISCLAIMER

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.