



Manuals.plus /

› Samoser /

› Samoser Refrigerator Ice Maker Assembly Instruction Manual for Samsung Models RF260BEAESG, RF221NCTASP, and others

## Samoser RF260BEAESG RF221NCTASP

# Samoser Refrigerator Ice Maker Assembly Instruction Manual

For Samsung Models RF260BEAESG, RF221NCTASP, and Compatible Units

## 1. INTRODUCTION

---

This manual provides essential instructions for the installation, operation, and maintenance of your Samoser Refrigerator Ice Maker Assembly. This product is designed as an aftermarket replacement part for specific Samsung refrigerator models. Please read this manual thoroughly before proceeding with installation or use to ensure proper function and safety.

## 2. SAFETY INFORMATION

---

- Always disconnect power to the refrigerator before attempting any installation or repair. Failure to do so may result in electric shock or injury.
- Wear appropriate personal protective equipment, such as gloves, during installation.
- If you are unsure about any step of the installation process, it is recommended to consult a qualified technician.
- Keep small parts away from children.

## 3. PACKAGE CONTENTS

---

The package includes the following item:

- 1x Samoser Refrigerator Ice Maker Assembly



Image showing the Samoser Refrigerator Ice Maker Assembly, a white plastic unit with internal wiring and mechanical components, designed for installation in compatible Samsung refrigerators.

#### 4. COMPATIBILITY

This Samoser Ice Maker Assembly is an aftermarket replacement part compatible with various Samsung refrigerator models. Please verify your refrigerator's model number before installation. Compatible models include, but are not limited to:

- RF220NCTABC, RF220NCTABC/AA, RF220NCTASG, RF220NCTASG/AA, RF220NCTASL/AZ, RF220NCTASL/SA, RF220NCTASP, RF220NCTASP/AA, RF220NCTASR, RF220NCTASR/AA, RF220NCTAWW, RF220NCTAWW/AA, RF220NFTASR, RF220NFTASR/AA
- RF221NCTABC, RF221NCTABC/AA, RF221NCTASP, RF221NCTASP/AA, RF221NCTASR, RF221NCTASR/AA, RF221NCTAWW, RF221NCTAWW/AA
- RF23HCEDTSR, RF23HCEDTSR/AA

- RF260BEAEBBC, RF260BEAEBBC/AA, RF260BEAESG, RF260BEAESG/AA, RF260BEAESP, RF260BEAESP/AA, RF260BEAESR, RF260BEAESR/AA, RF260BEAEWW, RF260BEAEWW/AA
- RF261BEAEBBC, RF261BEAEBBC/AA, RF261BEAESG, RF261BEAESG/AA, RF261BEAESP, RF261BEAESP/AA, RF261BEAESR, RF261BEAESR/AA, RF261BEAEWW, RF261BEAEWW/AA, RF261BIAESR, RF261BIAESR/AA
- RF262BEAESR, RF262BEAESR/AA
- RF263AEBP, RF263AEBP/XAA, RF263AEPN, RF263AEPN/XAA, RF263AERS, RF263AERS/XAA, RF263AERS/XAC, RF263AEWP, RF263AEWP/XAA, RF263AFWP, RF263AFWP/XAC
- RF263TEAEBBC, RF263TEAEBBC/AA, RF263TEAESG, RF263TEAESG/AA, RF263TEAESP, RF263TEAESP/AA, RF263TEAESR, RF263TEAESR/AA, RF263TEAEWW, RF263TEAEWW/AA
- RF266AEBP, RF266AEBP/XAA, RF266AEPN, RF266AEPN/XAA, RF266AERS, RF266AERS/XAA, RF266AEWP, RF266AEWP/XAA, RF266AFRS, RF266AFRS/XAC
- RF268ABBP, RF268ABBP/XAA, RF268ABPN, RF268ABPN/XAA, RF268ABRS, RF268ABRS/XAA, RF268ABWP, RF268ABWP/XAA

If your model number is not listed or you are unsure about compatibility, please contact the seller for assistance.

## 5. SETUP AND INSTALLATION

---

Installation of the ice maker assembly requires careful attention. It is recommended to have basic tool knowledge or seek professional assistance if needed.

1. **Disconnect Power:** Before beginning, unplug the refrigerator from the electrical outlet to prevent electric shock.
2. **Access the Ice Maker Compartment:** Open the freezer door and carefully remove any freezer drawers or shelves that obstruct access to the existing ice maker or its mounting location. A headlamp or flashlight can be helpful for visibility.
3. **Remove Old Ice Maker (if applicable):** Locate the screws or clips securing the old ice maker. Disconnect any wiring harnesses by gently pressing the release tab and pulling. You may need offset needle-nose pliers for tight connections.
4. **Install New Ice Maker:** Position the new Samoser Ice Maker Assembly in the designated location. Secure it with the appropriate screws or clips.
5. **Connect Wiring:** Carefully connect the wiring harness from the refrigerator to the new ice maker assembly. Ensure the connection is firm and secure.
6. **Reassemble:** Replace any removed drawers or shelves.
7. **Restore Power:** Plug the refrigerator back into the electrical outlet.

## 6. OPERATING INSTRUCTIONS

---

After installation, allow the refrigerator to cool down and the ice maker to cycle. The first batch of ice may take several hours to produce. Discard the first few batches of ice to ensure cleanliness and proper function.

- Ensure the water supply to the refrigerator is turned on.
- Verify that the ice maker's shut-off arm is in the down position (indicating it's ready to make ice).
- The ice maker will automatically fill with water and begin the ice-making cycle once the freezer reaches the appropriate temperature.

## 7. MAINTENANCE

---

Regular maintenance helps ensure the longevity and optimal performance of your ice maker.

- **Cleaning:** Periodically clean the ice bucket and the ice maker components with a mild soap and water solution. Rinse thoroughly and dry completely before reinserting.
- **Water Filter:** Ensure your refrigerator's water filter is replaced according to the manufacturer's recommendations to maintain water quality and prevent mineral buildup in the ice maker.
- **Inspection:** Occasionally inspect the ice maker for any signs of wear, leaks, or unusual noise.

## 8. TROUBLESHOOTING

---

If your ice maker is not functioning as expected, consider the following common issues:

- **No Ice Production:**
  - Check if the refrigerator is plugged in and receiving power.
  - Ensure the water supply valve to the refrigerator is open.
  - Verify that the ice maker's shut-off arm is in the down position.
  - Confirm the freezer temperature is set correctly (typically 0°F / -18°C).
  - Check for any kinks or blockages in the water line.
- **Small or Hollow Ice Cubes:**
  - This often indicates low water pressure or a partially clogged water filter. Replace the water filter if due.
- **Ice Tastes Bad:**
  - Replace the water filter.
  - Clean the ice bucket and discard old ice.

If troubleshooting steps do not resolve the issue, contact customer support for further assistance.

## 9. SPECIFICATIONS

---

**Brand:**

Samoser

**Model Name:**

Ice Maker

**Part Number (Example):**

RF260BEAESR, RF260BEAESP

**Item Model Number:**

RF260BEAESG RF221NCTASP

**Material:**

Plastic

**Product Dimensions:**

Approximately 1 x 1 x 1 inches (Refer to actual product for precise measurements)

**UPC:**

734665704774

## 10. WARRANTY AND SUPPORT

---

For any questions regarding product warranty, technical support, or replacement parts, please contact the seller

directly through your purchase platform. Provide your order number and a detailed description of the issue for prompt assistance.