

[manuals.plus](#) /

› [JBL](#) /

› [JBL Clip 4 Portable Bluetooth Speaker Instruction Manual](#)

JBL Clip 4

JBL Clip 4 Portable Bluetooth Speaker Instruction Manual

Model: Clip 4

1. PRODUCT OVERVIEW

The JBL Clip 4 is an ultra-portable Bluetooth speaker designed for on-the-go audio. It features a unique integrated carabiner for easy attachment and is built to withstand outdoor conditions.

- **Compact Design:** Small in size, delivering surprisingly robust sound.
- **Extended Playtime:** Enjoy up to 10 hours of audio playback on a single charge.
- **Wireless Streaming:** Connect wirelessly via Bluetooth 5.1 for high-quality sound.
- **Durable and Resilient:** IP67 waterproof and dust resistant, featuring improved fabric material and rugged rubber housing.
- **Integrated Carabiner:** Easily hook the speaker to clothing, backpacks, or belt loops.



Image: Front view of the JBL Clip 4 portable Bluetooth speaker.

2. WHAT'S IN THE Box

Ensure all the following items are included in your package:

- 1 x JBL Clip 4 Speaker
- 1 x Type-C to Type-A charging cable
- Quick Start Guide
- Safety Sheet
- Warranty Card

3. GETTING STARTED (SETUP)

3.1 Charging the Speaker

Before first use, fully charge your JBL Clip 4 speaker. Use the provided Type-C to Type-A charging cable to connect the speaker to a power source.

Sound To Go

The fully integrated metal carabiner lets you bring your music with you.




Image: Side view of the JBL Clip 4, highlighting the USB-C charging port.

3.2 Power On/Off

To power on the speaker, press the power button located on the side. Press and hold the same button to power off.

3.3 Bluetooth Pairing

To pair your JBL Clip 4 with a Bluetooth-enabled device:

1. Power on the JBL Clip 4.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and select "JBL Clip 4" from the list of available devices.
4. Once connected, the LED light will turn solid, and you will hear a confirmation tone.

4. OPERATING THE SPEAKER

4.1 Controls

The JBL Clip 4 features intuitive controls on its front surface:

- **Play/Pause:** Press the triangle button to play or pause audio.
- **Volume Up:** Press the '+' button to increase the volume.
- **Volume Down:** Press the '-' button to decrease the volume.

4.2 Using the Integrated Carabiner

The redesigned carabiner allows for versatile portability. Simply open the carabiner clip and attach it to your backpack, belt loop, or any suitable anchor point.



Image: The JBL Clip 4 with its integrated carabiner, demonstrating its portability.

5. MAINTENANCE

5.1 Waterproof and Dust Resistant

The JBL Clip 4 is IP67 rated, meaning it is fully waterproof and dust resistant. It can be submerged in up to 1 meter of water for 30 minutes. This makes it suitable for use in various environments, including by the pool, at the beach, or during outdoor activities.



Image: The JBL Clip 4 demonstrating its waterproof capability.

5.2 Cleaning

To clean the speaker, gently wipe it with a damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the fabric or rubber housing.

6. TROUBLESHOOTING

- **No Power:** Ensure the speaker is fully charged. Connect it to a power source using the USB-C cable.
- **Cannot Pair via Bluetooth:** Make sure the speaker is in pairing mode (flashing LED). Check your device's Bluetooth settings and ensure it's discoverable. If issues persist, try turning both devices off and on again.
- **Poor Sound Quality:** Ensure the speaker and your device are within Bluetooth range (approximately 10 meters/33 feet). Check for any obstructions between the devices.
- **Volume Issues:** Adjust the volume using the '+' and '-' buttons on the speaker and on your connected device.

7. SPECIFICATIONS

Feature	Specification
Model Name	Clip 4
Brand	JBL
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Speaker Type	Outdoor
Special Feature	Portable
Compatible Devices	Smartphone, Tablet, Laptop
Surround Sound Channel Configuration	5.1
Color	Black/Orange
Product Dimensions	3.4"D x 5.3"W x 1.8"H
Item Weight	239 Grams (8.4 ounces)
Is Waterproof	True (IP67)
Battery Capacity	Up to 10 Hours Playtime
Speaker Maximum Output Power	5 Watts
Control Method	Touch
Material	Plastic
Shape	Oval
Mounting Type	Clip On, Freestanding



Image: Visual representation of the JBL Clip 4's 10-hour playtime.

8. WARRANTY AND SUPPORT

The JBL Clip 4 comes with a Limited Warranty provided by JBL. For detailed warranty information, please refer to the Warranty Card included in your product package.

For technical support, product inquiries, or service, please contact JBL customer support or visit the official JBL website.

- **2-Year Protection Plan:** Available for purchase.
- **3-Year Protection Plan:** Available for purchase.