

[Manuals.plus](#) /

› [VEGER](#) /

› VEGER 20000mAh 22.5W Power Bank User Manual

## VEGER V2053

# VEGER 20000mAh 22.5W Power Bank User Manual

Model: V2053

## 1. INTRODUCTION

Thank you for choosing the VEGER 20000mAh 22.5W Power Bank. This compact yet powerful portable charger is designed to provide reliable and fast charging for your mobile devices on the go. Featuring a large 20000mAh capacity, PD20W, and QC3.0 fast charging technology, it ensures your devices are powered efficiently. Please read this manual carefully before use to ensure optimal performance and safety.



*The VEGER 20000mAh Power Bank, demonstrating its compact and portable design when held in a hand.*

## 2. SAFETY INFORMATION

---

To ensure safe operation and prolong the lifespan of your power bank, please observe the following safety precautions:

- Do not expose the power bank to extreme temperatures (above 60°C/140°F or below 0°C/32°F), direct sunlight, or fire.
- Do not disassemble, modify, or attempt to repair the device. This will void the warranty and may cause safety hazards.
- Keep the power bank dry and away from water or other liquids.
- Avoid dropping, hitting, or subjecting the power bank to strong impacts.
- Keep out of reach of children.
- Use only certified cables and adapters for charging the power bank and your devices.
- If the power bank swells, emits an odor, or becomes excessively hot during use or charging, discontinue use immediately.
- Dispose of the power bank responsibly according to local regulations. Do not dispose of it with household waste.

### 3. PACKAGE CONTENTS

---

Please check the package for the following items:

- 1 x VEGER 20000mAh Power Bank
- 1 x USB-C Cable
- 1 x User Manual
- 1 x Carrying Pouch

### 4. PRODUCT OVERVIEW

---

Familiarize yourself with the different parts of your VEGER Power Bank:

# Charge & Recharge Conveniently



**18W**  
Micro Input



**22.5W** ⚡  
USB A Output

**20W/18W**  
Type C Output/Input

**22.5W** ⚡  
USB A Output

*Overview of the power bank's input and output ports, including Micro USB input, USB-A outputs, and USB-C input/output.*

- **Digital LED Display:** Shows the remaining battery percentage.
- **USB-A Output Ports (x2):** Deliver up to 22.5W fast charging.
- **USB-C Port (Input/Output):** Supports up to 20W PD output and 18W input.
- **Micro USB Input Port:** Supports up to 18W input for recharging the power bank.

# Fast Charging in All Ports

**22.5W  
SCP/VOOC**  
Fast Charge



**20W PD**  
USB C Power  
Delivery



**18W QC/PD**  
Quick Charge



*The power bank supports various fast charging protocols across its ports, including 22.5W SCP/VOOC, 20W PD, and 18W QC/PD.*

## 5. SETUP

Before first use, it is recommended to fully charge your VEGER Power Bank.

## 5.1 Charging the Power Bank

1. Connect the provided USB-C cable to the USB-C input port on the power bank. Alternatively, use a Micro USB cable with the Micro USB input port.
2. Connect the other end of the cable to a compatible USB wall charger (not included) or a computer's USB port. For faster charging, use a PD or QC compatible wall charger.
3. The digital LED display will show the charging progress, indicating the battery percentage.
4. The power bank is fully charged when the display shows "100%".

## 6. OPERATING INSTRUCTIONS

### 6.1 Charging Your Devices

1. Connect your device's charging cable to one of the USB-A output ports or the USB-C output port on the power bank.
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. The digital LED display will show the power bank's remaining battery level.
4. You can charge up to three devices simultaneously using the two USB-A ports and the USB-C port.

# Charge 3 Devices Simultaneously



*The power bank is capable of charging three devices concurrently, such as smartphones and wireless earbuds.*

## 6.2 Checking Battery Level

The digital LED display on the power bank shows the current battery percentage. Simply press the power button (if available, or it activates automatically upon connection) to view the remaining charge.

# Smaller & Lighter in 20,000mAh



*Despite its 20000mAh capacity, the power bank is designed to be smaller and lighter, making it highly portable.*

# Wide Compatibility



## For iPhone

14/13...6/SE/Airpods  
all series



## For Android

Samsung/Xiaomi/Google...  
/other Android



## For Tablets

iPad/iPad Pro/Samsung  
/Huawei Tablets



## For Heated Apparel

jackets/vests/pants  
/hats/gloves



*The power bank offers wide compatibility with various devices, including iPhones, Android phones, tablets, and even heated apparel.*

## 7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use harsh chemicals or abrasive materials.

- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures. If storing for a long period, charge it to about 50-75% every 3 months to maintain battery health.
- **Battery Care:** Avoid fully discharging the power bank frequently, as this can reduce its overall lifespan.

## 8. TROUBLESHOOTING

- **Power Bank Not Charging:**
  - Ensure the charging cable is securely connected to both the power bank and the power source.
  - Try a different charging cable or wall adapter.
  - Verify the power source is active.
- **Device Not Charging from Power Bank:**
  - Check if the power bank has sufficient charge (refer to the LED display).
  - Ensure the charging cable is securely connected to both the power bank and your device.
  - Try a different charging cable or a different output port on the power bank.
  - Some devices may require a specific charging protocol; ensure compatibility.
- **Slow Charging:**
  - Ensure both the power bank and your device support fast charging protocols (PD/QC).
  - Use a high-quality, fast-charging compatible cable.
  - If charging multiple devices, the output current may be distributed, leading to slower individual charging speeds.
- **Power Bank Overheating:**
  - It is normal for the power bank to get slightly warm during charging or discharging.
  - If it becomes excessively hot, disconnect all devices and the charging cable immediately. Allow it to cool down before resuming use. If the issue persists, contact customer support.

## 9. SPECIFICATIONS

| Feature             | Specification                  |
|---------------------|--------------------------------|
| Model Name          | V2053                          |
| Battery Capacity    | 20000mAh                       |
| Battery Composition | Lithium Polymer                |
| USB-C Input/Output  | Max 20W Output / Max 18W Input |
| Micro USB Input     | Max 18W Input                  |
| USB-A Output (x2)   | Max 22.5W Output (each)        |
| Voltage             | 5 Volts                        |
| Amperage            | 3 A                            |

| Feature          | Specification                                     |
|------------------|---------------------------------------------------|
| Item Weight      | 302 Grams                                         |
| Color            | White                                             |
| Special Features | Digital Display, Fast Charging, Lightweight, Slim |

## 10. WARRANTY AND SUPPORT

VEGER products are designed and manufactured to the highest quality standards. For any questions, technical support, or warranty claims, please contact VEGER customer service through the retailer's platform or the official VEGER website. Please retain your proof of purchase for warranty service.

© 2024 VEGER. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question