



Manuals.plus /

› GENGQIANSI /

› GENGQIANSI Remote Control User Manual for Traiden Air Portable AC Models CMTHS242A, EMTCS121A, CMTCS121A, EMTHS121A, EMTCS122A, TCS121M, EMTHS182A

## GENGQIANSI A520230309B08

# GENGQIANSI Remote Control User Manual

For Traiden Air Portable AC Models: CMTHS242A, EMTCS121A, CMTCS121A, EMTHS121A, EMTCS122A, TCS121M, EMTHS182A

Model: A520230309B08 | Brand: GENGQIANSI

## INTRODUCTION

---

This manual provides detailed instructions for the setup, operation, and maintenance of your GENGQIANSI remote control. This remote is designed for use with various Traiden Air Portable Air Conditioner models, ensuring convenient control over your unit's functions. Please read this manual thoroughly before using the remote control to ensure proper operation and longevity.

## PACKAGE CONTENTS

---

- 1 x GENGQIANSI Remote Control
- 1 x Wall Mount Case
- (Batteries are not included and must be purchased separately)



Image: The GENGQIANSI remote control shown alongside its included wall mount case. The remote is white with a digital display and various function buttons. The wall mount is also white, designed to securely hold the remote.

## PRODUCT OVERVIEW

The remote control features a clear digital display and ergonomically arranged buttons for easy access to all air conditioner functions. The display can show temperature in both Fahrenheit and Celsius.










Image: A close-up front view of the GENGQIANSI remote control. The digital screen displays "76°F" and fan speed indicators. Buttons for Power, Mode, Temp, Fan, Eco, Swing, Sleep, Display, Timer, Mute, Turbo, and I Feel are visible.

### Button Functions:

- **Power** ( ): Turns the air conditioner ON or OFF.
- **Mode**: Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temp** ( ▲ / ▼ ): Adjusts the desired temperature setting.
- **Fan**: Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Eco**: Activates or deactivates the energy-saving mode.
- **Swing** ( ▲ / ▼ ): Controls the vertical louver swing.
- **Swing** ( ◀ / ▶ ): Controls the horizontal louver swing.
- **Sleep**: Activates the sleep mode for comfortable nighttime operation.
- **Display**: Toggles the display on the air conditioner unit or changes display information.
- **Timer**: Sets the ON/OFF timer for the air conditioner.
- **Mute**: Silences the air conditioner's operational beeps.
- **Turbo**: Activates maximum cooling/heating for rapid temperature change.
- **I Feel**: Activates the "I Feel" function, which senses the temperature at the remote's location.

## SETUP

---

### Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two new AAA batteries (not included), ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: The back of the GENGQIANSI remote control, highlighting the battery compartment cover. The cover is designed to slide open for battery insertion.

### **First Use:**

After installing batteries, the remote control is ready for use. Point the remote directly at the infrared receiver on your Traiden Air Portable AC unit. No pairing is required for this infrared remote control.

### **OPERATING INSTRUCTIONS**

---

Ensure there are no obstructions between the remote control and the air conditioner unit for optimal signal transmission.

- **Turning On/Off:** Press the **Power** button once to turn the unit on, and again to turn it off.
- **Selecting Mode:** Press the **Mode** button repeatedly to cycle through available operating modes (e.g., Cool, Heat, Fan, Dry, Auto). The selected mode will be displayed on the remote's screen.
- **Adjusting Temperature:** Use the **Temp ▲** button to increase the temperature and the **Temp ▼** button to decrease it. The temperature can be displayed in Fahrenheit or Celsius.
- **Setting Fan Speed:** Press the **Fan** button to adjust the fan speed. Options typically include Auto, Low, Medium, and High.
- **Using Swing Function:** Press the **Swing** button to activate or adjust the louver swing direction. Some models may have separate buttons or multiple presses for vertical and horizontal swing.
- **Eco Mode:** Press **Eco** to engage an energy-saving operation, which may adjust temperature and fan speed automatically to reduce power consumption.
- **Sleep Mode:** Press **Sleep** to activate a mode that gradually adjusts the temperature and fan speed over time to maintain comfort during sleep while saving energy.
- **Timer Function:** Press **Timer** to set a specific time for the air conditioner to turn on or off. Refer to your air conditioner's main manual for detailed timer programming.
- **Turbo Function:** Press **Turbo** for a quick burst of high-power cooling or heating to reach the desired temperature rapidly.
- **I Feel Function:** When **I Feel** is activated, the remote control's built-in sensor measures the ambient temperature at its location and sends this information to the air conditioner, allowing the unit to optimize comfort based on the remote's position.



Image: The GENQIANSI remote control is shown in a living room, positioned to control a wall-mounted air conditioner unit. This illustrates the typical use case for the remote.

## MAINTENANCE

### Battery Replacement:

Replace batteries when the remote control's display becomes dim or unresponsive. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

### Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

## TROUBLESHOOTING

---

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner unit.
- **Display is dim or blank:**
  - Replace the batteries.
- **Air conditioner not responding to specific functions:**
  - Some functions may be specific to certain air conditioner models. Refer to your air conditioner's original manual to confirm compatibility with all remote functions.

## SPECIFICATIONS

---

<b>Model Number</b>	A520230309B08
<b>Brand</b>	GENGQIANSI
<b>Compatible Devices</b>	Traiden Air Portable AC Air Conditioner (Models: CMTHS242A, EMTCS121A, CMTCS121A, EMTHS121A, EMTCS122A, TCS121M, EMTHS182A)
<b>Connectivity Technology</b>	Infrared
<b>Special Feature</b>	Ergonomic design, Fahrenheit and Celsius display
<b>Item Weight</b>	1.06 ounces
<b>Package Dimensions</b>	0.39 x 0.2 x 0.08 inches

## WARRANTY AND SUPPORT

---

Information regarding warranty coverage and customer support for this GENGQIANSI remote control is not provided in this manual. For warranty details or technical assistance, please refer to the product packaging or contact the seller directly.

## IMPORTANT NOTES

---

- This remote control operates via infrared (IR) signal. Ensure a clear line of sight between the remote and the air conditioner unit.
- The functionality of certain buttons (e.g., specific swing directions, advanced timer settings) may depend on the features available on your specific Traiden Air Portable AC model.
- Keep the remote control away from direct sunlight, high temperatures, and moisture.