

AVATTO TRV07

Avatto TRV07 Zigbee 3.0 TUYA Smart Radiator Thermostat Valve User Manual

Model: TRV07

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Avatto TRV07 Zigbee 3.0 TUYA Smart Radiator Thermostat Valve. Please read this manual carefully before using the device to ensure proper function and safety. Keep this manual for future reference.

IMPORTANT SAFETY INFORMATION

- Ensure the power supply to the radiator system is off before installation or maintenance.
- Installation should be performed by a qualified professional if you are unsure about any steps.
- Do not expose the device to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Keep out of reach of children.

PACKAGE CONTENTS

Please check the package for the following items:

- Avatto TRV07 Smart Radiator Thermostat Valve
- User Manual (this document)
- Adapter set (various sizes for different valves)

PRODUCT OVERVIEW

The Avatto TRV07 is a smart radiator thermostat valve designed to provide intelligent control over your home heating system. It integrates with Zigbee 3.0 networks and the TUYA smart home platform, allowing

for remote control and automation.



Figure 1: Avatto TRV07 Smart Radiator Thermostat Valve. The image displays the white cylindrical device with a digital screen showing '22.5' degrees Celsius and icons for network connectivity and battery status. The adjustment ring is visible at the bottom.

Key Features:

- Zigbee 3.0 connectivity for stable and reliable communication.
- TUYA Smart Life App integration for remote control and scheduling.
- Digital display for current temperature and settings.
- Manual temperature adjustment.
- Energy saving features.

SETUP AND INSTALLATION

1. Preparing for Installation:

1. **Turn off Heating System:** Before beginning, ensure your heating system is turned off to prevent accidental water leakage or damage.
2. **Identify Valve Type:** Determine the type of radiator valve you have. The TRV07 comes with various

adapters to fit most standard radiator valves.

3. **Remove Old Thermostat Head:** Unscrew and remove the existing thermostatic radiator valve head. This usually involves unscrewing a collar or pressing a clip.

2. Installing the TRV07:

1. **Select Adapter:** Choose the appropriate adapter from the provided set that matches your radiator valve. If no adapter is needed, proceed to the next step.
2. **Attach Adapter (if needed):** Securely attach the chosen adapter to your radiator valve.
3. **Mount TRV07:** Carefully screw the Avatto TRV07 onto the adapter or directly onto the valve thread. Ensure it is hand-tightened securely but do not overtighten.
4. **Power On:** The device should power on automatically once installed. The display will light up.

Consult a professional if you encounter difficulties during installation.

PAIRING WITH ZIGBEE HUB AND TUYA APP

The Avatto TRV07 requires a Zigbee 3.0 compatible hub (e.g., TUYA Zigbee Gateway) to connect to your smart home network and be controlled via the TUYA Smart Life application.

1. Prepare Your Zigbee Hub:

- Ensure your Zigbee hub is powered on and connected to your home Wi-Fi network.
- Open the TUYA Smart Life app and confirm your hub is online.

2. Enter Pairing Mode on TRV07:

- On the TRV07, press and hold the main button (or follow specific instructions for your model, usually a long press on the central button or a combination) until the Zigbee icon on the display starts flashing. This indicates it is in pairing mode.

3. Add Device in TUYA Smart Life App:

1. Open the TUYA Smart Life app on your smartphone.
2. Tap the "+" icon in the top right corner to add a new device.
3. Select "Add Device" or navigate to the "Gateway" section and choose "Add sub-device".
4. The app will search for nearby Zigbee devices. Select the TRV07 when it appears.
5. Follow the on-screen prompts to complete the pairing process. Once successfully paired, the Zigbee icon on the TRV07 display will stop flashing and remain solid.

If pairing fails, ensure the TRV07 is close to the Zigbee hub and try again. You may need to reset the TRV07 to factory settings before re-attempting pairing (refer to Troubleshooting section).

OPERATING INSTRUCTIONS

Manual Control:

- **Adjusting Temperature:** Rotate the adjustment ring on the TRV07 clockwise to increase the target temperature and counter-clockwise to decrease it. The new target temperature will be displayed temporarily.

- **Display Information:** The digital display typically shows the current room temperature or the set target temperature. Icons indicate battery status, network connection, and operating mode.

App Control (TUYA Smart Life):

- **Remote Temperature Adjustment:** Open the TUYA Smart Life app, select your TRV07 device, and adjust the temperature slider or input a specific value.
- **Scheduling:** Set up daily or weekly heating schedules to automate temperature changes based on your routine.
- **Operating Modes:** The app allows you to switch between various modes such as Manual, Auto (scheduled), Holiday, or Eco mode, depending on the device's capabilities.
- **Child Lock:** Activate the child lock feature through the app to prevent unauthorized manual adjustments on the device.

MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Firmware Updates:** Periodically check the TUYA Smart Life app for available firmware updates for your TRV07 to ensure optimal performance and access to new features.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not powering on.	Improper installation or power issue.	Ensure the device is correctly mounted and secured to the valve. Check the power source (if external) or contact support if internal power is suspected.
Cannot pair with Zigbee hub.	Device not in pairing mode, hub too far, or interference.	Ensure the TRV07 is in pairing mode (flashing Zigbee icon). Move the TRV07 closer to the hub. Check for other Zigbee devices causing interference. Try resetting the TRV07 and re-pairing.
Temperature not adjusting.	Valve stuck, child lock active, or communication issue.	Manually check if the radiator valve pin moves freely. Deactivate child lock in the TUYA app. Verify Zigbee connection.
Inaccurate temperature readings.	Device placement or external factors.	Ensure the TRV07 is not exposed to direct sunlight, drafts, or heat sources that could affect its internal sensor.

Factory Reset:

To perform a factory reset, typically you would press and hold a specific button combination for several seconds until the display indicates a reset. Refer to the device's specific button layout or the TUYA app for exact instructions if needed. A factory reset will unpair the device and restore default settings.

SPECIFICATIONS

- **Model:** TRV07
- **Brand:** AVATTO
- **Connectivity:** Zigbee 3.0
- **App Support:** TUYA Smart Life
- **Batteries Required:** No (as per product specifications)

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided with your purchase or contact your retailer. For technical support, troubleshooting assistance, or further inquiries, please visit the official AVATTO website or contact their customer service department.

Note: Product specifications and features are subject to change without prior notice.

Related Documents - TRV07

	Avatto TRV07 Zigbee 3.0 Smart Thermostatic Radiator Valve User Manual Comprehensive user manual for the Avatto TRV07 Zigbee 3.0 Smart Thermostatic Radiator Valve. This guide covers installation, setup, features like app control via Smart Life and voice commands with Amazon Alexa/Google Assistant, temperature modes, troubleshooting, and technical specifications.
	TRV06 Wireless Smart Radiator Thermostat User Manual User manual for the AVATTO TRV06 Wireless Smart Radiator Thermostat, covering setup, operation, and app connection. Includes specifications and troubleshooting.
	Avatto ZWT198/ZWT100-BH Smart Wall Thermostat - Technical Specifications Detailed technical specifications and control parameters for the Avatto ZWT198/ZWT100-BH smart wall thermostat, including settings for climate control, scheduling, and device management via MQTT.

Inteligentní termostat Avatto ZWT198 ZigBee TUYA Instrukcja obsługi  Produkt jest zgodny z Dyrektywą Europejską CE i posiada certyfikat zgodności z normami CE. Produkt jest zgodny z normami CE i posiada certyfikat zgodności z normami CE.	Avatto ZWT198 ZigBee TUYA Smart Thermostat User Manual and Specifications Comprehensive user manual for the Avatto ZWT198 ZigBee TUYA smart thermostat, covering application, operation, WiFi connection, specifications, wiring, programming, installation, parameter settings, FAQ, safety precautions, environmental information, battery care, and EU declaration of conformity.
	AVATTO WT198/ZWT198 Zigbee Smart Thermostat User Manual Comprehensive user manual for the AVATTO WT198/ZWT198 Zigbee Smart Thermostat, covering installation, operation, programming, troubleshooting, and app integration for intelligent temperature control.
Inteligentní termostat Avatto WT198 WiFi TUYA Instrukcja obsługi 	Avatto WT198 WiFi TUYA Intelligent Thermostat - User Manual & Specifications Comprehensive user manual for the Avatto WT198 WiFi TUYA intelligent thermostat. Learn about application, operation, WiFi connection, specifications, wiring, installation, programming, parameter settings, troubleshooting, safety, and environmental protection.

Documents - AVATTO – TRV07

Inteligentní termostatická hlavice
termostatická hlavice Avatto TRV07
Zigbee 3.0 TUYA
Dálkové ovládání prostřednictvím aplikace
Smart Life, hlasové ovládání prostřednictvím
Amazon Alexa a Google Assistant



Kompatibilní s
Amazon Alexa

Kompatibilní s
Google Assistant

Verze 1.0 12/2022 71.04.00204

[pdf]

TRV07 PL AVATTO CZ files innpro pl s3 amazonaws Avatto |||

Inteligentn termostatick hlavice termostatick hlavice Avatto **TRV07** Zigbee 3.0 TUYA

Dlkov ovldn prstednictvm aplikace Smart Life, hlasov ovldn prstednictvm Amazon

Alexa a Google Assistant Kompatybilne z Amazon Alexa Kompatybilne z Google

Assistant Wersja:1.0 12/2022 71.04.00204 Personalizovan...

lang:en score:40 filesize: 13.28 M page_count: 19 document date: 2023-09-01



[Avatto TRV07 Zigbee 3.0 Smart Thermostatic Radiator Valve User Manual](#)

Comprehensive user manual for the Avatto TRV07 Zigbee 3.0 Smart Thermostatic Radiator Valve. This guide covers installation, setup, features like app control via Smart Life and voice commands with Amazon Alexa/Google Assistant, temperature modes, troubleshooting, and technical specifications.

lang:en score:39 filesize: 18.31 M page_count: 18 document date: 2023-02-01



[pdf]

TRV07 PL HU files innpro pl s3 amazonaws Avatto |||

Intelligens termosztatikus fej Avatto **TRV07** Zigbee 3.0 TUYA Tvvezrls tmogatsa smart life alkalmazson keresztl, hangvezrls az Amazon Alexa s a Google Assistant segtsgvel 16:00 ZigBee Smart Thermostat - 225 Current temperature20.6C Mode Auto Working status Heating State of the window close A Au...

lang:en score:35 filesize: 12.97 M page_count: 21 document date: 2023-01-25




[pdf]

fisa tehnica Capat termostatic inteligent pentru calorifer Wi Fi TUYA Smart Life Avatto TRV07 WIFI a2t ro sebi atutech Producator Avato Model Culoare Alb Cu sprijinul Baterii alcaline 3x 1 5V AA nu sunt incluse Conectivitate wireless Fisa source |||

Capat termostatic inteligent pentru calorifer, Wi-Fi, TUYA, Smart Life, Avatto, **TRV07-WIFI** Producator Model Culoare Cu sprijinul Conectivitate wireless Curent de asteptare Grad de protectie Temperatura ambientala Conexiune Dimensiuni Greutate Aplicatie Avato **TRV07-WIFI** Alb Baterii alcaline 3x 1,5V...

lang:en score:33 filesize: 127.35 K page_count: 1 document date: 2023-03-09



[pdf]

6976037360025 TRV07 WiFi CZ Návod k obsluze cze Avatto termosztatikus fej TUYA inteligens 50172

28426 cf39e9a35e7d3e8b53b1d96da5c8a519 puputeve hu media wysiwyg attachments |||

Intelligentn termostatick hlavice Avatto **TRV07** Wi-Fi 16:00 ZigBee Smart Thermostat - 22.5 Current temperature 20.6°C Mode Auto Working status Heating State of the window close A Auto Week prog... Setting Statistics Kompatibilita s Amazon Alexa Kompatibilita s Google Assistant Verze :1.0 12...

lang:en score:32 filesize: 13.42 M page_count: 19 document date: 2024-04-12



[pdf]

TRV07 WiFi PL files innpro pl s3 amazonaws Avatto WIFI |||

Wi-Fi 16:00 ZigBee Smart Thermostat - 22.5 Current temperature 20.6°C Mode Auto Working status Heating State of the window close A Auto Week prog... Setting Statistics Amazon Alexa Google Assistant :1.0 12/2022 71.04.00204 TRV LE D ZigBee Smart Thermostatic Radiator Valve Supporting...

lang:en score:25 filesize: 15.53 M page_count: 17 document date: 2023-02-01


[\[pdf\]](#) User Manual Installation Guide

Manual de utilizare pentru Capat termostatic inteligent calorifer Wi Fi TUYA Smart Life Avatto TRV07

WIFI a2t ro sebi atutech source |||

LED Wi-Fi Smart Thermostatic Radiator Valve Supporting remote control by smart life app, voice control by Amazon Alexa and Google Assistant 16:00 WiFi Smart Thermostat - 23.5 Current temperature 20.6°C Mode Auto Working status Heating State of the window close A Auto Week prog... Setting St...

lang:en score:22 filesize: 2.65 M page count: 1 document date: 2023-03-10



[\[pdf\]](#) Decleration of Conformity

TRV07 DOC files innpro pl s3 amazonaws Avatto |||

[illegible]

lang:tl score:17 filesize: 1.2 M page_count: 2 document date: 2023-01-25



[\[pdf\]](#) Decleration of Conformity

TRV07 WiFi DOC files innpro pl s3 amazonaws Avatto WIFI ||

Shenzhen Tian Hai Test Technology Co.,Ltd. E: Deklaracja zgodności Numer
certyfikacji: TH2206236-C 11-C0 1 Shenzhen Tian Hai Test Technology Co., Ltd.
niniejszym oświadczam, że testy zostały zakończone, a raporty wygenerowane dla:
Aplikant Shenzhen Rti-Tek Co., Ltd. Adres: Room 206, Yangtian B...

lang:it score:16 filesize: 1.26 M page count: 2 document date: 2023-01-25



[\[pdf\]](#)

TRV07 WiFi HU files innpro pl s3 amazonaws Avatto WIFI |||

Wi-Fi 16:00 ZigBee Smart Thermostat - 22.5 Current temperature20.6C Mode Auto Working status Heating State of the window close A Auto Week prog... Setting Statistics Amazon Alexa Google Assistant :1.0 12/2022 71.04.00204 TRV LE D ZigBee S martThermostatic R adiator Valve Supporting...
lang:en score:16 filesize: 24.84 M page_count: 21 document date: 2023-01-25

[\[pdf\]](#) User Manual Installation Guide

TRV601 20221216 71 04 00204 cdr administrator TRV07 EN files innpro pl s3 amazonaws Avatto |||

LED ZigBee Smart Thermostatic Radiator Valve Supporting remote control by smart life app, voice control by Amazon Alexa and Google Assistant 16:00 ZigBee Smart Thermostat - 22.5 Current temperature20.6C Mode Auto Working status Heating State of the window close A Auto Week prog... Setting...
lang:en score:13 filesize: 3.67 M page_count: 1 document date: 2022-12-16

[\[pdf\]](#)

TRV07 WiFi PL dobre promo*Uwaga Konfiguracja sieci może być przeprowadzona tylko w trybie ręcznym Proszę włączyć Bluetooth swoim telefonie wcześniej Upewnij się że28426 19254dobre promo pl p file e1fadfe1ea99e96c4937c35b85bf1c25 28426 19254 srsId AfmBOoo8mX21E1a9VD 9QBnuOU1sPoBx1hxV u29TutjGrlioYMku g promoTRV07 że*Uwaga żedobre gdobre AfmBOorFTIfko1clhJX Wf4WBkZOSRSobe1ixXU5I9RZmTyHvryaav1i żeglowica avatto instrukcjadobre Wf4WBkZOSRSobe1ixXU5I9RZmTyHvryaav1icdn bonmario glowica instrukcja ||| ||| Wi-Fi 16:00 ZigBee Smart Thermostat - 22.5 Current temperature20.6C Mode Auto Working status Heating State of the window close A Auto Week prog . Setting Statistics Amazon Alexa Google Assistant :1.0 12/2022 71.04.00204 TRV LE D ZigBee S mar ||| Wi-Fi 16:00 ZigBee Smart Thermostat - 22.5 Current temperature20.6C Mode Auto Working status Heating State of the window close A Auto Week prog . Setting Statistics Amazon Alexa Google Assistant :1.0 12/2022 71.04.00204 TRV LE D ZigBee S mar Wi-Fi 16:00 ZigBee Smart Thermostat - 22.5 Current temperature20.6C Mode Auto Working status Heating State of the window close A Auto Week prog... Setting Statistics Amazon Alexa Google Assistant :1.0 12/2022 71.04.00204 TRV LE D ZigBee S martThermostatic R adiator Valve Supporting...
lang:en score:13 filesize: 15.53 M page_count: 17 document date: 2023-02-01




[\[pdf\]](#) User Manual Installation Guide

TRV603 20221216 71 04 00206 cdr administrator TRV07 Wifi EN files innpro pl s3 amazonaws

Avatto WIFI |||

LED Wi-Fi Smart Thermostatic Radiator Valve Supporting remote control by smart life app, voice control by Amazon Alexa and Google Assistant 16:00 WiFi Smart Thermostat - 23.5 Current temperature 20.6C Mode Auto Working status Heating State of the window close A Auto Week prog... Setting St...

lang:en score:13 filesize: 3.68 M page_count: 1 document date: 2022-12-16



[\[pdf\]](#)

Avatto TRV07 Smartes Heizkörperthermostat BerryBase AT Der Thermostat stellt die Temperatur automatisch auf 12°C ein und dem Display erscheint OP Jetzt kannst du hohe Heizkostenrechnungen vergessen! Heizkoerperthermostat berrybase at Pixel data Article id 11415 onumber |||

...

lang:en score:11 filesize: 159.25 K page_count: 3 document date: 2023-04-15

[\[pdf\]](#)

Avatto TRV07 Smartes Heizkörperthermostat Zigbee AT EN 1 giorno fa — Habe die Gewissheit dass deine Heizung voll funktionsfähig ist Der hat eine automatische Entkalkungsfunktion Was das bedeutet Thermostat führt Heizkoerperthermostat berrybase at en Pixel data Article id 11415 onumber AVA |||

...

lang:en score:10 filesize: 182.7 K page count: 3 document date: 2024-05-06

[\[pdf\]](#)

Avatto TRV07 Smartes Heizkörperthermostat WiFi CH IT BerryBase 2 days ago — Das Thermostat ventil
ist ein praktisches Gerät mit dem du die Heizung in deinem Haus bequem steuern kannst Mit
Heizkoerperthermostat berrybase ch it Pixel data Article id 11414 onumber AVA TRV07W |||

...

lang:en score:10 filesize: 199.63 K page count: 3 document date: 2024-04-14

sertronics

Datenblatt

Avatto TRV07 Smartes Heizkörperthermostat



AVATTO

Artikel-Nr.: TRV07

Hersteller: Avatto

EAN: 607637300018

Herzauflösung: China

Zustelltemperatur: 14818031

Gewicht: 0,221 kg

Das Avatto TRV07 Thermostat ist ein praktisches Gerät, mit dem du die Heizung in deinem Haus bequem steuern kannst. Mit der Touch-Screen-App kannst du das Gerät von der Ferne steuern und auch Temperaturprofile erstellen. Mit dem Tuya-System (Tuya) in der Wohnung erhältst du alle Funktionen, die das Thermostat bietet. Es bietet dir eine Reihe nützlicher Funktionen zur Verfügung, wie z. B. die Erzeugung offener Fenster und die automatische Erhöhung der Außentemperatur bei einem eingetragenen digitalen 3-D-Modell. Es verfügt über ein LCD-Display, das den Zugriff auf die wichtigsten Informationen erleichtert, und in der Lüftung sind zwei verschiedene Adapter enthalten, so dass du das Gerät problemlos installieren kannst.

Erzeugung offener Fenster
Reagiere auf das Öffnen des Fensters. Das Gerät verfügt über eine Funktion für offene Fenster, die sofort aktiviert wird, wenn es einen kalten Wind und einen Temperaturanstieg von mehr als 1°C in 4,5 Minuten feststellt. Der Thermostat stellt die Temperatur automatisch auf 12°C ein, und auf dem Display erscheint "OP". Jetzt kannst du hohe Heizkostenrechnungen vergessen!

Automatische Erhöhung
Nimm die Kontrolle, wenn deine Heizung nicht funktioniert ist. Der TRV07 hat eine automatische Erhöhungsfunktion. Was das bedeutet, der Thermostat führt jeden Montag um 12:00 Uhr eine mehrstündige Erhöhung durch, um zu verhindern, dass sich eine große Menge an Kosten anhäuft. Während des gesamten Vorgangs wird auf dem Display "CAL" angezeigt.

Zusätzliche Funktionen
Das Gerät verfügt auch automatisch über weitere Einstellungen, wie vor allem bei einem Stromausfall sehr nützlich ist. Außerdem verfügt es über eine spezielle Kindersicherung, die verhindert, dass du die Temperatur veränderst. Du kannst auch die Thermostate in verschiedenen Räumen synchronisieren, indem du spezielle Gruppen erstellst.

Alle Informationen an deinen Fingernagel
Wird du bequemer Zugriff auf alle Informationen haben? Lade dir die kostenlose Tuya Smart App auf dein Smartphone oder Tablet! Mit ihrer Hilfe kannst du dein Heizkörperthermostat ganz einfach von überall aus steuern. Sobald du das Gerät mit dem Tuya-System (Tuya) in der Wohnung erhältst, werden alle Funktionen, die das Thermostat bietet, dir sofort zur Verfügung stehen. Google Home oder Amazon Alexa können ebenfalls verwendet werden, um die Temperatur in einem Raum an deine Bedürfnisse anzupassen. Außerdem kannst du das Gerät über die App mit anderen Funktionen verbinden, um gewonnenen an andere Räume zu schicken.

Erstelle Anwesenheitspläne
Passen die Temperatur in deinem Schlafzimmer oder Wohnzimmer an deinen Zeitplan an. Mit der App kannst du einen Wochenplan für

Alle hier angegebenen Namen und Zeichen sind Eigentum der jeweiligen Hersteller. (Übersicht, Änderungen & Fehler vorbehalten)

1/12
08.09.2023

[pdf]

Avatto TRV07 Smartes Heizkörperthermostat BerryBase DE 18 ore fa — Der Thermostat stellt die Temperatur automatisch auf 12°C ein und dem Display erscheint OP Jetzt kannst du hohe Heizkostenrechnungen vergessen! Heizkoerperthermostat berrybase de Pixel data Article id 11415 onumber |||

...
lang:en score:10 filesize: 179.1 K page_count: 3 document date: 2023-09-06

sertronics

Datenblatt

Avatto TRV07 Smartes Heizkörperthermostat



AVATTO

Order number: TRV07

Hersteller: Avatto

EAN: 607637300018

Herzauflösung: China

Zustelltemperatur: 14818031

Gewicht: 0,221 kg

Das Avatto TRV07 Thermostat ist ein praktisches Gerät, mit dem du die Heizung in deinem Haus bequem steuern kannst. Mit der Touch-Screen-App kannst du das Gerät von der Ferne steuern und auch Temperaturprofile erstellen. Mit dem Tuya-System (Tuya) in der Wohnung erhältst du alle Funktionen, die das Thermostat bietet. Es bietet dir eine Reihe nützlicher Funktionen zur Verfügung, wie z. B. die Erzeugung offener Fenster und die automatische Erhöhung der Außentemperatur bei einem eingetragenen digitalen 3-D-Modell. Es verfügt über ein LCD-Display, das den Zugriff auf die wichtigsten Informationen erleichtert, und in der Lüftung sind zwei verschiedene Adapter enthalten, so dass du das Gerät problemlos installieren kannst.

Erzeugung offener Fenster
Reagiere auf das Öffnen des Fensters. Das Gerät verfügt über eine Funktion für offene Fenster, die sofort aktiviert wird, wenn es einen kalten Wind und einen Temperaturanstieg von mehr als 1°C in 4,5 Minuten feststellt. Der Thermostat stellt die Temperatur automatisch auf 12°C ein, und auf dem Display erscheint "OP". Jetzt kannst du hohe Heizkostenrechnungen vergessen!

Automatische Erhöhung
Nimm die Kontrolle, wenn deine Heizung nicht funktioniert ist. Der TRV07 hat eine automatische Erhöhungsfunktion. Was das bedeutet, der Thermostat führt jeden Montag um 12:00 Uhr eine mehrstündige Erhöhung durch, um zu verhindern, dass sich eine große Menge an Kosten anhäuft. Während des gesamten Vorgangs wird auf dem Display "CAL" angezeigt.

Zusätzliche Funktionen
Das Gerät verfügt auch automatisch über weitere Einstellungen, wie vor allem bei einem Stromausfall sehr nützlich ist. Außerdem verfügt es über eine spezielle Kindersicherung, die verhindert, dass du die Temperatur veränderst. Du kannst auch die Thermostate in verschiedenen Räumen synchronisieren, indem du spezielle Gruppen erstellst.

Alle Informationen an deinen Fingernagel
Wird du bequemer Zugriff auf alle Informationen haben? Lade dir die kostenlose Tuya Smart App auf dein Smartphone oder Tablet! Mit ihrer Hilfe kannst du dein Heizkörperthermostat ganz einfach von überall aus steuern. Sobald du das Gerät mit dem Tuya-System (Tuya) in der Wohnung erhältst, werden alle Funktionen, die das Thermostat bietet, dir sofort zur Verfügung stehen. Google Home oder Amazon Alexa können ebenfalls verwendet werden, um die Temperatur in einem Raum an deine Bedürfnisse anzupassen. Außerdem kannst du das Gerät über die App mit anderen Funktionen verbinden, um gewonnenen an andere Räume zu schicken.

Erstelle Anwesenheitspläne
Passen die Temperatur in deinem Schlafzimmer oder Wohnzimmer an deinen Zeitplan an. Mit der App kannst du einen Wochenplan für

Alle hier angegebenen Namen und Zeichen sind Eigentum der jeweiligen Hersteller. (Übersicht, Änderungen & Fehler vorbehalten)

1/12
27.08.2023

[pdf]

Avatto TRV07 Smartes Heizkörperthermostat AT EN BerryBase 2 — Der Thermostat stellt die Temperatur automatisch auf 12°C ein und dem Display erscheint OP Jetzt kannst du hohe Heizkostenrechnungen vergessen! Heizkoerperthermostat berrybase at en Pixel data Article id 11415 onumber |||

...
lang:en score:10 filesize: 179 K page_count: 3 document date: 2023-08-27