

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DOG CARE](#) /

› [DOG CARE TC01 Dog Training Collar Instruction Manual](#)

## DOG CARE TC01-1208

# DOG CARE TC01 Dog Training Collar Instruction Manual

Model: TC01-1208 | Brand: DOG CARE

## INTRODUCTION

---

This manual provides detailed instructions for the safe and effective use of your DOG CARE TC01 Dog Training Collar. Designed for dogs weighing 15 to 100 pounds, this collar offers multiple training modes to assist in obedience training and behavior correction. Please read this manual thoroughly before operating the device.

## PACKAGE CONTENTS

---

- Remote Control Transmitter
- Training Collar Receiver with Adjustable Strap
- USB Charging Cable
- Lanyard
- Contact Points (short and long)
- Silicone Conductive Caps (for contact points)



Image: The DOG CARE TC01 remote control and collar receiver, showcasing the main components included in the package.

## SETUP GUIDE

---

### 1. Charging the Devices

Both the remote control and the collar receiver are rechargeable. Use the provided USB charging cable to charge both devices simultaneously. A full charge typically takes approximately 2 hours. The remote offers up to 45 days standby time, and the receiver up to 15 days.

# LONG-LASTING BATTERY LIFE & EASY CHARGING



- Remote -



Up to **45 Days**  
Standby Time



- Receiver -



Up to **15 Days**  
Standby Time



**Mirco USB Charging Port**

Easy Charging by Your PC/Laptop/Phone Charger/Power Bank

Image: Diagram illustrating the USB charging ports on both the remote and the collar receiver, highlighting their long-lasting battery life.

## 2. Fitting the Collar

Ensure the collar fits snugly but comfortably around your dog's neck. It should be tight enough for the contact points to touch the skin, but not so tight as to restrict breathing or cause discomfort. The collar is adjustable and suitable for dogs weighing between 15 to 100 pounds.

# TRAINING COLLAR FOR 15LBS~100LBS DOGS



Image: Visual guide demonstrating proper fitting of the DOG CARE TC01 collar on a dog, emphasizing comfort and contact point placement.

### 3. Turning On/Off and Pairing

To turn on the collar receiver, press and hold the power button on the receiver until the green indicator light illuminates. To turn off, press and hold the power button until the red light appears. The remote control can be turned on by pressing any button. The devices are pre-paired from the factory. If re-pairing is needed, refer to the detailed pairing instructions in the full manual.

Video: An unboxing and demonstration of the DOG CARE TC01 training collar, showing how to turn on/off the devices and their initial setup.

### OPERATING MODES

The DOG CARE TC01 offers five safe and efficient training modes to help you teach basic obedience and correct unwanted behaviors.

# 5 TRAINING MODES

Safe Training with Customized Experience



Vibrate



Keypad Lock



0~99 level



Multiple Control



Beep



Image: Infographic detailing the five training modes: Beep, Vibration, 0-99 Static Level, Keypad Lock, and Multiple Control.

## 1. Beep Mode

Emits an audible tone from the collar. This mode is ideal for initial training and gaining your dog's attention without physical stimulation.

## 2. Vibration Mode

Provides a gentle vibration. This can be used as a stronger cue than the beep, suitable for dogs that need a more noticeable signal.

## 3. Static Mode (0-99 Adjustable Levels)

Delivers a static stimulation. The intensity is adjustable from 0 to 99, allowing you to find the precise level for your dog's sensitivity. Always start at the lowest level and increase gradually if necessary. Silicone caps are provided for comfort and safety.

## 4. Security Keypad Lock

The remote features a keypad lock to prevent unintentional commands. Slide the lock switch on the side of the remote to activate or deactivate this feature, ensuring safe handling during training sessions.



Image: Close-up of the remote control highlighting the security keypad lock feature to prevent accidental button presses.

## 5. Multiple Control (Up to 9 Dogs)

Unlike many other training collars, the DOG CARE TC01 remote can control up to 9 individual collar receivers. This is ideal for households with multiple dogs, allowing you to switch between channels to train each dog independently.



Image: Illustration showing the remote controlling multiple dogs, emphasizing the 9-channel maximum control feature.

## Remote Control Range

The wireless control range can reach up to 1800 feet in open areas and approximately 1000 feet with obstacles. This extended range provides flexibility for training in various environments.



Image: Depiction of the DOG CARE TC01 remote control and its effective range, noting the difference between open areas and areas with obstacles.

## MAINTENANCE

### Waterproof and Dust-proof

The collar receiver is IP67 waterproof and dust-proof, allowing your dog to play freely in various conditions. However, it is recommended to remove the collar when your dog is swimming or bathing to ensure longevity and prevent potential issues.

# LONG-LASTING BATTERY LIFE & EASY CHARGING



- Remote -



Up to **45 Days**  
Standby Time



- Receiver -



Up to **15 Days**  
Standby Time



**Mirco USB Charging Port**

Easy Charging by Your PC/Laptop/Phone Charger/Power Bank

Image: A dog playing in water with the DOG CARE TC01 collar, illustrating its IP67 waterproof rating.

## Cleaning and Storage

Regularly clean the collar and contact points with a damp cloth. Ensure the devices are completely dry before charging or storing. Store in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Collar not responding to remote	Low battery on either device; devices not paired; remote keypad locked.	Charge both devices; re-pair the devices (refer to full manual); unlock remote keypad.
Dog not responding to stimulation	Collar too loose; contact points not touching skin; stimulation level too low.	Adjust collar fit; ensure contact points are making contact; increase stimulation level gradually.

Problem	Possible Cause	Solution
Reduced remote range	Environmental interference; low battery.	Move to an open area; charge devices.

## SPECIFICATIONS

**Model Number:** TC01-1208

**Item Weight:** 9.9 ounces

**Item Dimensions (LxWxH):** 7.48 x 1.97 x 0.98 inches

**Battery Type:** 1 Lithium Metal battery (included)

**Waterproof Rating:** IP67

**Remote Range:** Up to 1800FT (open area), 1000FT (with obstacles)

**Adjustable Static Levels:** 0-99

**Supported Dogs:** Up to 9 (with additional receivers)

**Suitable Dog Weight:** 15-100 lbs

## IMPORTANT SAFETY INFORMATION

- Do not use this product on aggressive dogs.
- Ensure the collar is properly fitted to prevent skin irritation.
- Avoid leaving the collar on your dog for more than 12 hours per day.
- Regularly check your dog's neck for any signs of irritation or sores.
- Use static stimulation as a last resort and always start with the lowest effective level.
- This device is a training tool, not a punishment device. Use it responsibly and humanely.

## WARRANTY & SUPPORT


For warranty information, technical support, or any inquiries regarding your DOG CARE TC01 Dog Training Collar, please visit the official DOG CARE website or contact their customer service. Contact details can typically be found on the product packaging or the brand's Amazon store page.

Visit the [DOG CARE Store on Amazon](#) for more products and support.

## Related Documents - TC01-1208

	<p><a href="#">DOGCARE Dog Training System TC01 Pro User Manual &amp; Safety Guide</a></p> <p>Comprehensive user manual for the DOGCARE TC01 Pro Dog Training Collar, covering safety instructions, quick start guide, operation, and specifications for remote dog training.</p>
---	---

	<p><b>DogCare WELL-D ADV TC01 Dog Training Collar FAQ</b></p> <p>Comprehensive FAQ for the DogCare WELL-D ADV TC01 Dog Training Collar, covering setup, pairing, troubleshooting, training tips, and safety. Get answers to common questions for effective pet training.</p>
	<p><b>WELL-D SD Dog Training System EC11 User Manual</b></p> <p>Comprehensive user manual for the WELL-D SD Dog Training System, model EC11. Learn about setup, collar fitting, training modes (vibration, sound, static), pairing, troubleshooting, safety guidelines, and product specifications.</p>
	<p><b>Dog Care TC01 Dog Training Collar User Manual</b></p> <p>User manual for the Dog Care TC01 Dog Training Collar, providing instructions on setup, training modes, matching the remote to the receiver, troubleshooting, and product specifications.</p>
	<p><b>DOG CARE TC05 Dog Training Collar User Manual and Guide</b></p> <p>Comprehensive user manual for the DOG CARE TC05 Dog Training Collar, covering setup, operation, training modes, troubleshooting, and safety guidelines.</p>
	<p><b>DOG TRAINING COLLAR</b></p> <p>User Manual Model:TC01</p> <p><b>I. Product Overview</b></p>  <p>Remote Control On &amp; OFF Switch / Static Level Regulator Repeal Lock Static Level Regulator Adjustment Vibrate Button Micro USB Charging Port Screen Training Mode Remote's Signal Repeat Lock User Manual Model:TC01</p> <p>Antenna Display Screen Static Button Channel Switch / Mode Button Beep Button Lanyard Holder</p> <p>Channel Display (1-10) Static Level Display (1-99) Battery Status (Normal) Battery Status (Warning)</p> <p><b>II. Package Content</b></p> 




#### II. Setting Up

1. Charge the devices respectively for 2 hours and more.

Remote Control: Charge the device until the battery icon on the display indicates full bar.



Receiver: Charge the device until the red LED turns green. The display on the Remote will indicate full bar as well.



2. Match the Remote Control to the Receiver: You may skip this step if the set is already paired by factory setting.

2.1. Connect the Receiver to a power source via the USB cable, matching mode can only be set during the pairing.

2.2. Press and hold Channel Switch / Match Button for 2 secs. The Receiver will vibrate and beeps indicates the Match is complete. You will see the Channel Display in the Channel Display if matching is successful.




Adding multiple Receivers:

2.3. Connect your additional Receiver to a power source. Press and hold Channel Switch / Match Button for 2 secs. The Channel Display will show the subsequent number of the new Receiver. Note: You can only connect one at a time, do not connect all simultaneously, or the Remote will match all Receivers into a single channel.




3. Removing of Matched Receivers:

Press and hold Static Level Regulator Activation Button and Beep Button simultaneously for 2 secs. The Channel Display will default to '0'. Note: Make sure the Receiver is connected to have power and in the effective range, so that Receivers could receive the remove command.



4. Configuring Static Level:

Press and hold Static Level Regulator Activation Button and simultaneously rotate Static Level Regulator until the digit on the screen reaches a suitable strength.



Recommended Static Level strength starts from \*10\*. This is the minimum sensation your dog can feel. You can increase the strength on an individual basis which you should find out from your dog's responses. The sensitivity to static depends on the dog's breed, age, coat, the amount of fur, and even skin condition.

#### III. Training Modes

1. Vibration Mode:

Press Vibrate Button, and the Receiver will vibrate once hold the button and the vibration persists.




2. Sound Mode:

Press Beep Button, and the Receiver will give a "beep" sound; hold the button and the "beep" sound persists.



3. Static Stimulation Mode:

Press the Static Button, and the Receiver will give 2 static stimulation on the weaker.



Do not hold the button as it is not recommended to have prolonged shock to your dog. The static however will turn off in 4 secs automatically to prevent unnecessary harm to your pet.

4. Switching Channel:

Press the Channel Switch Button to choose which Receiver you want to control if you matched more than one Receiver.



5. Wearing the Receiver Collar:

1. Thread the collar through the Receiver.

2. If your dog has thick fur, please separate the fur at the electrodes with a comb to make them fit the size.

3. When wearing the collar, the tightness is at its most fitting if one finger can be inserted underneath.

4. The Electrode Caps can dull the static sensation, you should decide if you need to use the caps. The electrode caps also protect your dog from direct contact with metal accessories which in some cases can cause discomfort to some dogs.

#### VI. Training Tips

1. Rewarding your dog with food will usually help to reinforce the basic rules.

2. Do not use the device on dogs aged below 6-months, old, pregnant, sick, high-risk, aggressive, or any other dog that is not in best of health.

3. Use verbal commands first, and supplement with a verbal command only as needed. Be consistent with your verbal commands, using the same command for the same action, only pet on one behavior at a time to avoid confusion and over-stimulation. Use a little stimulus at a time and only to reward the correct commands when necessary. Do not over stimulate your dog with too many commands.

4. For example, use the beeps as warning by pressing Beep Button. The dog will become conditioned to the beeps as a warning of corrective stimulus and will soon learn to recognize the beeps as a warning along with your verbal commands.

5. Do not rely on this product solely to train your dog. It is not a replacement for a qualified product. We cannot guarantee the effectiveness of this or any trainer on your dog.

If your dog exhibits growling, snarling, biting or aggression while using the collar, discontinue use immediately and contact a professional trainer for advice.

#### VII. Important Notes:

Informing you and the product:  
1. It is strictly prohibited to open the Receiver in any situation. Doing so will likely compromise the waterproof function and thus voiding the product warranty.

2. Please use Remote Control and Receivers from the complete set, do not use other product to match the receiver.

3. If you want to test the product, please use receiver and remote control together and not with hands, as to avoid accidental injury.

4. If find water at the charging port, please wipe it off and do not charge it.

5. Beware that interference from the environment can cause the product to not work properly. Examples include mobile phones, wireless routers, communication towers, thunderstorms, large buildings and strong electrical fields.

6. Both Remote and Receiver have a automatic power saving mode. They will enter sleep mode if idle for 20 mins.

7. The Remote is not a basic accessory and is not necessarily suitable for all types of dog breeds. Any collar wider than 24mm and

## DOG CARE TC01 Dog Training Collar User Manual

User manual for the DOG CARE TC01 Dog Training Collar, detailing product overview, package contents, setup instructions, training modes, wearing the receiver collar, training tips, important notices, troubleshooting, operating environment, maintenance, terms of use, FCC statements, and product specifications.

not thicker than 5mm, made of soft material, can be a replacement for the current collar.

Legend well-being of your dog:

1. Wear the collar and the regular collar and not recommended to put on a lead to walk your dog. (Doing so during pulling may hurt the dog or provoke electrical shocks on the Receiver).
2. Do not put the collar on for over 12 hours, may cause your dog to be uncomfortable and dogs skin.
3. Do not allow children, or anyone who has little to no experience with training dogs, to handle this training kit.
4. If you want to activate normal training function, please insert the waterproof rubber lid over the charging port.
5. Shock training is not a pleasant experience for any dogs. Punishment is a harsh way to train a dog. It is better to train your dog with body or good behavior. Note: With Anti Misoperation design, Static function always cut off after 4 Secs, Static function is designed to prevent unintentional long press of the buttons, and potential animal abuse.

#### III. Troubleshooting

1. Remote Control / Receiver runs out of power quickly not charging. Make sure the charger and Remote Control / Receiver are connected correctly. Recharge the Remote Control. Check the battery of the Remote; Match Remote Control to the receiver again. Receiver will be off.
2. Make sure the Receiver has been matched; Check your Remote, make sure the receiver is in the range of the remote. Check your Remote, make sure both devices have enough power.
3. Make sure the Remote has no effect on my dog. Make sure the Receiver is working and the electrodes touching the dog's skin. Try increase the strength of the Static.
4. Make sure the dog is in the range of the receiver in short distance. Make sure there is no strong signal disturbance in your surroundings. The Remote's range could fluctuate subject to obstacles, electromagnetic fields, and other factors.
5. Receiver Beeps, Vibrates, sending Static to itself constantly or occasionally. Make sure the receiver has been pressed or gotten stuck. Match Receiver to the Remote Control again.
6. Remote Control fails to match. Make sure the receiver is connected to a power source and in charging mode while you match.

#### IV. Operating Environment & Maintenance

Do not use the product in the circumstances below:

1. Do not operate the device under temperature of 10-49° and above, doing so in such high temperature will decrease the performance of the device.
2. Do not use the Remote during snowing, this could lead to water seeping in causing damage to the controller.
3. Do not use the set in places with strong electromagnetic fields. This will greatly compromise the performance of the product.
4. Avoid dropping the device on hard surface or in water.
5. Avoid using the device in environment flooded with water or chemical, this may lead to color degreding, deformation or cracking of exterior of the devices.

Maintenance:

1. When not in use, please wipe clean both the Remote and Receiver with mild detergent. Turn off the Remote, lock the keypad, put on the rubber lid over the charging port, and store the set in a cool dry place.
2. During cleaning, wipe with soft cloth and mild detergent. Do not use abrasive materials that may scratch the surface of the device.
3. If the device has gotten dirty, run the charging port over a lid of water and wash it thoroughly. Note: Do not submerge the Receiver into water for a long period of time, even though it is waterproof.
4. If found residues around the charging port's edges, please clean it often prevent water from slipping in.
5. If the device is wet, please pat it dry with cloth as much as you can and let it out to dry. It should resume function normally once the moisture is dried out.

#### IX. Terms of Use & Limitation of Liability

1. Use of this product means you accept all the terms and conditions.
2. This product is a professional dog training device. You are not recommended to use this product if your dog is clever and less than 8 lbs in weight. If you are not sure if this product is suitable for your pet dog, please consult a professional handler or contact us.
3. This product is a radio frequency emitting device and should not be used for other purposes. It is illegal to violate local laws in using this product.
4. We bear no liability for any direct or indirect losses resulting from the use of this product; all risks in using this product shall be borne by user.
5. Please contact the dealer for parts warranty, goods return or exchange. We provide only technical support.
6. We reserve the right to alter the terms, conditions and notices of this product offered.

#### X. FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### XI. Product Specification

Model	T031
Package Dimension	8.0" x 3" x 3"
Collar Dimension	21.0" x 4.8"
Receiver's Casing	IP67 waterproof, Rain resistant, Shock resistant
Remote's Casing	Non-waterproof, Keep away from water
Remote / Receiver's Battery	3.7V 1800mAh
Charging Voltage	DC 5V/200mA
Remote / Receiver	Full Charge > 2-3 hrs
Charging Port	Micro USB
Wireless Power	10Watt
Operating Environment	0°~45°, <95% RH
Remote / Receiver	Remote: 60' dist Receiver: 100' dist
Remote to Receiver's Signal Range Distance	400' ft
Transmitter Battery Sync Distance	100' ft