

ESR 2K6090201

ESR HaloLock Magnetic Wallet with Adjustable Stand Grip User Manual

Model: 2K6090201

1. INTRODUCTION

This manual provides instructions for the ESR HaloLock Magnetic Wallet with Adjustable Stand Grip. Please read this manual carefully before using the product to ensure proper function and longevity.

2. PRODUCT OVERVIEW

The ESR HaloLock Magnetic Wallet is designed to securely attach to your iPhone 16 series (or other MagSafe-compatible iPhones 12 series or later) and MagSafe cases. It features an adjustable stand, card storage, and RFID blocking technology for enhanced security.

Key Features:

- **Upgraded Stronger Magnetic Lock:** Provides 3,000 g of holding force with ESR magnetic cases, ensuring a secure attachment. Compatible with Apple Find My functionality.
- **Adjustable Stand:** Offers versatile viewing in portrait or landscape orientations, with angles adjustable between 15° and 175°.
- **Smart Card Storage:** Designed to hold up to 3 cards securely, including a clear ID window for quick access.
- **Enhanced Security:** Integrated RFID blocking technology protects your cards from unauthorized scans.
- **Compatibility:** Specifically designed for iPhone 16, iPhone 16 Plus, iPhone 16 Pro, iPhone 16 Pro Max, and other MagSafe-compatible iPhones (12 series or later).

Included Components:

- Geo Magnetic Wallet
- Charging Cable

3. SETUP

3.1 Initial Charging

Before first use, ensure your Geo Magnetic Wallet is fully charged. Connect the provided charging cable to the wallet. The green light on the wallet will indicate a full charge.




Figure 3.1: Charging the Geo Magnetic Wallet. Ensure the green light is on for a full charge.

3.2 Pairing with Apple Find My

Follow these steps to pair your ESR HaloLock Magnetic Wallet with Apple Find My for tracking functionality:

1. **Charge your Geo Wallet:** Ensure the green light is on.
2. **Turn on Bluetooth and Location Services:** On your iPhone, navigate to Settings > Bluetooth and ensure it is enabled. Also, go to Settings > Privacy & Security > Location Services and ensure it is enabled.
3. **Press the power button:** Press the power button on your Geo Wallet until you hear a beep.
4. **Open the Find My app:** On your iPhone, open the Find My app. Go to the 'Items' tab, then 'Add New Item', select 'Other Supported Item', and follow the on-screen prompts to connect.

Figure 3.2: Pairing your ESR HaloLock Magnetic Wallet with Apple Find My.

Your browser does not support the video tag.

Video 3.1: Demonstrates the features and setup of the ESR MagSafe Wallet with full Find My functionality.

4. OPERATING INSTRUCTIONS

4.1 Attaching to Your iPhone

Align the ESR HaloLock Magnetic Wallet with the MagSafe area on the back of your iPhone or MagSafe-compatible case. The strong magnets will securely snap the wallet into place.

Strong Magnetic Lock

Locks on your phone with more than 2x the magnetic strength of the official MagSafe Wallet




Figure 4.1: Attaching the magnetic wallet to an iPhone.

4.2 Using the Adjustable Stand

The wallet features an integrated adjustable stand. Gently pull out the stand mechanism to deploy it. You can adjust the angle between 15° and 175° for optimal viewing in both portrait and landscape orientations.



Figure 4.2: The adjustable stand in portrait and landscape modes.

4.3 Storing Cards

The wallet is designed to hold up to 3 cards. Slide your cards into the designated card slots. The clear ID window allows for easy identification of one card.




Figure 4.3: Inserting cards into the wallet.

4.4 Wireless Charging Compatibility

For optimal wireless charging of your iPhone, detach the ESR HaloLock Magnetic Wallet from your device before placing it on a wireless charger.




Figure 4.4: Detach wallet for wireless charging.

5. MAINTENANCE

To clean your ESR HaloLock Magnetic Wallet, use a wet wipe. Avoid harsh chemicals or abrasive materials that could damage the faux leather finish.

6. TROUBLESHOOTING

6.1 Wallet Not Attaching Securely

- Ensure your iPhone is a MagSafe-compatible model (iPhone 12 series or later).
- If using a case, ensure it is a MagSafe-compatible case. Non-magnetic cases may prevent a secure attachment.
- Check for any debris or obstructions between the wallet and your iPhone/case.



Figure 6.1: Compatibility guide for the magnetic wallet.

6.2 Find My Functionality Issues

- Verify that Bluetooth and Location Services are enabled on your iPhone.
- Ensure the wallet is sufficiently charged.
- Confirm the wallet is correctly paired with the Find My app as per the setup instructions.

7. SPECIFICATIONS

Attribute	Value
Brand	ESR
Model Name	2k609
Model Number	2K6090201
Color	Warm Brown
Material	Faux Leather
Item Dimensions (D x W x H)	4.02"D x 2.56"W x 0.67"H

Item Weight	83 Grams
Card Slot Count	1 (designed for up to 3 cards)
Closure Type	Magnetic
Product Care Instructions	Wet Wipe Clean

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official ESR website or contact their customer service directly. Keep your purchase receipt for warranty claims.

Manufacturer: Electronic Silk Road Corp

Website: [Visit the ESR Store on Amazon](#)