

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hiseeu](#) /
- › [Hiseeu Micro 64GB SD Card User Manual](#)

Hiseeu Micro SD

Hiseeu Micro 64GB SD Card User Manual

Model: Micro SD

1. PRODUCT OVERVIEW

The Hiseeu Micro 64GB SD Card is a high-performance memory solution designed for various devices requiring reliable data storage. It offers fast read and write speeds, making it suitable for recording 4K video and loading applications quickly. Its robust design ensures data safety in diverse environments.



Image: Hiseeu Micro 64GB SD Card. This image displays the physical appearance of the Hiseeu Micro 64GB SD card, highlighting its compact size and branding.

Key Features:

- **Capacity:** 64GB for extensive storage, including 4K video.
- **Speed:** Read speed up to 90MB/s, Write speed up to 25MB/s (Class 10, A1-rated performance).
- **Durability:** Water-resistant, anti-magnetic, shockproof, and resistant to high/low temperatures.
- **Compatibility:** Ideal for security cameras, action cameras, dash cameras, Steam Deck, and Nintendo Switch.

2. SETUP AND INSTALLATION

Follow these steps to properly install your Hiseeu Micro 64GB SD Card into a compatible device.

1. **Identify the SD Card Slot:** Locate the Micro SD card slot on your device (e.g., camera, dash cam, game console). Refer to your device's manual if unsure.
2. **Orient the Card:** Ensure the Micro SD card is oriented correctly. The gold contacts on the card should align with the contacts in the device's slot. Avoid forcing the card.
3. **Insert the Card:** Gently push the Micro SD card into the slot until it clicks into place. Some devices may require a slight push with a fingernail or a small tool.
4. **Format the Card (Recommended):** For optimal performance and compatibility, it is highly recommended to format the SD card using your device's internal formatting function. This ensures the card is properly recognized and configured for your specific device.
 - *Warning:* Formatting the card will erase all data on it. Back up any important files before proceeding.
5. **Verify Installation:** After installation and formatting, check your device's settings or storage information to confirm that the 64GB Micro SD card is recognized and available for use.

3. OPERATING INSTRUCTIONS

Once installed, the Hiseeu Micro 64GB SD Card functions as your device's primary or secondary storage. Its operation is largely dependent on the host device.

General Usage:

- **Data Storage:** The card will automatically store photos, videos, applications, and other data as configured by your device.
- **4K Video Recording:** With its Class 10 and U3 speed ratings, the card supports high-resolution video recording, including 4K. Ensure your device also supports 4K recording to utilize this feature fully.
- **Application Performance:** The A1-rated performance enhances app loading times and overall responsiveness for compatible devices like smartphones or gaming consoles.
- **Data Transfer:** To transfer data to or from the card, connect your device to a computer or use a compatible SD card reader.

Removing the SD Card:

Always ensure your device is powered off or the card is safely ejected through the device's software menu before physical removal to prevent data corruption.

1. **Safely Eject:** If your device has a software option to "Eject SD Card" or "Unmount Storage," use it.
2. **Power Off:** If no software eject option is available, power off the device completely.
3. **Press to Release:** Gently press the Micro SD card inward until it clicks, then release. The card should spring out slightly, allowing you to pull it out.

4. MAINTENANCE AND CARE

Proper care extends the lifespan and ensures the reliability of your Hiseeu Micro 64GB SD Card.

- **Physical Handling:** Avoid touching the gold contacts on the card. Hold the card by its edges.
- **Storage:** Store the card in a protective case when not in use to prevent dust, scratches, and static discharge.
- **Environmental Protection:** While the card is designed to be water-resistant, anti-magnetic, shockproof, and temperature-resistant, avoid exposing it to extreme conditions unnecessarily. Keep it away from strong magnetic fields and excessive moisture.
- **Regular Backups:** Periodically back up important data from the SD card to another storage device (e.g., computer hard drive, cloud storage) to prevent data loss.
- **Formatting:** If the card's performance degrades or you encounter frequent errors, reformatting the card (after backing up data) can often resolve issues. Use the device's built-in format function or a reliable SD card formatter on a computer.

5. TROUBLESHOOTING

If you encounter issues with your Hiseeu Micro 64GB SD Card, try the following solutions:

Card Not Recognized:

- **Reinsert the Card:** Remove the card and reinsert it carefully, ensuring it is seated correctly.
- **Restart Device:** Power off and restart your device.
- **Check Compatibility:** Verify that your device supports Micro SD cards of 64GB capacity. Some older devices may have limitations.
- **Try Another Device/Reader:** Test the card in a different compatible device or an external SD card reader to determine if the issue is with the card or the original device.
- **Clean Contacts:** Gently clean the gold contacts on the SD card with a soft, dry, lint-free cloth.

Slow Performance or Errors:

- **Free Up Space:** Ensure the card is not nearly full. Performance can degrade when storage is almost exhausted.
- **Format the Card:** If data is backed up, format the card using your device's utility or a computer. This can resolve file system corruption.
- **Check for Malware:** If used with a computer, scan the card for viruses or malware.
- **Verify Device Speed:** Ensure your device's card reader or controller supports the card's speed class. Using a high-speed card in a low-speed reader will limit performance.

Data Loss:

- **Avoid Further Use:** If you suspect data loss, stop using the card immediately to prevent overwriting lost data.
- **Data Recovery Software:** Consider using reputable data recovery software. Note that success is not guaranteed.

6. SPECIFICATIONS

Detailed technical specifications for the Hiseeu Micro 64GB SD Card.

Feature	Detail
Brand	Hiseeu
Model Name	Micro SD
Flash Memory Type	Micro SD
Memory Storage Capacity	64 GB
Read Speed	Up to 90 MB/s
Write Speed	Up to 25 MB/s
Secure Digital Association Speed Class	Class 10
Application Performance Class	A1 (1500 random read IOPS, 500 random write IOPS)
Hardware Interface	Secure Digital Card
Special Features	Water-resistant, Anti-magnetic, Shockproof, High/Low Temperature Resistant
Compatible Devices	Cameras, Security Cameras, Action Cameras, Dash Cameras, Steam Deck, Switch
Item Weight	0.634 ounces (approx. 0.02 Kilograms)
Package Dimensions	5.83 x 3.5 x 0.47 inches

7. WARRANTY INFORMATION

The Hiseeu Micro 64GB SD Card comes with a **Limited Warranty**. For specific terms and conditions, please refer to the warranty documentation included with your purchase or visit the official Hiseeu website. This warranty typically covers manufacturing defects under normal use.

Note: Physical damage, misuse, or unauthorized modifications are generally not covered under warranty.

8. CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Hiseeu customer service.

- **Online Support:** Visit the official Hiseeu website for FAQs, support resources, and contact forms.
- **Email Support:** Refer to your product packaging or the official website for the customer support email address.
- **Phone Support:** Check the official Hiseeu website for available phone support numbers and operating hours.

When contacting support, please have your product model (Micro SD) and purchase details ready.