Redragon K539 Anubis

Redragon K539 Anubis Wireless Mechanical Gaming Keyboard User Manual

Introduction

This manual provides detailed instructions for the Redragon K539 Anubis Wireless Mechanical Gaming Keyboard. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. The K539 Anubis features versatile 3-mode connectivity (USB-C wired, 2.4Ghz wireless, and Bluetooth 3.0/5.0), RGB backlighting, and low-profile brown mechanical switches.

Package Contents

- Redragon K539 Anubis Mechanical Gaming Keyboard
- USB-C to USB-A Cable
- 2.4Ghz Wireless Receiver
- User Manual

Product Overview

The Redragon K539 Anubis is a compact, 87-key (tenkeyless) mechanical keyboard designed for gaming and general use. It features low-profile brown switches for a tactile typing experience and customizable RGB backlighting.



Image: Top-down view of the Redragon K539 Anubis keyboard, showcasing its 87-key layout and vibrant RGB backlighting across all keys.



Image: Angled view of the Redragon K539 Anubis keyboard, highlighting its slim profile and keycap design.

Setup

1. Wired Connection

1. Connect the provided USB-C cable to the keyboard's USB-C port.
2. Connect the USB-A end of the cable to an available USB port on your computer.
3. The keyboard will automatically switch to wired mode and begin charging.



Image: The Redragon K539 Anubis keyboard shown connected to a device via its USB-C cable, illustrating the wired connection method.

2. 2.4Ghz Wireless Connection

1. Locate the 2.4Ghz wireless receiver (USB dongle) in the package.
2. Plug the 2.4Ghz receiver into an available USB port on your computer.
3. On the keyboard, switch the connectivity mode to 2.4Ghz (usually indicated by a switch or Fn key combination). The keyboard should automatically connect.

3. Bluetooth Connection

The K539 Anubis supports up to three Bluetooth devices (BT1, BT2, BT3).

1. On the keyboard, switch the connectivity mode to Bluetooth (e.g., Fn + 1 for BT1, Fn + 2 for BT2, Fn + 3 for BT3).
2. The indicator light for the selected Bluetooth channel will flash rapidly, indicating pairing mode.
3. On your device (computer, tablet, smartphone), enable Bluetooth and search for new devices.
4. Select "Redragon K539" or a similar name from the list of available devices.
5. Once connected, the indicator light on the keyboard will become solid.
6. To switch between paired Bluetooth devices, press Fn + 1, Fn + 2, or Fn + 3.

Operating Instructions

Key Functions (Fn Combinations)

The K539 Anubis utilizes the Fn key for various secondary functions:

- **Fn + F1-F12:** Multimedia controls (e.g., play/pause, volume up/down, mute). Specific functions may vary.
- **Fn + 1/2/3:** Switch between Bluetooth devices (BT1, BT2, BT3).
- **Fn + 4:** Switch to 2.4Ghz wireless mode.

- **Fn + Esc:** Reset keyboard to factory settings (hold for 3 seconds).
- **Fn + Right Shift:** Toggle between English and Arabic layouts (if supported by your operating system).

RGB Lighting Control

The keyboard features customizable RGB backlighting. Use the following combinations to adjust lighting:

- **Fn + PrtSc:** Cycle through various RGB lighting modes.
- **Fn + Scrlk:** Adjust lighting brightness (usually 5 levels).
- **Fn + Pause:** Adjust lighting speed or direction for dynamic modes.
- **Fn + Ins:** Change backlight color in certain modes.

Software Customization

For advanced customization, including key remapping, macro creation, and detailed RGB lighting effects, download the official Redragon software from the Redragon website. Ensure you download the correct software version for the K539 Anubis model.

Maintenance

Cleaning

- Disconnect the keyboard from all power sources before cleaning.
- Use a soft, dry cloth to wipe the surface of the keyboard.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- Use compressed air to remove dust and debris from between the keycaps.

Battery Care (for Wireless Modes)

- Charge the keyboard regularly using the provided USB-C cable.
- Avoid fully discharging the battery frequently to prolong its lifespan.
- If storing the keyboard for an extended period, charge it to approximately 50% before storage.

Troubleshooting

Issue	Possible Solution
Keyboard not responding in wired mode	Ensure the USB-C cable is securely connected to both the keyboard and the computer. Try a different USB port or cable.
2.4Ghz wireless connection unstable or not connecting	Ensure the 2.4Ghz receiver is plugged in and the keyboard is in 2.4Ghz mode. Move the receiver closer to the keyboard. Avoid interference from other wireless devices.
Bluetooth connection issues	Ensure the keyboard is in the correct Bluetooth pairing mode (Fn + 1/2/3). Forget the device on your computer/device and re-pair. Ensure your device's Bluetooth is enabled.
Keys typing incorrectly or double-typing	Clean the affected key switch. Try resetting the keyboard to factory settings (Fn + Esc for 3 seconds). Ensure firmware is up to date via Redragon software.

Issue	Possible Solution
RGB lighting not working or stuck	Ensure the keyboard is powered on. Try cycling through lighting modes (Fn + PrtSc). Reset the keyboard.
Battery drains quickly	Reduce RGB brightness. Ensure the keyboard is turned off or in sleep mode when not in use. Charge fully before use.

Specifications

- **Model:** Redragon K539 Anubis Wireless
- **Connectivity:** USB-C Wired, 2.4Ghz Wireless, Bluetooth 3.0/5.0 (3 devices)
- **Switch Type:** Low Profile Brown Mechanical Switches
- **Layout:** 87-key (Tenkeyless)
- **Backlighting:** RGB
- **Material:** Plastic
- **Operating System Compatibility:** Windows 10 (and generally compatible with other major OS)
- **Item Weight:** Approximately 1 Kilogram

Warranty and Support

Redragon products typically come with a limited warranty. Please refer to the warranty card included with your product or visit the official Redragon website for detailed warranty terms and conditions. For technical support, driver downloads, or further assistance, please visit the Redragon support page or contact their customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question