

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [WAMPAT](#) /

> [WAMPAT Modern TV Stand \(Model W01S1180Q-A2\) User Manual](#)

WAMPAT W01S1180Q-A2

WAMPAT Modern TV Stand User Manual

Model: W01S1180Q-A2

1. INTRODUCTION

Thank you for choosing the WAMPAT Modern TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The WAMPAT Modern TV Stand (Model W01S1180Q-A2) in a typical living room setup.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always secure the TV stand to the wall using appropriate wall anchor hardware to prevent tip-overs, especially when placing a heavy TV on it. Wall anchoring hardware is typically included or can be purchased separately.
- Keep the area around the TV stand clear of items that could pose a hazard if the TV stand were to tip over.
- Do not allow children to climb on or play with the TV stand.
- Ensure the TV stand is placed on a level and stable surface.
- Do not exceed the maximum weight capacity of the TV stand. (Refer to specifications for details).
- Use caution when moving the assembled TV stand to prevent damage or injury.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer support.

The package typically includes:

- Engineered wood panels (top, bottom, side, back, and door panels)
- Metal legs and mounting hardware
- Adjustable shelves
- Door hinges and concealed door handles
- Cable management grommets
- Non-slip foot pads
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly instructions manual

4. ASSEMBLY INSTRUCTIONS

Assembly of the WAMPAT Modern TV Stand is designed to be straightforward. A detailed instruction manual with illustrations is included in your package. Each screw and pin has its own code, and boards are clearly labeled to simplify the process.

4.1 Recommended Tools

- Phillips head screwdriver
- Hammer (for dowels)
- Measuring tape (optional, for placement)

4.2 General Assembly Steps

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Match each part to the corresponding label in the instruction manual.
2. **Assemble the Base:** Attach the metal legs to the bottom panel using the provided hardware. Ensure non-slip foot pads are attached to the bottom of the legs.
3. **Construct the Frame:** Connect the side panels, back panel, and internal dividers to the bottom panel,

then secure the top panel.

4. **Install Shelves:** Insert the adjustable shelves into the desired positions within the cabinets.
5. **Attach Doors:** Mount the door hinges to the cabinet doors and the main frame. Carefully align and attach the doors, ensuring they open and close smoothly. The TV stand features concealed door handles for a clean look.
6. **Cable Management:** Install any provided cable management grommets into the pre-drilled holes at the back of the unit.
7. **Final Check:** Ensure all screws are tightened, and the stand is stable.
8. **Wall Anchoring:** For safety, always secure the TV stand to a wall using appropriate anti-tip hardware.



Image 4.1: Detail of detachable shelves, hidden door handles, and walnut wood grain.



Image 4.2: Protective non-slip foot pad on the metal leg.


5. PRODUCT FEATURES

The WAMPAT Modern TV Stand is designed with functionality and aesthetics in mind:

- **Modern Design:** Features concealed door handles for a neat appearance and a walnut grain finish that complements various decor styles.
- **Powerful Cable Management:** Equipped with cable holes at the back to organize and hide cords and plugs, reducing clutter.
- **Versatile Storage:** Includes multiple storage cabinets with detachable shelves, offering flexible space for media devices, accessories, and other items.
- **Protective Foot Pads:** Non-slip mats are installed on the bottom of the legs to protect your flooring from scratches.
- **Durable Construction:** Made from engineered wood, providing a sturdy and stable platform for your television.



Image 5.1: Cable management holes at the back of the TV stand.



6. OPERATION

Once assembled and securely anchored, your WAMPAT Modern TV Stand is ready for use.

- **Placing Your TV:** Carefully place your television on the top surface of the stand. Ensure the TV's base is fully supported and centered to prevent imbalance. This stand is suitable for TVs up to 75 inches.
- **Organizing Cables:** Utilize the cable management holes at the back of the stand to route power cords and media cables, keeping them tidy and out of sight.
- **Using Storage Cabinets:** Open the cabinet doors to access the internal storage. The detachable shelves can be adjusted to accommodate various items such as media players, gaming consoles, remote controls, or decorative objects.

7. MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your TV stand.

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the engineered wood finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent water damage or staining. The stand features a waterproof surface, but prompt cleaning is still recommended.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.

8. TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Loose connections; uneven floor.	Ensure all screws are tightened. Adjust the non-slip foot pads if your floor is uneven. Verify wall anchoring.
Cabinet doors do not align properly.	Hinges not adjusted correctly; panels misaligned during assembly.	Adjust the screws on the hinges to fine-tune door alignment. Refer to the assembly manual for hinge adjustment details. If severe, re-check panel assembly.
Missing parts or damaged components.	Manufacturing error or shipping damage.	Do not proceed with assembly. Contact WAMPAT customer support immediately for replacement parts.

9. SPECIFICATIONS

Feature	Detail
Model Number	W01S1180Q-A2
Dimensions (L x W x H)	70.9 x 16.3 x 20 inches (1800 x 415 x 510 mm)
Item Weight	78 pounds (35.4 kg)
Material	Engineered Wood
Color	Walnut
TV Size Compatibility	Up to 75 inches
Number of Storage Cabinets	4
Number of Shelves	3 (adjustable)
Special Features	Waterproof surface, Cable Management, Concealed Door Handles, Protective Foot Pads

Display Personality



Image 9.1: Product dimensions overview.

10. WARRANTY AND CUSTOMER SUPPORT

WAMPAT stands behind the quality of its products. For specific warranty details, please refer to the

documentation included with your purchase or visit the official WAMPAT website. If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact WAMPAT customer support.

Contact Information: Please refer to your purchase receipt or the WAMPAT brand store for the most current customer service contact details.