

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HOOBRO](#) /

› [HOOBRO 4-Tier Slim Service Cart EWN15TC01 Instruction Manual](#)

## HOOBRO EWN15TC01

# HOOBRO 4-Tier Slim Service Cart EWN15TC01 Instruction Manual

Model: EWN15TC01

## INTRODUCTION

---

Thank you for choosing the HOOBRO 4-Tier Slim Service Cart. This versatile cart is designed to provide efficient storage in narrow spaces within your kitchen, bathroom, or living room. Its stable structure, lockable wheels, and raised edges ensure both practicality and safety for your items.

This manual provides detailed instructions for assembly, operation, and maintenance to ensure safe and optimal use of your new service cart.



*Image: The HOOBRO 4-Tier Slim Service Cart in a kitchen, showcasing its storage capacity for various items.*

## SAFETY INFORMATION

---

- Always assemble the cart on a clean, flat, and stable surface.
- Ensure all screws and fasteners are securely tightened before use.
- Do not overload the shelves. Each shelf can hold up to 5 kg, and the top can hold up to 7 kg.
- Keep the cart away from sharp objects to prevent damage.
- Avoid exposing the cart to direct sunlight and excessive humidity to prolong its lifespan.
- Always lock the wheels when the cart is stationary to prevent accidental movement.
- Keep small parts out of reach of children during assembly.

## PACKAGE CONTENTS

---

Please check the package carefully to ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

The package includes all necessary parts and assembly tools for the HOOBRO 4-Tier Slim Service Cart.

## ASSEMBLY INSTRUCTIONS

---

Assembly of the HOOBRO Service Cart is designed to be straightforward. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches. Identify each part using the provided numbered labels.
2. **Attach Wheels:** Secure the four lockable wheels to the base of the cart. Ensure they are firmly attached.
3. **Assemble Side Panels:** Connect the side panels to the base using the provided screws and tools.
4. **Install Shelves:** Slide each of the three shelves into the designated slots on the side panels. Ensure the protective bars are facing upwards to prevent items from falling.
5. **Attach Top Panel:** Place the top panel onto the assembled structure and secure it with screws.
6. **Final Check:** Verify that all connections are tight and the cart is stable.

An illustrated guide is included in the package for visual assistance during assembly.

## OPERATING INSTRUCTIONS

---

### Using the Cart

The HOOBRO Service Cart is designed for versatile storage and easy mobility. Utilize its four tiers for organizing various items in different rooms.

- **Kitchen:** Store spice jars, bottles, cooking oils, or small appliances.
- **Bathroom:** Organize toiletries, cleaning supplies, towels, or cosmetics.
- **Living Room:** Keep books, magazines, remote controls, or decorative items within reach.



*Image: The service cart used in a kitchen, demonstrating its storage for food items.*



*Image: The service cart used in a bathroom, demonstrating its storage for toiletries.*

## **Mobility and Stability**

The cart features four lockable wheels and easy-grip handles for effortless movement.

- **Moving the Cart:** To move the cart, unlock the wheels by flipping the lever on each wheel upwards. Use the integrated handles on the top panel to guide the cart.
- **Securing the Cart:** To keep the cart stationary, push the lever on each wheel downwards to engage the lock mechanism.



*Image: Detail of the lockable wheels.*



*Image: Integrated handle for easy movement.*

## MAINTENANCE

---

- **Cleaning:** Wipe the cart with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the surfaces to maintain cleanliness.
- **Environmental Care:** Keep the cart away from direct sunlight and high humidity to prevent material degradation.
- **Fastener Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Cart is unstable or wobbly.	Loose screws or uneven assembly.	Check and tighten all screws. Ensure the cart is on a flat surface.

Problem	Possible Cause	Solution
Wheels do not roll smoothly.	Wheels are locked or obstructed.	Ensure wheel locks are disengaged. Clear any debris from the wheels.
Items fall off shelves.	Overloaded shelves or protective bars not installed correctly.	Reduce weight on shelves. Ensure protective bars are securely in place and facing upwards.
Difficulty during assembly.	Incorrect part orientation or missing tools.	Refer to the illustrated instructions. Ensure parts are oriented correctly. Contact support if parts are missing.

## SPECIFICATIONS

---

**Model:** EWN15TC01

**Dimensions (L x W x H):** 45 x 15 x 80 cm (17.7 x 5.9 x 31.5 inches)

**Number of Shelves:** 4 (3 open shelves + 1 top panel)

**Material:** Iron frame, Engineered wood shelves

**Color:** White + Natural Wood Color


**Weight:** 5.3 kg (11.7 lbs)

**Max. Load Capacity per Shelf:** 5 kg (11 lbs)

**Max. Load Capacity Top Panel:** 7 kg (15.4 lbs)

**Assembly Required:** Yes

**Care Instructions:** Keep away from direct sunlight and humidity.



*Image: Detailed dimensions of the service cart.*

## **WARRANTY AND SUPPORT**

HOOBRO products are manufactured with quality and durability in mind. For any questions regarding your HOOBRO 4-Tier Slim Service Cart, including assembly, missing parts, or operational issues, please

contact HOOBRO customer support.

Please retain your purchase receipt for any warranty claims. Specific warranty terms and conditions may vary by region and retailer.