Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- XINLEI /
- > XINLEI Universal TV Stand Base Instruction Manual

XINLEI TS103

XINLEI Universal TV Stand Base Instruction Manual

Model: TS103

INTRODUCTION

Thank you for choosing the XINLEI Universal TV Stand Base. This table-top TV stand is designed to provide a stable and adjustable mounting solution for your LCD/LED TV or monitor. It features a durable tempered glass base, height adjustment, and tilt functionality for optimal viewing. Please read this manual thoroughly before installation and use to ensure safe and proper operation.



Figure 1: Front view of the XINLEI Universal TV Stand Base.

SAFETY INFORMATION

WARNING: Failure to read and follow these instructions may result in serious personal injury, property damage, or voiding of warranty. If you have any questions, please contact customer support.

- Do not exceed the maximum weight capacity of 88 lbs (40 kg).
- Ensure your TV's VESA pattern is compatible (100x100mm to 200x200mm).

- This stand is designed for 17-43 inch flat LCD/LED/Plasma/curved TVs and monitors.
- Always ensure the stand is placed on a stable, level surface.
- Keep children and pets away from the stand during assembly.
- Do not attempt to modify the product.
- Periodically check all screws and connections to ensure they remain secure.

SPECIFICATIONS

Feature	Detail
Brand	XINLEI
Model	TS103
Compatible TV Sizes	17 to 43 Inches
Weight Capacity	Up to 88 lbs (40 kg)
VESA Compatibility	100x100mm to 200x200mm
Base Material	Tempered Glass
Base Dimensions	10.24" x 15.75"
Height Adjustment	3 levels: 11.1", 13.03", 14.96"
Tilt Angle	-12° to +5°
Color	Black
Item Weight	9.28 lbs (4.21 kg)

SPECIFICATION 200mm 100mm +5° MIN11.1" -MAX14.96" -12° For TV Size: 17-43Inch **Weight Capacity:** 88lbs 10.24 **Net Weight:** 15.75" 9.4lbs Tilt: -12°~+5° Vesa: 100x100~200x200mm

Figure 2: Detailed specifications and dimensions of the TV stand.

PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not attempt to assemble. Contact customer support for assistance.



Figure 3: Exploded view of the TV stand components, showing the base, column, and VESA plate.

The package includes the main stand components and various hardware (screws, washers, spacers) to accommodate different TV models. A detailed hardware list is typically provided in the included paper manual.

SETUP (INSTALLATION)

Follow these steps for proper assembly and installation of your XINLEI Universal TV Stand Base.

1. Attach the Column to the Tempered Glass Base:

Carefully align the metal column with the designated holes on the tempered glass base. Secure it using the provided screws and tools. Ensure the non-slip foam feet are attached to the bottom of the glass base for stability.



Figure 4: Close-up of the heavy-duty tempered glass base with non-slip rubber feet for enhanced stability.

2. Attach the VESA Plate to the TV:

Identify the VESA mounting holes on the back of your TV. Select the appropriate screws, washers, and spacers from the hardware kit that fit your TV's VESA pattern. Attach the VESA mounting plate to the back of your TV. Ensure the screws are tightened securely but do not overtighten.

IMPORTANT!

Ensure Mount Won't Block Ports



Figure 5: Important consideration: Ensure the VESA mount does not obstruct any ports on your TV.

3. Mount the TV to the Stand:

Carefully lift the TV with the attached VESA plate and hook it onto the column of the stand. Ensure the VESA plate is securely seated on the stand's mounting brackets. Secure the TV to the stand using the safety screws or locking mechanisms provided.

4. Adjust Height:

The stand offers 3 levels of height adjustment. Before mounting the TV, you can pre-select the desired height by adjusting the position of the VESA plate on the column. The available heights are 11.1", 13.03", and 14.96" from the base.



Figure 6: Illustration of the three adjustable height levels for the TV stand.

5. Cable Management:

Utilize the integrated cable management system behind the column to route and conceal your TV and device cables. This helps maintain a clean and organized appearance.



Figure 7: The stand's column features a cable management channel to keep wires tidy and out of sight.

OPERATING (USAGE)

Once assembled, the XINLEI Universal TV Stand Base allows for flexible viewing adjustments.

• **Tilt Adjustment:** The TV mount can be tilted from -12° to +5° to achieve the optimal viewing angle and reduce glare. Loosen the tilt adjustment knobs on the VESA plate, adjust to the desired angle, and then securely tighten the knobs.




Figure 8: The TV stand allows for tilt adjustment to achieve an ideal viewing experience.

• Placement Flexibility: Unlike wall mounts, this tabletop stand allows you to easily reposition your TV within a room, offering greater flexibility in room layout and viewing arrangements.

MAINTENANCE

To ensure the longevity and continued safe operation of your TV stand, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to clean the tempered glass base and metal components. Avoid abrasive cleaners or solvents that could damage the finish.
- Screw Check: Periodically (e.g., every 3-6 months) check all screws and connections to ensure they are tight and secure. Loose connections can compromise stability.
- Weight Limit: Do not place items on the stand that exceed its stated weight capacity.

TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common problems and solutions:

• Problem: The TV does not fit the VESA plate.

Solution: Verify your TV's VESA pattern (distance between mounting holes) matches the stand's compatibility (100x100mm to 200x200mm). Ensure you are using the correct set of screws and spacers for your TV model.

• Problem: The stand feels unstable.

Solution: Ensure all screws are securely tightened. Check that the stand is placed on a flat, level, and sturdy surface. Confirm your TV's weight does not exceed the stand's maximum capacity of 88 lbs.



Figure 9: The heavy-duty tempered glass base and non-slip feet contribute to the stand's durability and stability.

• Problem: Cables are messy.


Solution: Utilize the cable management clips or channel located on the back of the stand's column to neatly route and hide cables.

WARRANTY AND SUPPORT

For detailed warranty information or further assistance, please refer to the official product documentation included with your purchase or visit the XINLEI brand store on Amazon. You can also contact XINLEI customer support directly for any inquiries or technical support.

A PDF installation manual is available for download: Installation Manual (PDF)

Related Documents - TS103



ML5073 Mobile TV Cart Installation Guide

Comprehensive installation instructions for the ML5073 mobile TV cart, featuring height adjustment, a shelf, and support for 21-60 inch screens up to 77 lbs with VESA patterns up to 400x400mm.




Xinlei Mobile TV Cart: Important Installation and Stability Update

Important notification from Xinlei regarding common installation issues with their mobile TV carts, addressing stability concerns and detailing product improvements for future versions.



Xinlei MA570 TV Wall Mount Installation Manual

Comprehensive installation guide for the Xinlei MA570 TV wall mount, detailing steps for concrete and wood wall mounting, attaching the TV, and cable management.



ML5073 Mobile TV Cart Installation Guide

Comprehensive installation instructions for the ML5073 mobile TV cart, featuring height adjustment, a shelf, and support for 21-60 inch screens up to 77 lbs with VESA patterns up to 400x400mm.




Xinlei Mobile TV Cart: Important Installation and Stability Update

Important notification from Xinlei regarding common installation issues with their mobile TV carts, addressing stability concerns and detailing product improvements for future versions.



Xinlei MA570 TV Wall Mount Installation Manual

Comprehensive installation guide for the Xinlei MA570 TV wall mount, detailing steps for concrete and wood wall mounting, attaching the TV, and cable management.



[pdf] User Manual Installation Guide Instructions Accessories

TS103 Installation Manual XINLEI Universal TV Stand Base Table Top for 17 43 Inch LCD LED TVs Height Adjustable Monitor Mount with Tempered Glass Holds up to 88lbs VESA 200x200mm Electronics A1A8WvZPYYL m media amazon images I |||

Screw Bag **TS103** Rubber Feet-A M* Bolt-B M* Bolt-C M* Bolt-D M* Bolt-E M* Bolt-F ** Spacer-G ** Spacer-H ** Washer-I ** Washer-J M* Bolt-K Screw Bag Pay Attention Warning If improperly assembled, may result in serious injury, death or property destruction. Please rea...

lang:en score:25 filesize: 1.12 M page_count: 2 document date: 2023-03-14