

## XINLEI TS102

# XINLEI Universal TV Stand Base TS102 Instruction Manual

Model: TS102

## 1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Do not exceed the maximum weight capacity of 88 lbs (40 kg).
- Ensure your TV's VESA pattern is compatible (100x100mm to 400x400mm).
- Verify that all screws are securely tightened before placing the TV on the stand.
- Do not allow children to climb on or play with the TV stand.
- Place the stand on a stable, level surface to prevent tipping.
- Avoid placing heavy objects on the stand's base that could compromise stability.

## 2. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.




Image: Exploded view of the TV stand components.

- Tempered Glass Base
- Support Column
- TV Mounting Plate
- VESA Extension Brackets (if applicable for larger VESA patterns)
- Various Screws, Washers, and Spacers for TV attachment
- Assembly Hardware (bolts, nuts, Allen wrench)
- Non-slip Rubber Feet

### 3. SETUP AND ASSEMBLY

---

Follow these steps to assemble your XINLEI Universal TV Stand Base.

1. **Attach Non-Slip Feet to Base:** Secure the non-slip rubber feet to the underside of the tempered glass base.



Image: Detail of the tempered glass base with non-slip feet.

2. **Assemble Support Column:** Attach the support column to the tempered glass base using the provided hardware. Ensure it is firmly secured.
3. **Attach TV Mounting Plate:** Secure the TV mounting plate to the top of the support column.

#### 4. Prepare TV for Mounting:

- Identify your TV's VESA mounting holes on the back.
- Select the appropriate screws and spacers from the provided hardware kit that fit your TV's VESA pattern.
- Attach the VESA extension brackets to the TV mounting plate if your TV's VESA pattern requires them (e.g., 400x400mm).
- **Important:** Before attaching the TV to the stand, ensure that the mounting plate and screws will not block any ports or cables on the back of your television.



Image: Illustration emphasizing checking for port obstruction.

5. **Mount the TV:** Carefully lift your TV and align its VESA holes with the mounting plate/brackets. Secure the TV using the selected screws and spacers. Ensure the TV is level and stable.



Image: Fully assembled TV stand with a television.

## 4. OPERATING INSTRUCTIONS

The XINLEI Universal TV Stand Base offers height adjustment and tilt functionality for optimal viewing.

### 4.1 Height Adjustment

This stand provides 3 adjustable height levels. To adjust the height:

1. Carefully remove the TV from the mounting plate.
2. Adjust the mounting plate's position on the support column to one of the three available height settings (11.1", 13.03", or 14.96" from the base).
3. Secure the mounting plate at the desired height using the provided fasteners.
4. Re-mount the TV onto the adjusted plate.

### 3 HEIGHT ADJUSTABLE




Image: Visual representation of the three height settings.

#### 4.2 Tilt Adjustment

The TV mounting plate allows for a tilt range of -12 to +5 degrees.

- Loosen the tilt adjustment screws on the side of the mounting plate.
- Gently tilt the TV to your preferred viewing angle.
- Tighten the tilt adjustment screws to secure the TV in position.




Image: Diagram demonstrating the tilt functionality.

### 4.3 Cable Management

Utilize the integrated cable management system within the support column to keep cables organized and out of sight.



# CABLE MANAGEMENT



Image: Example of cable management through the stand's column.

## 5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your TV stand.

- **Cleaning:** Wipe the tempered glass base and metal components with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Stability:** Ensure the stand remains on a level surface and that the non-slip feet are intact.

## 6. TROUBLESHOOTING

If you encounter issues during assembly or use, refer to the following common solutions.

- **TV Not Level:** Ensure the stand is on a flat surface. Check that the TV mounting plate is securely attached and that the VESA screws are tightened evenly.
- **Screws Too Long/Short:** The kit includes various screw lengths and spacers. Refer to your TV's manual for recommended screw sizes for VESA mounting. Use the appropriate spacers to ensure a

secure fit without over-tightening or damaging the TV.



- **Mount Blocks Ports:** Before final mounting, always verify that the mounting plate does not obstruct any necessary ports on your TV. If it does, adjust the TV's position on the VESA plate or consider using longer spacers if safe and compatible.
- **Stand Feels Unstable:** Confirm that all assembly bolts are fully tightened. Ensure the tempered glass base is placed on a solid, flat surface and that the non-slip feet are properly installed.

## 7. SPECIFICATIONS

Feature	Specification
Model	TS102
Compatible TV Sizes	17 to 55 inches
Weight Capacity	88 lbs (40 kg)
VESA Compatibility	100x100mm to 400x400mm
Height Adjustment	3 levels (11.1", 13.03", 14.96")
Tilt Angle	-12° to +5°
Base Dimensions	10.24" x 15.75"
Material	Tempered Glass, Steel
Color	Black
Item Weight	9.86 pounds



# SPECIFICATION



**For TV Size:**  
17-55Inch



**Weight Capacity:**  
88lbs



**Net Weight:**  
10lbs



**Tilt:**  
-12°~+5°



**Vesa:**  
100x100~400x400mm

Image: Technical specifications and dimensions.


## 8. WARRANTY AND SUPPORT

XINLEI products are designed for durability and performance. For warranty information or technical support, please refer to the product packaging or contact XINLEI customer service directly.

Please have your model number (TS102) and purchase information ready when contacting support.

### Related Documents - TS102





[pdf] User Manual Installation Guide Instructions Accessories

TS102 Installation Manual XINLEI Universal TV Stand Base Table Top for 17 55 Inch LCD LED

TVs Height Adjustable Monitor Mount with Tempered Glass Holds up to 88lbs VESA 400x400mm

Electronics A1twNUdRgcL m media amazon images I |||

TS Screw Bag Rubber Feet-A M\* Bolt-B M\* Bolt-C M\* Bolt-D M\* Bolt-E M\* Bolt-F \*\*  
Spacer-G \*\* Spacer-H \*\* Washer-I \*\* Washer-J M\* Bolt-K Screw Bag Elliptic Lock-e  
Elliptic Pad-f S Allen Key-i Plastic Wiring-g Pay Attention Warning If improperly  
assembled, ma...

lang:en score:16 filesize: 1.74 M page\_count: 2 document date: 2023-03-14