

Vactidy T6

Vactidy T6 Robot Vacuum User Manual

Model: T6

1. INTRODUCTION

The Vactidy T6 Robot Vacuum is designed to provide efficient and convenient cleaning for your home. With powerful suction, a slim design, and multiple cleaning modes, it simplifies daily floor care. This manual will guide you through the proper use and maintenance of your device.



Figure 1.1: Vactidy T6 Robot Vacuum and included accessories.

2. WHAT'S IN THE BOX

Upon unboxing your Vactidy T6 Robot Vacuum, please ensure all components are present:

- Vactidy T6 Vacuum Robot (1 unit)
- Charging Base (1 unit)
- Power Adapter (1 unit)
- Remote Control (1 unit, 2 AAA batteries included)
- HEPA Filter (2 units)
- Side Brushes (4 units)
- Cleaning Tool (1 unit)
- User Manual (1 unit)

About Vactidy

Founded in 2013, Vactidy is a home appliance brand dedicated to providing easy-to-use, cost-effective, and durable cleaning equipment, saving your time from housekeeping chores and enjoying life.

Whether you have a baby exploring the world by making a mess or have a cute furry member in your home, cleaning should be easy and frequent.

Enjoy life without much burden. We'll get your back.

Figure 2.1: Contents of the Vactidy T6 package.

3. SETUP

3.1 Charging Base Placement

Place the charging base against a wall in an open, uncluttered area. Ensure there are no obstacles within 3 feet (1 meter) to the front and 1.5 feet (0.5 meters) to the sides of the charging base to allow the robot to easily dock.

3.2 Initial Charging

Before first use, fully charge the robot vacuum. Place the robot onto the charging base, ensuring the charging contacts align. The robot will automatically return to the charging dock when its battery is low (below 15%) or when cleaning is complete.



A Quiet Clean

Figure 3.1: Automatic return to charging base.

3.3 App and Voice Control Setup

The Vactidy T6 supports control via the Vactidy App, Alexa, Siri, and Google Assistant. The robot only supports 2.4GHz WiFi networks.

1. Download the "Vactidy" App from your app store.
2. Add your T6 robot vacuum to the App.
3. Ensure the T6 is on and charging in the charging dock.
4. Press and hold the start button for 5 seconds.
5. Connect to the 2.4GHz WiFi network named "SL-Vactidy-XXXX".

6. Wait for the robot to pair successfully.
7. For Alexa, add the "Vactidy" skill in the Alexa App.



Figure 3.2: App connection guide.

3.4 Cleaning Precautions

To ensure optimal performance and prevent damage, prepare your cleaning area:

- Remove objects such as clothes, loose paper, rope, power lines, and all fragile items before using the robot vacuum cleaner.
- If the robot moves along and pulls out of a power line, the line may move objects from a table or shelf.
- If the room to be cleaned has a balcony, use a barrier to prevent the robot from entering the balcony to ensure safety.

4. OPERATING

4.1 Suction Power

The Vactidy T6 offers up to 2000Pa strong suction in max mode, effectively picking up dust, debris, and pet hair from hard floors and low-pile carpets. It features 3 levels of suction power to adapt to various cleaning needs.



2000Pa Powerful Suction

Figure 4.1: Powerful 2000Pa suction.

4.2 Slim Body Design

With a compact height of only 2.89 inches and a 360-degree universal wheel, the Vactidy T6 can effectively clean hard-to-reach areas such as under beds, sofas, and cabinets.



Nimble Slim Body

Figure 4.2: Nimble slim body for hard-to-reach areas.

4.3 3-Point Thorough Cleaning System

The RoboVac is equipped with 2 spinning auto side sweeper brushes that extend its reach and rotate to gather dirt and debris. Unlike brushless suction ports, the roller brush provides deep cleaning for fine dust on all floor types. A cleaning brush is included to help manage entangled hair.



Auto-Return Charging

Figure 4.3: Roller brush for powerful pick-up.

4.4 Multiple Control Methods

Control your Vactidy T6 using various methods:

- **Vactidy App:** Set schedules, choose cleaning modes, and monitor your robot.
- **Voice Control:** Use Alexa, Siri, or Google Assistant for hands-free operation.
- **Remote Control:** A traditional remote is included for convenient control, especially useful for users who prefer not to use apps or voice commands.



Powerful Pick Up With Roller Brush

Figure 4.4: Smart App and Voice Control options.

4.5 Diverse Cleaning Modes

The robotic vacuum cleaner offers three primary cleaning modes:

- **Auto Cleaning:** The robot intelligently navigates to clean the entire area.
- **Spot Cleaning:** Focuses on a specific dirty area, cleaning in a spiral pattern.
- **Edge Cleaning:** Cleans along walls and furniture edges.

You can freely switch between these modes and power levels via the Vactidy App. You can also preset a working time for daily routine cleaning.



Versatile Cleaning Modes

Figure 4.5: Various cleaning modes.

4.6 Safe and Non-stop Cleaning

Sensitive anti-collision and drop-sensing sensors prevent the robot vacuum from hitting furniture or falling down stairs, making it suitable for various home environments. The Vactidy Nimble T6 can also climb inclines of up to 15 degrees, allowing it to transition smoothly from hardwood to carpet for continuous cleaning.

4.7 Quiet Operation

Operating at a low noise level of 60dB in quiet mode, the Vactidy T6 ensures your cleaning routine does not disturb your activities or rest.

works with
Google Assistant



works with
Amazon Alexa



works with
Siri



works with
Vactidy APP



2.4GHZ



More functions



Schedule settings



Consumables record



Cleaning records



Positioning device



Remote

Smart APP & Voice Control

Figure 4.6: Quiet cleaning experience.

5. MAINTENANCE

Regular maintenance is crucial for the optimal performance and longevity of your Vactidy T6 Robot Vacuum.

5.1 Dust Bin Emptying

The 500ML dust bin should be emptied regularly, ideally after each cleaning cycle, especially if you have pets or a large area to clean. To empty, simply remove the dust bin from the robot and discard collected debris.

5.2 HEPA Filter Maintenance

The HEPA filters should be cleaned periodically to maintain suction efficiency. Tap the filter to remove loose dirt, or use the included cleaning tool. Replace filters as needed (Replacement Accessories ASIN: B0BNDKN4NF).

5.3 Side Brushes and Roller Brush Cleaning

Inspect and clean the side brushes and the main roller brush regularly to remove tangled hair and debris. The included cleaning tool can assist with this. Ensure brushes are free of obstructions for effective cleaning.



Figure 5.1: Top and bottom view for maintenance access.

6. TROUBLESHOOTING

If you encounter issues with your Vactidy T6, please refer to the following common solutions:

- **Robot not charging:** Ensure the charging base is plugged in and the robot's charging contacts are clean and properly aligned with the base.
- **Reduced suction:** Check and empty the dust bin. Clean or replace the HEPA filter. Clear any blockages from the main brush and side brushes.
- **Robot getting stuck frequently:** Clear obstacles from the cleaning path. Ensure cords and small items are picked up. Check cliff sensors for dirt or obstructions.
- **App connectivity issues:** Verify your WiFi is 2.4GHz. Restart your router and the robot. Re-attempt the app pairing process as described in Section 3.3.
- **Unusual noises:** Inspect brushes and wheels for tangled hair or debris. Ensure all components are correctly installed.

For persistent issues, please contact customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	Vactidy

Model Name	T6
Special Feature	Bagless
Color	Black
Product Dimensions	13" L x 16" W x 5" H
Filter Type	Cartridge
Battery Life	100 minutes
Dust Bin Capacity	500 Milliliters
Power Source	Battery Powered
Compatible Devices	Amazon Echo
Item Weight	5.4 pounds
Manufacturer	Vactidy
Date First Available	March 14, 2023

8. WARRANTY & SUPPORT

The Vactidy T6 Robot Vacuum comes with a 12-month worry-free warranty. For professional customer service and support, please refer to the contact information provided in your product packaging or visit the official Vactidy website.

Replacement accessories can be found by searching ASIN: B0BNDKN4NF on Amazon.