AOOGITF S5-6+6

AOOGITF S5-6+6 Cat Water Fountain User Manual

Model: S5-6+6

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your AOOGITF S5-6+6 Cat Water Fountain. Please read these instructions carefully before use to ensure proper function and longevity of the product. This water fountain is designed to provide fresh, filtered water for your pet.




Image: Assembled AOOGITF S5-6+6 Cat Water Fountain, showing its compact design and water basin.

Setup Instructions

Follow these steps to set up your cat water fountain:

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components, including the fountain base, water basin, pump, filter tray, filter, and sponge, are present.
2. **Prepare the Filter:**
   - Soak the new filter in clean water for 3-5 minutes. This helps remove any loose carbon dust and ensures proper water flow.
   - Rinse the filter thoroughly under running water for 30 seconds.
3. **Assemble the Pump:** Attach the sponge to the pump intake. Ensure it is securely fitted.
4. **Place the Pump:** Position the assembled pump at the bottom of the water basin in the designated area.
5. **Install the Filter:** Place the prepared filter into the filter tray, then position the filter tray over the pump. Ensure it sits correctly.
6. **Fill with Water:** Fill the water basin with clean water up to the maximum fill line. Do not overfill.

7. **Connect Power:** Connect the power adapter to the fountain and then plug it into a suitable electrical outlet. The fountain should begin operating.



Image: Visual guide demonstrating the steps for filter preparation (soaking and rinsing) and installation of the replacement filter and sponge.

Operating Instructions

Once set up, the AOOGITF S5-6+6 Cat Water Fountain operates continuously to provide fresh water.

- **Continuous Operation:** The fountain will run as long as it is plugged in and has sufficient water.
- **Water Level Monitoring:** Regularly check the water level. Ensure the water level is always above the pump to prevent it from running dry, which can damage the pump. Refill as needed.
- **Power On/Off:** To turn the fountain off, simply unplug it from the power outlet. To turn it back on, plug it in again.

Maintenance

Regular maintenance is crucial for the longevity of your fountain and the health of your pet.

Filter Replacement

The filter is designed to clean a significant volume of water, typically over 50 liters, but replacement frequency depends on usage and water quality. It is recommended to replace the filter every 2-4 weeks, or more frequently if you have multiple pets or notice reduced water flow or impurities.

1. Unplug the fountain.
2. Remove the top tray and the old filter.
3. Prepare a new filter by soaking and rinsing it as described in the "Setup Instructions".
4. Place the new filter into the filter tray and reassemble the fountain.



Image: Illustration indicating the filter's capacity to clean over 50 liters of water before replacement is typically needed.

Cleaning the Fountain

Clean the entire fountain, including the pump, at least once a week. This prevents mineral buildup and bacterial growth.

- Unplug the fountain and disassemble all components.
- Wash the basin, trays, and other plastic parts with mild soap and water. The components are designed for easy hand cleaning and some parts may be dishwasher safe (refer to product specifications for details).

- Clean the pump:
  - Remove the pump cover and impeller.
  - Use a small brush (e.g., a toothbrush) to clean any debris or mineral buildup from the impeller and inside the pump housing.
- Rinse all components thoroughly to remove any soap residue.
- Reassemble the fountain.

Filter System Details

The AOOGITF S5-6+6 water fountain utilizes a multi-stage filtration system to ensure water purity:

- **Sponge Filter:** Captures hair and debris, protecting the pump.
- **Non-woven Fabric Layer:** Provides initial filtration of larger particles.
- **Activated Carbon:** Made from coconut shells, it absorbs odors, chlorine, and other organic impurities.
- **Ion Exchange Resin:** Softens water by reducing heavy metal ions like magnesium (Mg) and calcium (Ca).
- **Food-grade Plastic:** All components are made from safe, food-grade materials.

High Quality Cotton Fiber





Image: Exploded view of the filter components, detailing the high-quality sponge and the multi-layer filter cartridge with activated carbon, non-woven fabric, and ion exchange resin.



Image: Visual representation of the deep filtration process, showing water passing through the various layers of the filter for thorough cleaning.

Activated Carbon with Strong Adsorption Capacity






Image: Close-up view of the key filter materials: activated carbon, white cotton mesh (non-woven fabric), and ion exchange resin, highlighting their roles in purification.




Image: Illustration demonstrating how the fountain's filtration system absorbs various impurities, including magnesium (Mg) and calcium (Ca) ions, from the water.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Fountain not dispensing water or weak flow.	• Low water level. • Pump or filter is clogged with debris (hair, food particles). • Pump is not properly assembled or connected.	• Refill water to the appropriate level. • Clean the pump and replace the filter as per maintenance instructions. • Ensure all pump components are correctly assembled and the power cord is securely plugged in.
Fountain is making unusual noise.	• Low water level, causing the pump to run dry. • Debris in the pump impeller. • Pump not seated correctly.	• Add water immediately. • Clean the pump impeller thoroughly. • Ensure the pump is securely placed in its designated spot in the basin.
Water appears dirty or has an odor.	• Filter needs replacement. • Fountain needs cleaning.	• Replace the filter. • Perform a thorough cleaning of all fountain components and the pump.

Specifications

Model Number	S5-6+6
Brand	AOOGITF
Dimensions (L x W x H)	19 x 16 x 11 cm
Weight	130 grams
Color	Black
Material	Food-grade plastic
Filter Type	Multi-layer (Activated Carbon, Ion Exchange Resin, Non-woven Fabric)
Power Source	Electric (requires power adapter)
Batteries Required	No
Age of Animal	All life stages

Warranty and Support

For warranty information or technical support, please contact the manufacturer directly. Refer to your purchase documentation for specific warranty terms and contact details.

© 2026 AOOGITF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question