

[Manuals.plus](#) /

> [NUTRIFROST](#) /

> NUTRIFROST Side-by-Side Refrigerator with Ice Maker User Manual

NUTRIFROST FF2-69IMFS

NUTRIFROST Side-by-Side Refrigerator with Ice Maker User Manual

Model: FF2-69IMFS

1. PRODUCT OVERVIEW

The NUTRIFROST Side-by-Side Refrigerator with Ice Maker (Model FF2-69IMFS) offers a spacious 18.1 cubic feet capacity, featuring a no-frost design and a freestanding configuration. It is equipped with an integrated ice maker and water dispenser, electronic temperature controls, and adjustable shelving for versatile storage.





Figure 1: Front view of the NUTRIFROST Side-by-Side Refrigerator.



Figure 2: Dimensions of the NUTRIFROST Refrigerator: 69.7 inches height, 35.5 inches width, 26 inches depth.

2. SETUP AND INSTALLATION

2.1 Unpacking

Carefully remove all packaging materials, tape, and any temporary labels from the refrigerator. Ensure all accessories and internal components are accounted for. Dispose of packaging materials responsibly.

2.2 Placement

Place the refrigerator on a flat, stable surface away from direct sunlight and heat sources. Allow adequate clearance around the unit for proper ventilation. The dimensions are approximately 26 inches (D) x 35.5 inches (W) x 69.7 inches (H).

2.3 Leveling

Adjust the leveling feet at the bottom of the refrigerator to ensure the unit is stable and level. This helps in proper door alignment and efficient operation.

2.4 Electrical Connection

Connect the refrigerator to a dedicated 110 Volt AC power outlet. Ensure the electrical supply meets the requirements specified on the product's rating label.

2.5 Water Line Connection (for Ice Maker & Water Dispenser)

For the ice maker and water dispenser to function, connect the refrigerator to a potable water supply. Refer to the detailed instructions in the full User Guide (PDF) for proper water line installation to prevent leaks and ensure optimal performance.

3. OPERATING INSTRUCTIONS

3.1 Temperature Control

The refrigerator features an electronic control panel on the exterior for easy temperature adjustments for both the freezer and refrigerator sections. The freezer section can be set between -8°F and 7°F, while the refrigerator section maintains temperatures between 35°F and 47°F. Use the touch controls to cycle through temperature settings.



Figure 3: Close-up of the external control panel for temperature and dispenser settings.

3.2 Ice Maker and Water Dispenser

The built-in ice maker and water dispenser provide convenient access to filtered water, cubic ice, and crushed ice. Select your desired option using the touch panel. A child lock feature is available to prevent unsupervised use.

QUALITY DESIGN DETAILS

For Care-free Use & Easy Maintenance



Figure 4: The integrated water and ice dispenser for easy access.

Your browser does not support the video tag.

Video 1: Demonstration of temperature control and ice/water dispensing features of the Side-by-Side Refrigerator with Ice Makers.

3.3 Interior Storage and Organization

The 18.1 cubic feet capacity is divided into a 12.1 cubic feet fresh food capacity and a 6 cubic feet freezer capacity. The interior features adjustable glass shelves and four crispers/drawers, allowing for flexible storage arrangements to accommodate various food items, including tall bottles and wide jugs.



Figure 5: Interior view of the refrigerator showing organized food items and adjustable shelving.



Figure 6: Detailed view of the crisper drawers, ideal for storing fruits and vegetables.

3.4 No Frost Technology

This refrigerator incorporates a two-way airflow system, ensuring even and balanced air circulation throughout both compartments. This advanced "Frost Free" technology prevents ice buildup, eliminating the need for manual defrosting and maintaining consistent temperatures for optimal food preservation.

4. MAINTENANCE

4.1 Cleaning

Regular cleaning of your refrigerator is essential for hygiene and longevity. Wipe down interior surfaces with a mild detergent and warm water. Removable glass shelves and drawers can be taken out for thorough cleaning. Clean the exterior with a soft cloth and a non-abrasive cleaner suitable for stainless steel. Avoid harsh chemicals or abrasive

materials.

4.2 Water Filter Replacement

The refrigerator is equipped with a water filter to ensure clean, fresh water and ice. The filter should be replaced periodically, typically every 6 months, depending on water quality and usage. Refer to the full User Guide for specific instructions on locating and replacing the water filter.

4.3 Automatic Defrost

This unit features an automatic defrost system, which means manual defrosting is not required. The system periodically melts away any frost buildup, ensuring efficient operation and preventing ice accumulation.

5. TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and their potential solutions:

Problem	Possible Cause	Solution
Refrigerator not cooling	Power supply issue, temperature setting too high, door not closed properly.	Check power connection. Adjust temperature settings. Ensure doors are fully closed and sealed.
Ice maker not producing ice or water dispenser not working	Water line disconnected, water filter clogged, ice maker switch off.	Verify water line connection. Replace water filter. Ensure ice maker switch is on. Check for child lock activation.
Unusual noise	Refrigerator not level, items vibrating inside, normal operating sounds.	Level the refrigerator. Rearrange items inside. Note that some sounds (e.g., refrigerant flow, defrost cycle) are normal.
Unit overheating or tripping breaker	Poor ventilation, overloaded circuit.	Ensure adequate clearance around the unit. Connect to a dedicated circuit. If issues persist, contact a qualified technician.

6. SPECIFICATIONS

- **Brand:** NUTRIFROST
- **Model:** FF2-69IMFS
- **Capacity:** 18.1 Cubic Feet Total (12.1 Fresh Food, 6 Freezer)
- **Dimensions (D x W x H):** 26 x 35.5 x 69.7 inches
- **Item Weight:** 216 pounds
- **Noise Level:** 40 dB
- **Installation Type:** Freestanding
- **Defrost System:** Automatic
- **Number of Doors:** 2

- **Voltage:** 110 Volts
- **Shelf Type:** Glass
- **Crispers/Drawers:** 4
- **Special Features:** Adjustable Electrical Thermostat, Removable Glass shelves, LED Lighting, Frost Free, Low Noise
- **Color:** Grey
- **Certification:** CSA

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Specific warranty details for your NUTRIFROST refrigerator are typically provided with the product at the time of purchase or can be obtained directly from the manufacturer. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, parts, or service, please contact NUTRIFROST customer support. You may also refer to the official User Guide (PDF) and Safety Information (PDF) documents for comprehensive details:

- [User Guide \(PDF\)](#)
- [Safety Information \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BYDJYPJH>

More documents and user manuals: <https://manuals.plus/>