



Manuals.plus /

› EasyAcc /

› EasyAcc Keyboard Case User Manual for Samsung Galaxy Tab S7 FE/S8+/S7+ Plus

EasyAcc SM-T730, SM-T736B, SM-X800, SM-X806

EasyAcc Bluetooth Keyboard Case User Manual

Model: SM-T730, SM-T736B, SM-X800, SM-X806

1. INTRODUCTION

Thank you for choosing the EasyAcc Bluetooth Keyboard Case. This product is designed to enhance your tablet experience by providing a protective case and a versatile wireless keyboard. This manual will guide you through the setup, operation, and maintenance of your new keyboard case.



Image: The EasyAcc Keyboard Case with a Samsung Galaxy Tab S7 FE tablet, illustrating the product's design and functionality.

2. COMPATIBILITY

This EasyAcc Bluetooth Keyboard Case is specifically designed to be compatible with the following Samsung Galaxy Tab models:

- Samsung Galaxy Tab S7 FE 12.4 (2021) - Models: SM-T730, SM-T736B
- Samsung Galaxy Tab S8+ Plus 5G 12.4 (2022) - Models: SM-X800, SM-X806
- Samsung Galaxy Tab S7+ Plus 12.4 (2020)

Compatibility

for Samsung Galaxy Tab S8+ 12.4 " (2022)/
Tab S7 FE 12.4 " (2021)/Tab S7+ 12.4 " (2020)



Tab S8+ 12.4 "
2022

(SM-X800, SM-X806)



Tab S7FE 12.4 "
2021

(SM - T730 / T736B)



Tab S7+ 12.4 "
2020

(SM - T970/ T976B)



Tab S8 11 "
2022

(SM-X700, SM-X706)



Image: A visual guide to compatible Samsung Galaxy Tab models, ensuring correct fit.

3. KEY FEATURES

- **Detachable Magnetic Keyboard:** The wireless Bluetooth keyboard can be easily attached or detached from the case, allowing you to switch between a lightweight laptop and a tablet experience.



Magnetische abnehmbare Tastatur

Image: The magnetic detachable keyboard offers flexible usage.

- **360-Degree Protection:** The case provides comprehensive protection for your tablet against scratches, bumps, and drops, thanks to its elegant design, high-quality PU leather, and soft TPU shell.

360° Rundumschutz

Hochwertiges PU-Leder



Weiche TPU-Hülle

Weiche TPU-Hülle

Image: The case's construction provides all-around protection.

- **Adjustable Viewing Angles:** The case features a built-in stand that allows for multiple adjustable viewing angles, optimizing your comfort for typing, viewing, or drawing.

Einstellbarer Blickwinkel des Standfußes



Image: Multiple viewing angles for enhanced usability.

- **Long Battery Life:** Equipped with a high-efficiency integrated battery, the keyboard offers an estimated 100 hours of continuous working time on a single charge (4-5 hours charging time).
- **10-Meter Bluetooth Range:** Connects wirelessly to your Samsung Galaxy Tab and other Android devices with Bluetooth functionality, offering a stable connection up to 10 meters.
- **Slim and Lightweight Design:** The keyboard and case are designed to be super slim and lightweight, making them easy to carry anywhere.

DIESE SUPERSCHLANKE LEICHTE TASTATUR FINDET ÜBERALL PLATZ




Image: The slim and lightweight design ensures portability.

4. SETUP INSTRUCTIONS

4.1. Charging the Keyboard

Before first use, fully charge the keyboard. Use the included USB cable to connect the keyboard to a power source (e.g., computer USB port, USB wall adapter).

- Charging time: Approximately 4-5 hours.
- The charging indicator light will typically turn off or change color when fully charged.



Image: Connect the USB cable to the charging port for power.

4.2. Bluetooth Pairing

1. Ensure the keyboard is charged and turned on. The power switch is usually located on the side or top edge of the keyboard.
2. On your Samsung Galaxy Tab, go to **Settings > Connected devices > Bluetooth** and turn Bluetooth ON.
3. On the keyboard, press the **Connect** button (often labeled with a Bluetooth icon or 'Pair'). The Bluetooth indicator light on the keyboard will start blinking, indicating it's in pairing mode.
4. On your tablet, look for "EasyAcc Keyboard" or a similar name in the list of available Bluetooth devices and tap on it to connect.
5. Once connected, the Bluetooth indicator light on the keyboard will stop blinking and remain solid or turn off, indicating a successful connection.

5. OPERATING INSTRUCTIONS

5.1. Keyboard Layout (QWERTZ)

Your EasyAcc keyboard features a QWERTZ layout, commonly used in German-speaking regions. Familiarize yourself with the key positions, especially for special characters and symbols.



DEUTSCHE QWERTZ-TASTATUR

Image: The QWERTZ keyboard layout for efficient typing.

5.2. Switching Operating Modes

The keyboard supports different operating systems. To optimize key functions for your device, switch to the appropriate mode:


- **Android Mode:** The keyboard is set to Android mode by default. For Android users, it should work immediately upon connection.
- **iOS Mode:** Press **Fn + Q** to switch to iOS mode. The Bluetooth indicator will flash three times.
- **Windows Mode:** Press **Fn + W** to switch to Windows mode. The Bluetooth indicator will flash three times.

Den richtigen Arbeitsmodus auswählen


Android-Benutzer:


Die Tastatur befindet sich standardmäßig im Android-Modus. Kunden mit Android-Geräten können es sofort verwenden, sobald die Verbindung hergestellt ist.

iOS-Benutzer:

Schließen Sie Ihr iPad an die Tastatur an und drücken Sie **Fn** + **Q** , um in den iOS-Modus zu wechseln. Die Bluetooth-Anzeige oben rechts blinkt dreimal schnell hintereinander.

Windows-Benutzer:

Schließen Sie Ihr Gerät an die Tastatur an und drücken Sie **Fn** + **W** , um in den Windows-Modus zu wechseln. Die Bluetooth-Anzeige oben rechts blinkt dreimal schnell hintereinander.



Spezielles Symbol

@ = **Alt** + **Q** 

€ = **Alt** + **E** 

Image: Instructions for switching keyboard operating modes.

5.3. Special Function Keys

The top row of keys often includes function keys (F1-F12) that can be used for media control, volume adjustment, and other shortcuts when pressed in combination with the **Fn** key. Refer to the keyboard's printed legends for specific functions.

6. MAINTENANCE

To ensure the longevity and optimal performance of your EasyAcc Keyboard Case, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the keyboard and case. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the keyboard case in a cool, dry place. Ensure the keyboard is turned off to conserve battery life.
- **Avoid Liquids:** Keep the keyboard and case away from liquids to prevent damage to electronic components.
- **Handle with Care:** While the case offers protection, avoid dropping or subjecting the product to strong impacts.

7. TROUBLESHOOTING

If you encounter issues with your EasyAcc Keyboard Case, try the following solutions:

Problem	Solution
Keyboard not connecting via Bluetooth.	<p>Ensure the keyboard is charged and turned on.</p> <p>Make sure Bluetooth is enabled on your tablet.</p> <p>Press the 'Connect' button on the keyboard to enter pairing mode.</p> <p>Forget the device on your tablet's Bluetooth settings and try pairing again.</p> <p>Restart both the keyboard and your tablet.</p>
Keys are not responding or typing incorrectly.	<p>Check if the keyboard is fully charged.</p> <p>Ensure the keyboard is in the correct operating mode (Android, iOS, Windows) for your tablet.</p> <p>Reconnect the Bluetooth connection.</p> <p>Clean any debris from around the keys.</p>
Short battery life.	<p>Ensure the keyboard is fully charged before use.</p> <p>Avoid leaving the keyboard on when not in use.</p> <p>Battery performance may degrade over time with prolonged use.</p>

8. SPECIFICATIONS

Feature	Detail
Brand	EasyAcc
Connectivity Technology	Bluetooth
Keyboard Description	Wireless, Detachable
Power Source	Battery Powered
Battery Life (Continuous Working)	Approx. 100 hours
Charging Time	Approx. 4-5 hours
Bluetooth Range	Up to 10 meters (33 feet)
Material	Acrylonitrile Butadiene Styrene (ABS), PU Leather, TPU
Included Components	USB Cable
Compatible Devices	Samsung Galaxy Tab S7 FE 12.4, S8+ Plus 12.4, S7+ Plus 12.4

9. WARRANTY AND SUPPORT

EasyAcc products are manufactured to high quality standards. For specific warranty information and support, please refer to the warranty card included with your product or visit the official EasyAcc website. If you encounter any issues not covered in this manual, please contact EasyAcc customer service for assistance.

