

[Manuals.plus](#) /

› [Scentsationals](#) /

› Scentsationals Honeycomb Capiz Wax Melt Warmer User Manual

Scentsationals Honeycomb Capiz Warmer

Scentsationals Honeycomb Capiz Wax Melt Warmer User Manual

Model: Honeycomb Capiz Warmer

INTRODUCTION

This user manual provides comprehensive instructions for the safe and effective use of your Scentsationals Honeycomb Capiz Wax Melt Warmer. This modern warmer is designed to fill your home with fragrance using scented wax melts, offering a flameless alternative to traditional candles. Please read this manual thoroughly before initial use and retain it for future reference.



Image: Scentsationals Honeycomb Capiz Wax Melt Warmer

IMPORTANT SAFETY INFORMATION

WARNING: Please read all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or injury.

- Do not touch hot surfaces. The warmer and melted wax will become hot during operation.
- Unplug the warmer when not in use, before cleaning, or before changing the bulb.
- Keep out of reach of children and pets.
- Place the warmer on a stable, level, heat-resistant, and non-flammable surface.
- Do not place the warmer near flammable materials, curtains, or drapes.
- Do not add water to the wax dish.
- Do not move the warmer while in operation or while wax is melted.
- Use only Scentsationals wax melts or similar approved fragrance cubes.
- Ensure the electrical cord is not pinched or damaged.
- This product is for indoor use only.

PACKAGE CONTENTS

Verify that all items are present and undamaged:

- Scentsationals Honeycomb Capiz Wax Melt Warmer Base
- Wax Dish
- 25W Light Bulb (for heat source)

Note: Scented wax cubes are sold separately.

SETUP INSTRUCTIONS

1. Unpack all components from the packaging and ensure they are intact.
2. Place the warmer base on a flat, stable, and heat-resistant surface, away from any flammable objects.
3. Carefully screw the included 25W light bulb into the bulb holder located inside the warmer base. Ensure it is securely tightened.
4. Place the wax dish securely on top of the warmer base.
5. Ensure the on/off switch located on the power cord is in the 'off' position.
6. Plug the 5-foot power cord into a standard electrical outlet.

Scentsationals®

SCENTED WAX WARMER

YOUR CHOICE FOR HOME FRAGRANCE




Image: Diagram of Wax Warmer Components

OPERATING INSTRUCTIONS

1. Place one or more Scentsationals scented wax cubes into the wax dish. Do not overfill the dish.
2. Flip the on/off switch on the power cord to the 'on' position. The light bulb will illuminate, and the warmer will begin to heat the wax.
3. The wax will melt, releasing fragrance into the room. The fast-heating plate quickly melts wax to release maximum aroma in minutes.
4. To turn off the warmer, flip the on/off switch to the 'off' position. The light will turn off, and the wax will begin to solidify.
5. Allow the warmer and wax to cool completely before handling or moving the unit.



Image: Wax melting in dish



Image: Operating the On/Off Switch

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your warmer.

- Always unplug the warmer and allow it to cool completely before cleaning.
- **To remove melted wax:** Place cotton balls in the melted wax to soak it up, then wipe the dish clean with a soft cloth. Alternatively, allow the wax to cool and solidify completely. Once solid, slightly warm the wax for a few minutes until it loosens from the dish, then gently push the solidified wax out in one piece.
- Wipe the exterior of the warmer with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- Do not immerse the warmer base in water or any other liquid.
- Replace the light bulb only with a 25W bulb specifically designed for wax warmers. Using an incorrect bulb may damage the unit or pose a safety risk.




Image: Cleaning melted wax with cotton balls

TROUBLESHOOTING

Problem	Possible Cause / Solution
Warmer not turning on	Ensure the warmer is securely plugged into a working electrical outlet. Check that the on/off switch is in the 'on' position. Verify the light bulb is properly screwed in and not burnt out; replace if necessary.
No fragrance or weak fragrance	Ensure wax cubes are placed in the dish. Fragrance intensity can vary based on the type and age of the wax, as well as room size and ventilation. Try adding more wax cubes or using a different scent. Ensure the warmer has been on long enough for the wax to fully melt.

Problem	Possible Cause / Solution
Light is too bright	The warmer is designed to provide ambient light as part of its function. The brightness is a characteristic of the product. Consider placing it in an area where the light level is suitable for your preference, or use it as a decorative nightlight.

SPECIFICATIONS

Feature	Detail
Brand	Scentsationals
Model Name	Honeycomb Capiz Warmer
Power Source	Corded Electric
Material	Glass, Metal
Wattage	25 watts
Item Weight	1.63 pounds
Package Dimensions	9.29 x 6.73 x 6.69 inches
UPC	843283147464
ASIN	B0BYF83MKD

WARRANTY AND SUPPORT

For product support, warranty information, or to inquire about replacement parts, please contact Scentsationals customer service. Refer to the product packaging or the official Scentsationals website for the most current contact details.

It is recommended to keep your purchase receipt as proof of purchase for any warranty claims.

You can visit the [Scentsationals Store on Amazon](#) for more products and information.