

SPIT 054555

Spit P18 Cordless Drywall Screwdriver

Model: 054555

INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Spit P18 Cordless Drywall Screwdriver. Please read this manual thoroughly before using the tool to ensure proper handling and to prevent injury or damage.

The Spit P18 is an 18V cordless drywall screwdriver designed for efficient fastening of plasterboard screws to both wooden frames and metal studs. It features a high torque output and an ergonomic soft-grip handle for enhanced user comfort and control.

SAFETY INSTRUCTIONS

WARNING: Read all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- Always wear eye protection and hearing protection when operating the tool.
- Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- Use the correct tool for your application. Do not force the tool.
- Disconnect the battery pack from the tool before making any adjustments, changing accessories, or storing power tools.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.
- Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the power tool's operation.
- Use the power tool, accessories, and tool bits etc., in accordance with these instructions, taking into account the working conditions and the work to be performed.

COMPONENTS AND PACKAGE CONTENTS

Your Spit P18 Cordless Drywall Screwdriver package typically includes the following items:

- Spit P18 Cordless Drywall Screwdriver (tool body)
- Carrying Case
- *Note: Battery and charger are typically sold separately.*



Image 1: The Spit P18 Cordless Drywall Screwdriver tool body, shown without a battery attached. This image highlights the ergonomic design and the front chuck for bit insertion.

SETUP

1. Battery Installation

Ensure the battery is fully charged before use. The Spit P18 operates on an 18V battery (not included).

1. Align the battery pack with the receptacle on the bottom of the tool handle.
2. Slide the battery pack into the tool until it clicks securely into place.
3. To remove, press the battery release button(s) and slide the battery out.



Image 2: Side view of the Spit P18 Cordless Drywall Screwdriver with an 18V battery pack securely attached. This demonstrates the tool's compact form factor with the power source.

2. Bit Installation

The tool uses standard screwdriver bits suitable for drywall screws.

1. Ensure the tool is switched off and the battery is removed.
2. Insert the desired screwdriver bit into the chuck at the front of the tool.
3. Push the bit firmly until it locks into place.
4. To remove, pull the chuck collar forward and pull the bit out.



Image 3: Front view of the Spit P18 Cordless Drywall Screwdriver with an 18V battery pack attached. This angle highlights the bit holder and the overall balance of the tool.

OPERATING INSTRUCTIONS

General Operation

1. **Power On/Off:** Press the trigger switch to start the tool. Release the trigger to stop.
2. **Direction of Rotation:** Use the forward/reverse selector switch, usually located above the trigger, to select the desired rotation direction (clockwise for fastening, counter-clockwise for loosening).
3. **Depth Adjustment:** The P18 features an adjustable nose cone for precise depth setting of screws. Rotate the nose cone to adjust the screw depth. Test on a scrap piece of material first.
4. **Fastening Drywall Screws:**
 - Place the screw on the bit.
 - Position the screw tip on the drywall and apply firm, steady pressure to the tool.

- Press the trigger. The tool will drive the screw until the preset depth is reached, then the clutch will disengage.
- Release the trigger and lift the tool from the screw head.

MAINTENANCE

- **Cleaning:** Regularly clean the ventilation openings of the tool with a soft brush or compressed air. Do not use water or chemical cleaners.
- **Bit Holder:** Keep the bit holder clean and free of debris to ensure proper bit seating.
- **Battery Care:** Store batteries in a cool, dry place. Do not store fully discharged batteries for extended periods.
- **Storage:** When not in use, store the tool in its carrying case in a dry, secure location out of reach of children.
- **Inspection:** Periodically inspect the tool for any signs of damage, loose screws, or worn parts. If damage is found, have it repaired by a qualified service technician.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Tool does not start.	Battery not inserted correctly or discharged.	Ensure battery is fully seated. Charge battery.
Screw not driving to correct depth.	Depth adjustment incorrect.	Adjust the nose cone for desired depth. Test on scrap material.
Bit slips in chuck.	Bit not fully inserted or chuck is dirty.	Ensure bit is pushed in until it locks. Clean chuck.
Tool overheats.	Continuous heavy use or blocked ventilation.	Allow tool to cool down. Clear ventilation openings. Reduce load.

SPECIFICATIONS

Feature	Detail
Model Number	054555
Voltage	18 Volts
Power Source	Battery-Powered
Maximum Screw Diameter (metal rail)	4.2 mm
Dimensions (L x W x H)	22.3 x 18.2 x 8.4 cm (approx. 16.2 x 45.2 x 37.6 cm for package)
Weight (according to EPTA)	1.546 kg (tool only) / 3.6 kg (package weight)
Material	Plastic, Metal
Color	Orange
Special Features	Lightweight, Soft-grip handle

WARRANTY AND SUPPORT

For warranty information, service, or technical support, please refer to the documentation provided with your purchase or contact SPIT customer service directly. Keep your proof of purchase for warranty claims.

No official product videos were found for this item. For visual guidance, please refer to the images provided in this manual or consult the manufacturer's website.

© 2023 SPIT. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question