

Teka 111040009

Teka HSB 756 G SS Built-in Electric Oven User Manual

Model: 111040009

1. INTRODUCTION AND SAFETY INFORMATION

This manual provides essential instructions for the safe installation, operation, and maintenance of your Teka HSB 756 G SS Built-in Electric Oven. Please read it thoroughly before using the appliance and keep it for future reference.

1.1 General Safety Warnings

- Ensure the oven is correctly installed by a qualified technician before use.
- Do not allow children to operate the oven unsupervised.
- The oven becomes hot during operation. Avoid touching hot surfaces. Use oven mitts.
- Never use water to extinguish oil or grease fires. Smother the flames with a lid or fire blanket.
- Do not store flammable materials in or near the oven.
- Disconnect the appliance from the power supply before cleaning or maintenance.
- This appliance is for domestic use only.

2. PRODUCT OVERVIEW

The Teka HSB 756 G SS is a 60 cm built-in electric oven designed for modern kitchens. It features a stainless steel finish with an anti-fingerprint coating, multiple cooking functions, and a generous capacity.

2.1 Key Features

- **External Dimensions:** 595 mm (Height) x 595 mm (Width) x 543 mm (Depth)
- **Internal Capacity:** 65 liters (net) / 71 liters (gross)
- **Cooking Methods:** 5 cooking methods, including Grill and Bottom heat functions.
- **Temperature Range:** Adjustable from 150°C to 240°C.
- **Control Type:** Rotary knobs for function and temperature selection.
- **Timer:** Integrated timer for precise cooking control.
- **Interior:** Crystal Clean enamel for easy cleaning.
- **Safety:** Child safety lock.
- **Illumination:** Interior lighting for clear visibility.
- **Cooling:** Tangential ventilation system.
- **Accessories:** Standard grill rack and deep tray with Crystal Clean enamel.

2.2 Product Components



Figure 1: Front view of the Teka HSB 756 G SS Built-in Electric Oven. Shows the stainless steel control panel with three rotary knobs and the large glass oven door with the Teka logo.




Figure 2: Close-up of the control panel. From left to right, the knobs control cooking functions, timer, and temperature.

The panel is brushed stainless steel.



Figure 3: Interior view of the oven with the door open. Shows multiple rack positions, a standard grill rack, and a deep tray. The rear wall features a fan for tangential ventilation.

3. INSTALLATION (SETUP)

The Teka HSB 756 G SS is a built-in appliance and requires professional installation. Incorrect installation can lead to hazards and void the warranty. Always consult a qualified technician.

3.1 Pre-Installation Checks

- Verify that the electrical supply matches the oven's requirements (127V~, 60 Hz, 1470 W max).
- Ensure the cabinet opening dimensions are appropriate for the oven's external dimensions (595x595x543 mm).
- The cabinet material must be heat-resistant.

3.2 Installation Steps (Summary)

1. Carefully remove the oven from its packaging.
2. Slide the oven into the prepared cabinet opening.
3. Secure the oven to the cabinet using the provided screws.
4. Connect the oven to the electrical supply, ensuring proper grounding.
5. Perform a test run to ensure all functions operate correctly.

For detailed installation diagrams and specific requirements, refer to the separate installation guide provided with the appliance or consult the Teka website.

4. OPERATING INSTRUCTIONS

Familiarize yourself with the control panel before operating the oven.

4.1 Control Panel Overview

The oven features three rotary knobs on the control panel:

- **Left Knob:** Selects cooking functions (e.g., conventional heat, grill, bottom heat).
- **Middle Knob:** Sets the timer for cooking duration.
- **Right Knob:** Adjusts the oven temperature from 150°C to 240°C.

4.2 First Use

Before first use, clean the oven interior with a damp cloth. Then, heat the empty oven at maximum temperature for approximately 30 minutes to burn off any manufacturing residues. Ensure adequate ventilation during this process.

4.3 Setting a Cooking Program

1. Turn the **Left Knob** to select the desired cooking function (e.g., Grill, Bottom Heat, or a combination).
2. Turn the **Right Knob** to set the desired cooking temperature.
3. (Optional) Turn the **Middle Knob** to set the cooking duration. The oven will switch off automatically once the set time expires.
4. The oven's interior light will illuminate when a function is selected.

4.4 Child Safety Lock

The oven is equipped with a child safety lock. Refer to the full instruction manual for specific activation and deactivation procedures for this feature.

5. CLEANING AND MAINTENANCE

Regular cleaning and maintenance ensure the longevity and optimal performance of your oven.

5.1 General Cleaning

- Always ensure the oven is cool and disconnected from the power supply before cleaning.
- Clean the exterior stainless steel surfaces with a soft cloth and a mild, non-abrasive cleaner. The anti-fingerprint coating helps reduce smudges.
- Wipe the glass door with a soft cloth and glass cleaner.

5.2 Interior Cleaning (Crystal Clean Enamel)

The oven interior is coated with Crystal Clean enamel, designed for easy cleaning.

- After each use, wipe down the interior with a damp cloth and mild detergent once the oven has cooled.
- For stubborn stains, use a specialized oven cleaner suitable for enamel surfaces. Follow the product instructions carefully.
- Avoid using abrasive pads, harsh chemicals, or steam cleaners, as these can damage the enamel.

5.3 Accessories

The grill rack and deep tray can be removed and washed by hand with warm soapy water or in a dishwasher.

6. TROUBLESHOOTING

Before contacting customer service, please consult the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Oven does not heat up.	No power supply; incorrect function/temperature setting; timer not set or expired.	Check power connection and circuit breaker. Ensure function and temperature knobs are correctly set. Check if the timer has expired.
Uneven cooking.	Food placed incorrectly; oven not preheated; dirty interior.	Ensure food is centered and not overcrowding the oven. Always preheat the oven. Clean the interior regularly.
Oven light not working.	Bulb needs replacement.	Ensure oven is cool and unplugged. Replace the oven bulb with a suitable high-temperature bulb.

If the problem persists after attempting these solutions, please contact Teka customer support.

7. TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Teka
Model Number	111040009
External Dimensions (H x W x D)	595 mm x 595 mm x 543 mm
Internal Dimensions (H x W x D)	342 mm x 475 mm x 402 mm
Net Capacity	65 Liters
Gross Capacity	71 Liters
Minimum Temperature	150°C
Maximum Temperature	240°C
Maximum Nominal Power	1470 W
Voltage	127V~
Frequency	60 Hz
Energy Class	A+
Fuel Type	Electric
Finish Type	Polished Stainless Steel (Anti-fingerprint)
Weight	35 kg

8. WARRANTY AND CUSTOMER SUPPORT





For warranty information, please refer to the warranty card included with your appliance or visit the official Teka website. Keep your proof of purchase for any warranty claims.

For technical assistance, spare parts, or service requests, please contact Teka customer support through their

official channels. You can find contact details on the Teka website or in your product documentation.
Teka Official Website: www.teka.com

© 2024 Teka. All rights reserved. Information in this manual is subject to change without notice.

Related Documents

	<p>Teka NEO Series Ovens: Design and Technology</p> <p>Discover the Teka NEO Series ovens, featuring innovative design, advanced technology, and user-friendly features like Push-Pull controls, BrightClean enamel, and AirFry function for a superior cooking experience.</p>
	<p>Teka HLF 940 90cm 9 Function Oven with Hydroclean® - Product Overview</p> <p>Detailed information on the Teka HLF 940, a 90cm 9-function oven featuring Hydroclean® technology, SurroundTemp, full extension telescopic guides, and a Maestro lifestyle design. Includes technical specifications, energy consumption, and safety features.</p>
	<p>Teka Ovens Catalog 2020: Features, Models, and Specifications</p> <p>Explore the 2020 catalog of Teka ovens, featuring innovative technologies like SteakMaster, iOven, SurroundTemp, and advanced cleaning systems. Find detailed specifications and model information for a wide range of Teka ovens.</p>
	<p>Teka MW FS20 WH Microwave Oven User Manual</p> <p>Comprehensive user manual for the Teka MW FS20 WH microwave oven, detailing safety instructions, operation, cleaning, installation, and troubleshooting. Includes multilingual support.</p>



[\[pdf\]](#) Catalog

Catalogo Teka MX 2024 teka es mx sites 11 05 |||

Donde se cocina la vida Electrodomesticos, fregaderos y grifera Catlogo 2024 Grupo

Teka Miles de so ... Profundo 565mm MAESTRO HLB 760 G SS Cdigo: 111030000

EAN: 8434778000122 TOTAL HSB 756 G SS Cdigo: **111040009** EAN:

8434778024012 TOTAL HSB 750 G SS RX Cdigo: 111040004 EAN: 8434778000047

Multifunci...

lang:es score:16 filesize: 12.83 M page_count: 45 document date: 2024-04-01



[\[pdf\]](#)

Horno SteakMaster TekaTOTAL HSB 750 G SS RX Multifunción con convección Acero inoxidable

antihuella 5 funciones de cocinado Minutero mecánico 120 minutos Grill Hornos 1teka es mx sites 11

2018 07 Hornos 1 |||

NOVEDAD MUNDIAL Horno SteakMaster BIENVENIDOS AMANTES DE LA CARNE

El primer y nico horno para preparar ... Profundo 565mm MAESTRO HLB 760 G SS

Cdigo: 111030000 EAN: 8434778000122 TOTAL HSB 756 G SS Cdigo: **111040009**

EAN: 8434778024012 TOTAL HSB 750 G SS RX Cdigo: 111040004 EAN:

8434778000047 Multifunci...

lang:es score:14 filesize: 1.6 M page_count: 4 document date: 2024-05-08



[\[pdf\]](#) Catalog

Catálogos de productos — hidrosanCatalogo TEKA septiembre 2024cdn shopify s files 1 0651 5579 3139

Catalogo 2024 v 1733857962 cocina la vidaCatálogos 2024Catalogo 2024teka es mx sites 11 10 ||| |||

Donde se cocina la vida Electrodomesticos, fregaderos y grifera Catlogo septiembre 2024 Grupo Teka

Miles de soluciones. Millones de momentos. Grupo Teka pertenece al grupo empresarial Heritage B,

siendo el lder en soluciones para cocina y ba

Donde se cocina la vida Electrodomesticos, fregaderos y grifera Catlogo septiembre

2024 Grupo Teka ... Profundo 565mm MAESTRO HLB 760 G SS Cdigo: 111030000

EAN: 8434778000122 TOTAL HSB 756 G SS Cdigo: **111040009** EAN:

8434778024012 TOTAL HSB 750 G SS RX Cdigo: 111040004 EAN: 8434778000047

Multifunci...

lang:es score:14 filesize: 16.86 M page_count: 45 document date: 2024-09-09