

[Manuals.plus](#) /

› [Pagani Design](#) /

› Pagani Design PD1753 Automatic Mechanical Dive Watch Instruction Manual

Pagani Design PD1753

Pagani Design PD1753 Automatic Mechanical Dive Watch

Instruction Manual

INTRODUCTION

This manual provides essential information for the proper use and care of your Pagani Design PD1753 Automatic Mechanical Dive Watch. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.



Image: The Pagani Design PD1753 watch featuring a green dial and stainless steel bracelet.

SETUP

Initial Winding

Your Pagani Design PD1753 watch is equipped with an automatic mechanical movement (Japanese TMI NH35). It does not require batteries. For initial use or after the watch has stopped, it needs to be manually wound.

1. Unscrew the crown by turning it counter-clockwise until it springs free.
2. Turn the crown clockwise approximately 30-40 times. This will provide sufficient power reserve to start the watch.
3. Push the crown back in and screw it down clockwise to ensure water resistance.

The watch will continue to wind automatically with the motion of your wrist while worn. If worn for less than 10 hours a day, manual winding may be necessary to maintain power.

Setting Time and Date



Image: Diagram illustrating the crown positions for setting the date and time.

1. Unscrew the crown by turning it counter-clockwise.
2. **To set the date:** Pull the crown out to the first click position (Level 1). Turn the crown clockwise or counter-clockwise until the correct date is displayed. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
3. **To set the time:** Pull the crown out to the second click position (Level 2). Turn the crown to move the hands clockwise until the correct time is displayed. Ensure the AM/PM is correctly set by observing if the date changes when passing midnight.
4. Once time and date are set, push the crown back in and screw it down clockwise firmly against the case to maintain water resistance.

OPERATING THE WATCH

Automatic Movement

The watch is powered by an automatic mechanical movement. It harnesses the natural motion of your wrist to wind the mainspring. When fully wound, it has a power reserve that allows it to run for a certain period (typically 36-40 hours) when not worn. Regular wear ensures continuous operation.



PAGANI DESIGN

ISPIRAZIONE PER IL DESIGN

*Come un classico degli orologi d'affari
deve superare la prova del tempo.*

"Semplice e generoso

Lusso leggero con sostanza".

Aggiungono gusto e fascino al polso.



Image: View of the automatic mechanical movement through the transparent case back.

Water Resistance (100 Meters / 10 ATM)

This watch is water-resistant up to 100 meters (10 ATM), making it suitable for daily use, showering, swimming, and snorkeling. It is not recommended for scuba diving or high-impact water sports.

- Always ensure the crown is fully screwed down before any contact with water.
- Do not operate the crown or pushers (if present) while the watch is wet or submerged.
- Avoid exposing the watch to hot water or steam (e.g., hot showers, saunas, hot tubs), as this can compromise the seals.



Image: The watch partially submerged in water, illustrating its water resistance.

Luminous Display

The watch features luminous hands and hour markers, allowing for time readability in low-light conditions. The luminescence charges when exposed to light.



Image: The watch dial displaying its luminous hands and markers in a dark environment.

MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For the stainless steel bracelet and case, a slightly damp cloth can be used, followed by drying. Avoid harsh chemicals or abrasive materials.
- **Temperature:** Avoid exposing the watch to extreme temperatures (above 60°C / 140°F or below 0°C / 32°F) or sudden temperature changes.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones), as these can affect the accuracy of the mechanical movement.
- **Impact:** While durable, avoid dropping the watch or subjecting it to severe impacts.
- **Water Resistance Check:** It is recommended to have the water resistance checked periodically (e.g., every 2-3 years) by a qualified watchmaker, especially if the watch is frequently exposed to water.

TROUBLESHOOTING

- **Watch has stopped or is running slow:**

This is common for automatic watches if not worn regularly. Manually wind the watch by unscrewing the crown and turning it clockwise 30-40 times. Ensure you wear the watch for at least 8-10 hours daily for consistent power.
- **Date changes at noon instead of midnight:**

This indicates the watch's internal AM/PM setting is incorrect. Pull the crown out to the time-setting position (Level 2) and advance the time by 12 hours. Then, reset the correct time.
- **Condensation under the crystal:**

If you notice condensation, this may indicate a breach in water resistance. Immediately take the watch to a qualified watchmaker for inspection and repair to prevent damage to the movement.
- **Crown does not screw down:**

Ensure the crown is pushed fully into the case before attempting to screw it down. Turn it gently clockwise. If it still doesn't screw down, do not force it, and seek professional assistance.

SPECIFICATIONS

Model Number	PD1753
Movement	Japanese TMI NH35 Automatic Mechanical
Case Material	Stainless Steel
Band Material	Stainless Steel
Crystal	Sapphire Glass
Water Resistance	100 Meters (10 ATM)
Case Diameter	40 mm
Case Thickness	12 mm
Band Width	20 mm
Band Length	220 mm
Clasp Type	Three-fold safety buckle with push-button release
Special Features	Luminous hands and markers, Date display

Watch Weight	Approximately 148 grams
Country of Origin	China



Image: Detailed dimensions of the Pagani Design PD1753 watch.

WARRANTY

Your Pagani Design PD1753 watch comes with a one-year limited warranty from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear. Please retain your proof of purchase for warranty claims.

SUPPORT

For any questions regarding the use, maintenance, or troubleshooting of your Pagani Design watch, please contact our customer support directly. Refer to the contact information provided with your purchase or visit the official Pagani Design website for assistance.

You can also visit the [Pagani Design Store on Amazon](#) for more product information.

© 2024 Pagani Design. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question