

[Manuals.plus](#) /

› [MHW-3BOMBER](#) /

› MHW-3BOMBER Espresso Coffee Distributor 58.35mm User Manual

## MHW-3BOMBER T6095L4

# MHW-3BOMBER Espresso Coffee Distributor 58.35mm

## USER MANUAL



Model: T6095L4

## 1. Introduction

Thank you for choosing the MHW-3BOMBER Espresso Coffee Distributor. This tool is designed to evenly distribute coffee grounds in your portafilter, promoting consistent extraction and improving the quality of your espresso shots. Please read this manual carefully before use to ensure optimal performance and longevity of your distributor.



*The MHW-3BOMBER Espresso Coffee Distributor, featuring a wooden lid and textured sides.*

## 2. Product Overview & Components

---

The MHW-3BOMBER Espresso Coffee Distributor is crafted from durable materials for reliable performance. It features an adjustable design to suit various dose sizes and preferences.

- **Base:** 58.35mm solid 304 stainless steel, designed for 58mm portafilters.
- **Adjust Ring:** Aluminum alloy for height adjustment.
- **Handle:** Features a natural walnut wood cover and classic anti-slip strip texture for comfortable grip.



Detailed view of the distributor's components: natural wood cover, anti-slip texture, aluminum alloy adjust ring, and SUS 304 stainless steel base.

### 3. Compatibility

This espresso distributor is designed to fit 58mm portafilters. Compatible models include, but are not limited to:

- Breville 9 Series (BES920XL, BES980BSS, BES990BSS)
- Rancilio Silvia
- Gaggia models (BABY, CAREZZA, CLASSIC, RI9380/46 Classic Pro)
- Gevi
- Other 58mm espresso machines

### 4. Setup & Adjustment

Before first use, ensure the distributor is clean. The height of the distribution tool is adjustable to accommodate different

coffee doses and basket depths.

1. **Adjusting Height:** To adjust the height, hold the base firmly and loosen the middle aluminum alloy ring by turning it counterclockwise.
2. **Setting Depth:** Turn the top part of the distributor clockwise or counterclockwise to raise or lower the distribution blades. This sets the desired depth for your coffee grounds.
3. **Securing Adjustment:** Once the desired height is achieved, tighten the middle ring by turning it clockwise until it is secure. This locks the adjustment in place.



*Illustrates the counterclockwise and clockwise adjustment for setting the distributor's depth.*

## 5. Operating Instructions

Follow these steps for effective coffee distribution:

1. **Grind Coffee:** Grind your fresh coffee beans directly into your 58mm portafilter basket. Ensure the coffee grounds

are evenly filled.

2. **Place Distributor:** Place the MHW-3BOMBER Espresso Coffee Distributor on top of the portafilter basket, ensuring it sits flat on the rim.
3. **Distribute Grounds:** Gently rotate the distributor clockwise a few times. The blades will evenly spread the coffee grounds, removing clumps and creating a flat, uniform surface. The non-slip design provides a secure grip during this process.
4. **Remove Distributor:** Lift the distributor straight up from the portafilter. You should observe a smooth, level bed of coffee grounds.
5. **Tamp:** Proceed with tamping your coffee grounds as usual. The even distribution will help reduce channeling and improve extraction consistency.



*Demonstration of using the distributor to level coffee grounds in a portafilter.*

**Watch the Distributor in Action:**

Your browser does not support the video tag.

## 6. Maintenance & Care

---

To maintain your MHW-3BOMBER Espresso Coffee Distributor in excellent condition:

- **Cleaning:** After each use, wipe the stainless steel base and wooden handle with a soft, damp cloth to remove any coffee residue.
- **Drying:** Ensure all parts are thoroughly dry before storage to prevent water spots or damage to the wood.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these can damage the finish and materials.
- **Storage:** Store the distributor in a dry place, away from direct sunlight or extreme temperatures.

## 7. Troubleshooting

---

If you encounter any issues with your distributor, consider the following:

- **Uneven Distribution:** Ensure the distributor's height is correctly adjusted for your specific coffee dose and portafilter basket depth. The distributor should sit evenly on the portafilter rim.
- **Coffee Grounds Sticking:** Make sure the base is clean and dry. A small amount of static electricity can sometimes cause grounds to stick; try gently tapping the portafilter before distribution.
- **Difficulty Rotating:** Check for any obstructions or excessive coffee grounds preventing smooth rotation. Ensure the height adjustment ring is not overtightened, which could impede movement.

## 8. Specifications

---

Feature	Detail
Model Number	T6095L4
Base Diameter	58.35mm
Material	304 Stainless Steel (Base), Aluminum Alloy (Adjust Ring), Walnut Wood (Cover)
Item Weight	1.07 pounds
Package Dimensions	3.07 x 2.91 x 2.44 inches

## 9. Warranty & Support

---

MHW-3BOMBER products are designed for quality and durability. For any questions, concerns, or support needs regarding your espresso coffee distributor, please contact MHW-3BOMBER customer service. Refer to your purchase documentation for specific warranty details.