

[Manuals.plus](#) /

> [WYBOT](#) /

> WYBOT Robotic Pool Cleaner Grampus 1300 User Manual

WYBOT Grampus 1300

WYBOT Robotic Pool Cleaner Grampus 1300 User Manual

Model: Grampus 1300

[Components](#) [Setup](#) [Operation](#) [Introduction](#) [Safety Information](#) [Product](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the WYBOT Robotic Pool Cleaner Grampus 1300. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new pool cleaner. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image 1.1: The WYBOT Robotic Pool Cleaner in a pool environment, illustrating its purpose.

2. SAFETY INFORMATION

Always observe the following safety precautions to reduce the risk of injury, electric shock, or damage to the product.

- Read all instructions before operating the appliance.
- Do not operate the cleaner if the power cord is damaged.
- Ensure the power source matches the specifications listed on the cleaner's label.

- Keep children and pets away from the pool area while the cleaner is operating.
- Never enter the pool while the cleaner is in operation.
- Disconnect the power supply before performing any maintenance or cleaning.
- Only use accessories and replacement parts recommended by WYBOT.
- Store the cleaner in a dry environment when not in use.

3. PRODUCT COMPONENTS

The WYBOT Grampus 1300 Robotic Pool Cleaner consists of the following main components:



Image 3.1: Overview of the WYBOT Grampus 1300 Robotic Pool Cleaner.

- **Main Unit:** The body of the robotic cleaner housing the motor, pump, and control system.
- **Filter Baskets:** Removable baskets for collecting debris.
- **Power Supply Unit:** Connects the cleaner to an AC power source.
- **Floating Cable:** Connects the main unit to the power supply.
- **Scrubbing Wheels/Brushes:** For cleaning pool surfaces.
- **Remote Control:** For manual navigation and mode selection.

4. SETUP

4.1 Unpacking

1. Carefully remove all components from the packaging.
2. Verify that all included components are present (refer to the "Product Components" section).
3. Remove any protective films or packaging materials from the cleaner.

4.2 Initial Placement

1. Place the power supply unit at least 3.5 meters (11.5 feet) from the edge of the pool. Ensure it is not exposed to direct sunlight or standing water.
2. Uncoil the floating cable completely.
3. Gently lower the robotic cleaner into the pool. Allow it to sink to the bottom. Ensure there are no air bubbles trapped inside the unit.
4. Connect the floating cable to the power supply unit, ensuring a secure connection.
5. Plug the power supply unit into a grounded AC outlet.

5. OPERATION

5.1 Starting a Cleaning Cycle

1. Ensure the cleaner is fully submerged and the power supply is connected.
2. Press the power button on the power supply unit or use the remote control to start the cleaning cycle.
3. The cleaner will begin its programmed cleaning pattern, covering the pool floor and walls.

5.2 Using the Remote Control

The remote control allows for manual steering and selection of specific cleaning modes or speeds.

- **Directional Buttons:** Use to steer the cleaner manually to specific areas.
- **Mode Selection:** Choose between different cleaning modes (e.g., floor-only, wall-climbing).
- **Speed Adjustment:** Adjust the cleaning speed if available.

5.3 Retrieving the Cleaner

1. Once the cleaning cycle is complete, or you wish to retrieve the cleaner, turn off the power supply.
2. Gently pull the floating cable to bring the cleaner to the edge of the pool.
3. Use the handle to lift the cleaner out of the water. Allow excess water to drain before placing it on the pool deck.
4. Disconnect the floating cable from the power supply unit.

6. MAINTENANCE

Regular maintenance ensures the efficient operation and extends the lifespan of your WYBOT Grampus 1300.

6.1 Cleaning the Filter Baskets

1. After each cleaning cycle, remove the filter baskets from the cleaner.
2. Empty any collected debris into a waste bin.
3. Rinse the filter baskets thoroughly with a garden hose until all debris is removed.
4. Ensure the filters are completely dry before reinserting them into the cleaner.

6.2 Cleaning the Cleaner Unit

- Periodically rinse the exterior of the cleaner with fresh water to remove any chemical residue or algae.
- Inspect the scrubbing wheels/brushes for wear or damage. Clean any entangled hair or debris.
- Ensure all sensors (if applicable) are clean and free from obstructions.

6.3 Storage

- When not in use for extended periods, clean the cleaner thoroughly and allow it to dry completely.
- Store the cleaner in a cool, dry, and shaded area, away from direct sunlight and extreme temperatures.
- Coil the floating cable neatly to prevent tangling.

6.4 Belt Replacement (If Applicable)

Over time, the drive belts may wear out and require replacement. Refer to the official WYBOT support resources for specific instructions and to obtain genuine replacement parts. Using non-genuine parts may void your warranty or impair performance.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your WYBOT Grampus 1300. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Cleaner does not start.	No power, cable not connected, power supply fault.	Ensure power supply is plugged in and turned on. Check cable connections. Verify outlet functionality.
Poor cleaning performance.	Clogged filters, worn brushes/wheels, debris obstruction.	Clean filter baskets. Inspect and clean brushes/wheels. Remove any large debris from the cleaner's intake.
Cleaner does not climb walls effectively.	Air trapped inside, dirty brushes/wheels, water chemistry issues.	Ensure cleaner is fully submerged and air is expelled. Clean brushes/wheels. Check pool water chemistry (e.g., calcium hardness).
Cable tangles during operation.	Improper cable deployment, excessive cable length.	Ensure cable is fully uncoiled before use. Distribute excess cable evenly around the pool.

8. SPECIFICATIONS

Feature	Detail
Brand	WYBOT
Model Name	HJ
Model Number	Grampus 1300
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	White
Power Source	AC

Feature	Detail
Control Method	Remote
Special Features	Self Propelled
Included Components	Pool Vacuum, Quick Guide
Product Care Instructions	Place in a dry environment

9. WARRANTY & SUPPORT

9.1 Limited Warranty

The WYBOT Grampus 1300 Robotic Pool Cleaner comes with a limited warranty. Please refer to the warranty card included with your product or visit the official WYBOT website for detailed terms and conditions. This warranty typically covers manufacturing defects under normal use conditions.

9.2 Customer Support

For technical assistance, troubleshooting not covered in this manual, or to inquire about replacement parts, please contact WYBOT customer support. Contact information can typically be found on the official WYBOT website or on the product packaging. When contacting support, please have your product model number (Grampus 1300) and purchase date available.

© 2026 WYBOT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BYK3Y513>

More documents and user manuals: <https://manuals.plus/>