

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Bear](#) /

> [Bear Rice Cooker 3 Cups \(Uncooked\), 3D Heating and Fuzzy Logic, Healthy Nonstick Small Rice Cooker, PFAS-Free, Touch-Screen, for White/Brown Rice Quinoa Oatmeal Soup](#)

Bear DFB-B16C1

Bear Rice Cooker User Manual

Model: DFB-B16C1 | Brand: Bear

INTRODUCTION

Thank you for choosing the Bear Rice Cooker. This compact and versatile appliance is designed to simplify your cooking experience, offering perfect results for various grains and dishes. With its 3D heating, fuzzy logic technology, and healthy nonstick inner pot, you can enjoy perfectly cooked rice, quinoa, oatmeal, and soups with ease. This manual provides essential information for safe operation, maintenance, and troubleshooting.



Image: Front view of the Bear Rice Cooker.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been

damaged in any manner.

- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

PRODUCT COMPONENTS

Your Bear Rice Cooker comes with the following components:

- **Rice Cooker Unit:** The main appliance with touch-screen control panel.
- **Inner Pot:** Healthy nonstick, PFAS-free pot for cooking.
- **Measuring Cup:** For accurate measurement of rice and water.
- **Rice Spoon:** Non-scratch spoon for serving rice.
- **Detachable Power Cable:** For connecting the cooker to power.

HEALTHY AND SAFE ACCESSORIES



INCLUDES:



MEASURING CUP



RICE SPOON



DETACHABLE POWER CABLE



CLEAR MEASUREMENT MARKS

Image: Bear Rice Cooker with its included accessories: inner pot, measuring cup, and rice spoon.

SETUP

1. **Unpack:** Carefully remove all packaging materials and accessories.
2. **Clean:** Before first use, wash the inner pot, measuring cup, and rice spoon with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the rice cooker unit with a damp cloth.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight or heat sources. Ensure adequate ventilation around the unit.
4. **Insert Inner Pot:** Place the clean, dry inner pot into the main rice cooker unit. Ensure it sits properly and is level.
5. **Connect Power:** Insert the detachable power cable into the rice cooker's power inlet, then plug the other end into a standard 120V electrical outlet.

OPERATING INSTRUCTIONS

General Cooking Steps:

1. **Measure Ingredients:** Use the provided measuring cup to measure the desired amount of rice. Rinse rice thoroughly if desired.
2. **Add Water:** Add the appropriate amount of water to the inner pot. The inner pot has clear measurement marks for different types of rice and quantities.
3. **Place Inner Pot:** Ensure the inner pot is correctly placed inside the rice cooker unit. Close the lid securely.
4. **Select Menu:** Plug in the rice cooker. The display will show "OFF". Press the "Menu" button to cycle through the cooking options: White Rice, Brown Rice, Quinoa, Oatmeal, Soup. The selected option will illuminate.
5. **Start Cooking:** Press the "Start/Cancel" button to begin the cooking process. The display will show a countdown or progress indicator.
6. **Keep Warm:** Once cooking is complete, the rice cooker will automatically switch to "Keep Warm" mode. The display will show how long it has been keeping warm.

Specific Cooking Modes:

- **White Rice:** Ideal for fluffy white rice. The fuzzy logic system adjusts cooking time and temperature for optimal results.
- **Brown Rice:** Designed for the longer cooking time and higher water absorption of brown rice.
- **Quinoa:** Perfectly cooks quinoa, ensuring a light and fluffy texture.
- **Oatmeal:** Prepares creamy oatmeal.
- **Soup:** Use this setting for preparing various soups.

EASY OPERATION

Panel on the top, simple to control



Image: Close-up of the Bear Rice Cooker's top-mounted control panel, showing menu options for different food types.

Delay Timer / Preset Function:

The delay timer allows you to set a specific time for your cooking to finish. This is useful for meal planning.

1. After adding ingredients and selecting a menu, press the "Delay" button.
2. Use the "+" and "-" buttons to adjust the desired delay time (e.g., 2 hours).
3. Press "Start/Cancel" to confirm. The cooker will start cooking after the set delay time has passed.

3D HEATING AND SMART FUZZY LOGIC

Cook fluffy and evenly rice



Image: Illustration of the preset/delay start function, showing how to set the cooker to finish at a later time.

MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and performance of your rice cooker.

- **Always unplug** the rice cooker from the power outlet and allow it to cool completely before cleaning.
- **Inner Pot:** The healthy nonstick inner pot is dishwasher-safe. For best results and to preserve the nonstick coating, hand wash with warm, soapy water and a soft sponge. Avoid abrasive cleaners or metal scouring pads.
- **Lid:** The inner lid is detachable for easy cleaning. Wash it with warm, soapy water and rinse thoroughly.
- **Exterior:** Wipe the exterior of the rice cooker unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Steam Vent:** Ensure the steam vent is clear of any food debris.

PRESET / DELAY START



23:00 Put rice



07:30 Enjoy delicious soup



Image: The inner pot and other removable parts of the Bear Rice Cooker placed in a dishwasher, indicating they are dishwasher safe.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Rice is too hard/dry	Not enough water; lid not properly closed; inner pot not seated correctly.	Add more water next time (refer to water lines); ensure lid is sealed; check inner pot placement.
Rice is too soft/mushy	Too much water.	Reduce water next time (refer to water lines); ensure correct rice-to-water ratio.
Cooker does not turn on	Not plugged in; power outage; faulty outlet.	Check power cord connection; test outlet with another appliance; contact customer service if issue persists.

Problem	Possible Cause	Solution
Steam leaking from lid	Lid not closed properly; seal ring dirty or damaged.	Ensure lid is securely latched; clean or inspect seal ring for damage.

SPECIFICATIONS

Brand: Bear

Model Name: small rice cooker

Model Number: DFB-B16C1

Capacity: 1.6 Liters (3 cups uncooked rice)

Product Dimensions: 8.98"D x 8.03"W x 9.61"H

Item Weight: 4.3 Pounds

Power Source: Corded Electric

Wattage: 400 watts

Voltage: 120 Volts

Material: Metal (body), Plastic (lid)

Special Feature: Automatic Keep Warm, Non-Stick (PFAS-Free)

Product Care Instructions: Hand Wash (Inner Pot is Dishwasher Safe)



Image: Dimensional diagram of the Bear Rice Cooker.

WARRANTY AND SUPPORT

Bear provides a **3-year after-sale warranty** for this product. We are committed to providing excellent customer service and lifetime technical support.

For any product issues or inquiries, please contact our friendly customer support team. We aim to reply within 24 hours to ensure your fullest satisfaction.

Please refer to your purchase documentation for specific contact details or visit the official Bear website for support information.



Image: Graphic detailing friendly service, including warranty and customer support.