

Cosmic Byte ARES Wireless

Cosmic Byte ARES Wireless Controller User Manual

Model: ARES Wireless

INTRODUCTION

Thank you for choosing the Cosmic Byte ARES Wireless Controller. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new controller. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

The Cosmic Byte ARES Wireless Controller is designed for PC gaming, offering a reliable wireless connection, ergonomic design, and responsive controls for an enhanced gaming experience. It features pressure-sensitive analog triggers, LED-backlit buttons, and supports both Xinput and D Input modes.


SETUP GUIDE

1. Package Contents

- Cosmic Byte ARES Wireless Controller
- USB Wireless Dongle
- USB Charging Cable
- User Manual

2. Charging the Controller

Before initial use, fully charge the controller. Connect the supplied USB charging cable to the USB port on the top of the controller and plug the other end into a powered USB port (e.g., PC, USB wall adapter). The LED indicator on the controller will show charging status and turn off or change color when fully charged.



Top view of the Cosmic Byte ARES Wireless Controller showing the USB port for charging and connection, along with the V LED and ABXY button backlighting.

3. Connecting to PC

1. Insert the USB wireless dongle into an available USB port on your PC.
2. Turn on the Cosmic Byte ARES Wireless Controller by pressing the central 'Home' button.
3. The controller will automatically pair with the dongle. The LED indicator on the controller will stabilize once connected.
4. Your PC should automatically detect and install the necessary drivers. If not, refer to the troubleshooting section.

The controller offers a wireless range of 8-10 meters, providing flexibility during gameplay.



The Cosmic Byte ARES Wireless Controller highlighting its reliable wireless connection and 700mAh battery, providing up to 12 hours of continuous gaming.

OPERATING INSTRUCTIONS

1. Basic Controls

The controller features standard gamepad buttons and joysticks:

- **Left Analog Stick:** Movement and navigation.
- **Right Analog Stick:** Camera control and aiming.
- **D-Pad:** Directional input, menu navigation.
- **ABXY Buttons:** Action buttons, typically for jumping, interacting, attacking, etc. These buttons are LED-backlit.
- **Shoulder Buttons (L1/R1):** Quick actions.
- **Triggers (L2/R2):** Pressure-sensitive analog triggers for precise input, such as acceleration or shooting.
- **START/BACK Buttons:** Menu access, map, inventory, etc.
- **Home Button:** Powers on/off the controller, accesses system menus.



Front view of the Cosmic Byte ARES Wireless Controller, showcasing the button layout, joysticks, D-pad, and central LED indicator.

2. Special Features

- **Xinput and D Input Support:** The controller automatically detects and supports both Xinput and D Input modes, ensuring compatibility with a wide range of PC games.
- **Vibration Feedback:** Experience immersive gameplay with the built-in vibration feature, providing tactile feedback for in-game events.
- **Turbo Function:** The 'TURBO' button allows for rapid, repeated input of a selected action button. To activate, press and hold the 'TURBO' button, then press the desired action button (e.g., A, B, X, Y). To deactivate, repeat the process.
- **Auto Function:** The 'AUTO' button enables continuous, automatic input of a selected action button without holding it down. To activate, press and hold the 'AUTO' button, then press the desired action button. To deactivate, repeat the process.
- **Hall Effect Triggers:** The controller is equipped with Hall Effect Triggers, providing precise and durable input for enhanced control.
- **Ergonomic Design:** The controller features ergonomic, rubberized textured sticks for improved grip and comfort during extended gaming sessions.



Illustration of the Cosmic Byte ARES Wireless Controller's vibration feedback feature and the design of its rubberized textured joysticks for enhanced grip.



TURBO AND AUTO FUNCTION

Because every millisecond counts

HALL EFFECT TRIGGERS

Where every press hits different

Detail of the Cosmic Byte ARES Wireless Controller's Turbo and Auto function buttons, alongside an illustration of its Hall Effect Triggers for precise input.

MAINTENANCE

1. Cleaning

To clean your controller, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals, solvents, or abrasive cleaners, as these can damage the controller's surface and internal components.

2. Battery Care

- Avoid exposing the controller to extreme temperatures (hot or cold).
- Do not leave the controller uncharged for extended periods. Charge it periodically if not in use.
- Do not attempt to replace the internal battery yourself. Contact support if battery issues arise.

TROUBLESHOOTING

1. Controller Not Connecting

- Ensure the USB wireless dongle is securely plugged into a working USB port on your PC.
- Make sure the controller is powered on and has sufficient battery charge.
- Try plugging the dongle into a different USB port on your PC.
- Restart your PC and try connecting again.
- If the issue persists, try re-pairing the controller by pressing the reset button (if available, usually a small pinhole on the back) on the controller and then the pairing button on the dongle (if applicable).

2. Buttons/Joysticks Unresponsive

- Check if the controller is properly connected to your PC.
- Ensure the game you are playing supports gamepad input.
- Test the controller with another game or a gamepad testing tool on your PC to rule out game-specific issues.
- Restart the controller and your PC.

3. Battery Not Charging

- Verify that the USB charging cable is correctly connected to both the controller and a powered USB port.
- Try using a different USB charging cable or a different USB port/power adapter.
- Ensure the charging port on the controller is free of debris.

SPECIFICATIONS

Feature	Detail
Model Number	ARES Wireless White
Connectivity	Wireless (USB Dongle)
Wireless Range	8-10 meters
Battery	1 Lithium-polymer (included), 700mAh
Battery Life	Up to 12 hours of continuous gaming
Compatibility	PC (Xinput & D Input)
Product Dimensions (L x W x H)	6 x 10 x 4 cm
Weight	200 grams
Outer Material	Plastic and paper
Water Resistance Level	Water-resistant
Manufacturer	Cosmic Byte

WARRANTY INFORMATION

The Cosmic Byte ARES Wireless Controller comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official Cosmic Byte website for detailed






warranty terms and conditions. Keep your purchase receipt as proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact Cosmic Byte customer support. Contact details can typically be found on the official Cosmic Byte website or on the product packaging.

© 2023 Cosmic Byte. All rights reserved.

Related Documents - ARES Wireless


	<p>Cosmic Byte ARES Wireless Controller User Manual</p> <p>Comprehensive user manual for the Cosmic Byte ARES Wireless Controller, detailing its features, specifications, setup, mode switching, turbo functions, battery status, pairing, and support information.</p>
	<p>Cosmic Byte CosmoBuds X100 Pinch Touch Functionality Guide</p> <p>Learn how to use the pinch touch controls on your Cosmic Byte CosmoBuds X100 earbuds for music playback, calls, and switching between Music and GOD modes.</p>
	<p>Cosmic Byte Firefly Mechanical Gaming Keyboard User Manual</p> <p>Comprehensive user manual for the Cosmic Byte Firefly Mechanical Gaming Keyboard, detailing specifications, multimedia and FN key functions, troubleshooting steps, software download, social media links, and warranty information.</p>
	<p>Cosmic Byte Firefly Mechanical Gaming Keyboard User Manual Specifications, Features, Troubleshooting</p> <p>Comprehensive user manual for the Cosmic Byte Firefly Mechanical Gaming Keyboard (CB-GK-16, CB-GK-18). Find details on specifications, multimedia and FN key combinations, software download, troubleshooting tips, and warranty information.</p>
	<p>Cosmic Byte CosmoBuds X200 True Wireless Gaming Earbuds User Manual</p> <p>User manual for the Cosmic Byte CosmoBuds X200 True Wireless Gaming Earbuds. Learn about features like Bluetooth 5.3, 38ms ultra-low latency, 40-hour playback, IPX5 water resistance, touch controls, charging, pairing, and troubleshooting.</p>



[Cosmic Byte ARES Wireless Controller User Manual](#)


Comprehensive user manual for the Cosmic Byte ARES Wireless Controller, detailing its features, specifications, setup, mode switching, turbo functions, battery status, pairing, and support information.

Documents - Cosmic Byte – ARES Wireless



[\[pdf\]](#) User Manual Specifications

V1 0 Firefly User manual 2021 4 26 ai Manual Buy Cosmic Byte CB GK 16 Per Key RGB Ten Keyless Mechanical Keyboard with Outemu Blue Switch ARES Wireless Controller for PC Black Reviews Ratings 71s6p0qf36L m media amazon images I |||
User Manual of Product 1: Cosmic Byte CB-GK-16 Firefly Per-Key RGB TKL Mechanical Keyboard with Swappable Outemu Blue Switch, Macros, Software Black
User Manual of Product 2: Cosmic Byte ARES Wireless Controller for PC Black Firefly Mechanical Gaming Keyboard User Manual CONGRATULATIONS ON THE...
lang:en score:34 filesize: 165.19 K page_count: 3 document date: 2021-04-26




[\[pdf\]](#) User Manual

User Manual Cosmic Byte ARES Wireless Controller for PC Black CB GK 26 USB A Pandora TKL Mechanical Keyboard with Outemu Red Switches and Rainbow LED Grey Video Games 01Drc 3dz4L m media amazon images I |||
User Manual of Product 1: Cosmic Byte ARES Wireless Controller for PC Black User Manual of Product 1: Cosmic Byte ARES Wireless Controller for PC Black ...
lang:en score:34 filesize: 1.81 K page_count: 2 document date: 0000-00-00



[\[pdf\]](#) User Manual


User Manual Buy Cosmic Byte CB GK 23 Artemis 68Key Per Key RGB Wired Mechanical Keyboard with Outemu Blue Switches and Software Black ARES Wireless Controller for PC Reviews Ratings 81km05AkYPL m media amazon images I |||
User Manual of Product 1: Cosmic Byte ARES Wireless Controller for PC Black ...
lang:en score:32 filesize: 291.97 K page_count: 9 document date: 0000-00-00



[\[pdf\]](#) User Manual

User Manual Cosmic Byte ARES Wireless Controller for PC Black CB GK 25 Pandora TKL Mechanical Keyboard with Outemu Blue Switches and Rainbow LED Grey Video Games 01FqwiEr3L m media amazon images I |||

User Manual of Product 1: Cosmic Byte CB-GK-23 Artemis 68Key Per Key RGB Wired Mechanical Keyboard with Outemu Blue Switches and Software Black User Manual of Product 1: Cosmic Byte CB-GK-23 Artemis 68Key Per Key RGB Wired Mechanical Keyboard with Outemu Blue Switches and Software Black ...
lang:en **score:29** filesize: 1.88 K page_count: 2 document date: 0000-00-00



[\[pdf\]](#) User Manual

User Manual Cosmic Byte ARES Wireless Controller for PC Black CB GK 17 Galactic Wired Gaming Keyboard with Aluminium Body 7 Color RGB Backlit Effects Anti Ghosting Video Games 01ngmbkj7VL m media amazon images I |||

User Manual of Product 1: Cosmic Byte CB-GK-16 Firefly Per-Key RGB TKL Mechanical Keyboard with Swappable Outemu Blue Switch, Macros, Software Black User Manual of Product 1: Cosmic Byte CB-GK-16 Firefly Per-Key RGB TKL Mechanical Keyboard with Swappable Outemu Blue Switch, Macros, Software Bla...
lang:en **score:29** filesize: 1.89 K page_count: 2 document date: 0000-00-00



[Cosmic Byte ARES Wireless Controller User Manual](#)

Comprehensive user manual for the Cosmic Byte ARES Wireless Controller, detailing its features, specifications, setup, mode switching, turbo functions, battery status, pairing, and support information.

lang:en **score:26** filesize: 587.79 K page_count: 10 document date: 2023-02-03