

[Manuals.plus](#) /

› [Feasto](#) /

› Feasto Portable Camping Propane Stove User Manual

Feasto 1813CSR

Feasto Portable Camping Propane Stove User Manual

Model: 1813CSR

1. INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Feasto Portable Camping Propane Stove. Please read this manual thoroughly before assembly, operation, or maintenance. Keep this manual for future reference.

2. SAFETY INFORMATION

WARNING: For Outdoor Use Only. Do not operate indoors or in enclosed spaces. Carbon Monoxide Hazard.

DANGER: If you smell gas:

1. Shut off gas to the appliance.
2. Extinguish any open flame.
3. Open lid.
4. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.

Always ensure proper ventilation when operating the stove. Keep children and pets away from the stove during operation. Do not leave the stove unattended while in use.



Image: The Feasto Portable Camping Propane Stove in its open configuration, ready for use. Note the two burners and the integrated wind guards.

3. PRODUCT COMPONENTS

- **Two Burners:** Each with 14,000 BTU output.
- **Push-Button Ignition:** For easy lighting.
- **Adjustable Control Knobs:** To regulate flame intensity.
- **Folding Wind Guards:** Integrated into the lid for wind protection.
- **Folding Legs:** Provide stable support and compact storage.
- **Portable Handle:** For convenient transport.
- **Safety Buckle:** Secures the stove for transport.
- **Propane Regulator:** Connects to standard 1lb propane cylinders.

PORTABLE COLLAPSIBLE DESIGN

HEAT, GRILL, AND FRY ANYTIME, ANYWHERE



Image: Practical dimensions of the stove, showing its height (13.6 inches) and length (22.8 inches including regulator) when open, and its compact size (18.7 inches length, 13.2 inches width, 3.4 inches height) when folded.

4. SETUP INSTRUCTIONS

1. **Unpack and Inspect:** Carefully remove the stove from its packaging. Inspect for any damage.
2. **Set Up Legs:** Place the stove on a flat, stable surface. Unfold the integrated legs until they lock securely into place.
3. **Open Lid and Wind Guards:** Unlatch the safety buckle and open the lid. Extend the side wind guards to provide protection from wind.
4. **Connect Propane Tank:** Ensure both burner control knobs are in the "OFF" position. Screw the propane regulator firmly into the stove's gas inlet. Then, screw a 1lb propane cylinder onto the regulator. Ensure all connections are tight to prevent leaks.

PROPER USE OF GAS TANK

START CREATING DELICIOUS MEALS

ONCE THE PROPANE HOSE ATTACHMENT IS CONNECTED

Note:



Note:

Never operate the stove with the propane cylinder in an inverted position.



Image: Proper use of the gas tank. The correct method shows the propane cylinder upright, connected to the regulator. An incorrect method shows the cylinder inverted, which should be avoided.

5. OPERATING INSTRUCTIONS

1. **Prepare for Lighting:** Ensure the stove is set up on a stable surface and the propane tank is securely connected.
2. **Turn on Gas:** Slowly turn one of the burner control knobs counter-clockwise to the "ON" position. You should hear the gas flowing.
3. **Ignite Burner:** Immediately press the red push-button ignition. The burner should ignite. If it does not ignite within 5 seconds, turn the knob to "OFF", wait 5 minutes for gas to dissipate, and then repeat the process.
4. **Adjust Flame:** Once lit, adjust the flame to the desired intensity by rotating the control knob. The flame should be compact and blue in color.
5. **Shut Down:** To turn off the burner, turn the control knob clockwise to the "OFF" position. Ensure the flame is completely extinguished.

TOTAL 28,000 BTU OUTPUT



Image: Close-up view of the control panel, highlighting the push-button ignition and the adjustable burner knobs for precise flame control.

Your browser does not support the video tag.

Video: An official product video demonstrating the setup and use of the Feasto Portable Camping Propane Stove, including cooking various foods. This video highlights the ease of use and portability of the stove.

6. MAINTENANCE AND CARE

- **Cleaning:** Allow the stove to cool completely before cleaning. Wipe down the stainless steel cooking surface and exterior with a damp cloth and mild detergent. Do not use abrasive cleaners or scouring pads.
- **Storage:** Ensure the stove is clean and dry before storing. Fold the legs and wind guards, secure the safety buckle, and store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Burner Maintenance:** Periodically check the burners for any obstructions or debris. Clean as necessary to ensure optimal performance.

FOLDING WIND SCREEN

THREE SIDES SHIELD, WINDPROOF GATHER FIRE



Image: Demonstrates the ease of cleaning the stove's stainless steel surface after use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner does not light.	No gas flow; clogged burner; faulty igniter.	Check propane tank connection and ensure it's not empty. Clean burner ports. Try lighting with a long match or lighter.
Flame is weak or inconsistent.	Low gas pressure; partially clogged burner; wind interference.	Ensure propane tank is full and regulator is properly connected. Clean burner. Ensure wind guards are fully extended.
Gas smell without flame.	Gas leak; improper connection.	Immediately shut off gas. Check all connections for tightness. If smell persists, do not operate and contact customer support.

8. SPECIFICATIONS

- **Brand:** Feasto
- **Model Number:** 1813CSR
- **Fuel Type:** Propane, Liquefied Petroleum Gas
- **Material:** Stainless Steel
- **Product Dimensions (Open):** 22.8"L x 14.1"W x 13.6"H
- **Power Source:** Gas Powered
- **Maximum Energy Output:** 28,000 British Thermal Units (14,000 BTU per burner x 2)
- **Item Weight:** 9.9 Pounds
- **UPC:** 850038350161
- **Country of Origin:** China

9. WARRANTY AND SUPPORT

Feasto products are designed for durability and performance. For any questions, technical support, or warranty claims, please contact Feasto customer service. Please have your model number (1813CSR) and purchase information ready.

Customer Service: Refer to your product packaging or the official Feasto website for the most current contact information.

© 2025 Feasto. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BYMQRF39>

More documents and user manuals: <https://manuals.plus/>