

Funistree L26

Funistree Cell Phone Stand with Wireless Bluetooth Speaker

USER MANUAL - MODEL L26

Product Overview

The Funistree Cell Phone Stand with Wireless Bluetooth Speaker (Model L26) is a versatile device designed to enhance your mobile experience. It combines a stable phone holder with a high-definition Bluetooth speaker and an integrated LED light, offering convenience for various activities such as watching videos, making hands-free calls, listening to music, and providing illumination.



Figure 1: The Funistree Cell Phone Stand with Wireless Bluetooth Speaker, showcasing its integrated design with a phone resting on the stand and sound waves emanating from the speaker.

3 in 1 Bluetooth Speaker

phone stand with LED light



MUSIC



MOVIE



E-BOOK



HANDS
FREE



Funistree

Figure 2: Illustration of the device's 3-in-1 functionality: Bluetooth speaker, phone stand, and LED light, suitable for music, movies, e-books, and hands-free calls.

Key Features:

- Wireless Bluetooth Speaker:** Features a dual stereo system for HD sound with boosted bass, clear highs, and balanced mids.
- Adjustable Phone Stand:** Designed with adjustable height and angle to accommodate various viewing needs for smartphones (4"-8.3") and mini tablets.
- Built-in Microphone:** Enables convenient hands-free calling.
- High Capacity Battery:** Equipped with an 1800 mAh battery for extended playtime and reduced charging frequency.
- Integrated LED Light:** Features a high-bright LED light with two modes (lighting and flashing) for use as a night light, outdoor lighting, or in emergencies.
- Universal Compatibility:** Supports a wide range of smartphones and mini tablets.

Setup Guide

1. Unboxing and Initial Charge:

Carefully remove the device from its packaging. Before first use, fully charge the device using the provided charging cable. The 1800 mAh Lithium Ion battery ensures a long operational period.

2. Powering On/Off:

Locate the power button on the device. Press and hold the power button for approximately 3 seconds to turn the device on or off. An indicator light or sound will confirm the power status.

3. Bluetooth Pairing:

Once powered on, the speaker will automatically enter Bluetooth pairing mode, indicated by a flashing LED light. On your smartphone or tablet, navigate to the Bluetooth settings and search for available devices. Select "Funistree L26" (or similar name) from the list to connect. A confirmation sound will indicate successful pairing.



Figure 3: Visual representation of the Bluetooth 5.0 technology, ensuring stable and efficient wireless connection.

4. Adjusting the Phone Stand:

The phone stand features adjustable height and angle. Gently pull the stand upwards to extend its height and tilt the phone holder to achieve your desired viewing angle. Ensure your device is securely placed on the stand's anti-slip surface.

Strong Stability

Adjustable Viewing Angle



Figure 4: Demonstrates the adjustable height and angle features of the phone stand, highlighting its strong stability and anti-slip design.

Operating Instructions

Bluetooth Speaker Functions:

- **Play/Pause:** Press the **Play/Pause** button (often indicated by a triangle or two vertical bars) to start or pause audio playback.
- **Volume Control:** Use the + button to increase volume and the- button to decrease volume.
- **Next/Previous Track:** Press and hold the + button to skip to the next track. Press and hold the- button to go to the previous track.

Hands-Free Calling:

When a call comes in while connected via Bluetooth, the speaker will ring. Press the **Play/Pause** button to answer the call. To end the call, press the **Play/Pause** button again. The built-in microphone allows for clear communication.

HANDSFREE CALL

With Built-in Mic



Funistree

Figure 5: Demonstrates the hands-free calling capability of the device, facilitated by its built-in microphone.

LED Light Operation:

- **Turn On/Off:** Locate the dedicated light button (often on the side). Press once to turn on the lighting mode.
- **Switch Modes:** Press the light button again to switch to flashing mode. Press a third time to turn the light off.



ENJOY COOKING

Hands Free and Make Life Convenience

Figure 6: The integrated LED light provides illumination, useful for bedside or other low-light environments.

Maintenance

- Cleaning:** Use a soft, dry cloth to wipe the surface of the device. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the finish.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. If storing the device for an extended period, charge it to approximately 50% every few months.
- Storage:** Store the device in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- Handling:** Avoid dropping the device or subjecting it to strong impacts, which could damage internal components.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Battery is depleted.	Connect the device to a power source using the charging cable and allow it to charge for at least 30 minutes before attempting to power on again.
Cannot connect via Bluetooth.	Device is not in pairing mode. Bluetooth is off on your phone/tablet. Device is too far from your phone/tablet. Interference from other devices.	Ensure the device is powered on and the Bluetooth indicator is flashing. Activate Bluetooth on your phone/tablet and search for "Funistree L26". Move the device closer to your phone/tablet (within 10 meters). Turn off other Bluetooth devices nearby or move to an area with less interference.
No sound from speaker.	Volume is too low. Device is not connected. Audio source issue.	Increase the volume on both the speaker and your connected device. Verify that the speaker is successfully paired and connected to your device. Check if audio is playing correctly from your source device (phone/tablet).

Problem	Possible Cause	Solution
LED light not working.	Light function is off or battery is low.	Press the light button to cycle through modes. Ensure the device has sufficient battery charge.

Specifications

Feature	Detail
Brand	Funistree
Model	L26
Compatible Devices	Smartphones (4"-8.3"), Mini Tablets
Special Features	Portable, Wireless, Adjustable Phone Stand, Built-in Microphone, LED Light
Battery Capacity	1800 Milliamp Hours (mAh)
Battery Type	Lithium Ion (included)
Audio Output Mode	Stereo
Speakers Maximum Output Power	3 Watts
Connector Type	Bluetooth
Material Type	Metal
Form Factor	Foldable
Mounting Type	Tabletop
Product Dimensions	15 x 9.5 x 4.3 cm
Item Weight	322 g

Warranty and Support

For warranty information, technical support, or any inquiries regarding your Funistree Cell Phone Stand with Wireless Bluetooth Speaker, please contact Funistree customer service directly. Refer to the product packaging or the official Funistree website for the most up-to-date contact details.

It is recommended to retain your proof of purchase for warranty claims.