

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Next](#) /

> [Next Q-play 4K Satellite Receiver User Manual](#)

Next Q-play 4K

Next Q-play 4K Satellite Receiver User Manual

Model: Q-play 4K

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Next Q-play 4K Satellite Receiver. Please read this manual thoroughly before using the device to ensure proper functionality and to prevent damage. Keep this manual for future reference.

2. SAFETY INFORMATION

- Ensure the device is connected to a power source with the correct voltage as specified on the product label.
- Do not expose the device to rain, moisture, or extreme temperatures.
- Avoid placing the device near heat sources or in direct sunlight.
- Do not open the device casing. Refer all servicing to qualified personnel.
- Keep the device away from strong magnetic fields.
- Unplug the device during lightning storms or when unused for extended periods.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Next Q-play 4K Satellite Receiver Unit
- Remote Control
- Power Adapter
- HDMI Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

4.1 Front Panel



Figure 4.1: Front view of the Next Q-play 4K Satellite Receiver. The front panel features the Q-play 4K logo on the left, a digital display in the center showing time or channel information, and indicators for USB, DVB, HDMI, and NET connections.

4.2 Side Panel



Figure 4.2: Angled view of the Next Q-play 4K Satellite Receiver, highlighting the front display and the side panel. The side panel includes a USB 3.0 port and a TF Card Reader slot.

4.3 Rear Panel



Figure 4.3: Detailed view of the rear panel of the Next Q-play 4K Satellite Receiver. From left to right, connections include: Wi-Fi antenna, DVB-S2 IN (satellite input), LOOP OUT, CVBS/L/R (composite video/audio), HDMI output, LAN (Ethernet), OPTICAL (digital audio), and DC 12V power input.

5. SETUP GUIDE

5.1 Connecting to Your TV

1. Ensure both your TV and the satellite receiver are powered off.
2. Connect one end of the provided HDMI cable to the **HDMI** port on the rear of the Next Q-play 4K receiver.
3. Connect the other end of the HDMI cable to an available HDMI input port on your TV. Note the HDMI input number (e.g., HDMI 1, HDMI 2) for later selection.
4. (Optional) For older TVs, connect a composite video (CVBS) and analog audio (L/R) cable to the **CVBS/L/R** ports on the receiver and the corresponding inputs on your TV.

5.2 Connecting to a Satellite Dish

1. Connect the coaxial cable from your satellite dish LNB to the **DVB-S2 IN** port on the rear of the receiver.
2. If you have another satellite receiver or device you wish to loop through, connect a coaxial cable from the **LOOP OUT** port to the input of the other device.

5.3 Network Connection

- **Wired Connection (Ethernet):** Connect an Ethernet cable from your router or network switch to the **LAN** port on the rear of the receiver.
- **Wireless Connection (Wi-Fi):** The device has built-in 2.4G & 5G Dual Band Wi-Fi. During the initial setup, you will be prompted to connect to your wireless network.

5.4 Powering On

1. Connect the power adapter to the **DC 12V** input port on the receiver.
2. Plug the power adapter into a wall outlet.
3. Turn on your TV and select the correct HDMI input source (e.g., HDMI 1) that the receiver is connected to.
4. The receiver will power on automatically. Follow the on-screen instructions for the initial setup wizard.

6. OPERATING INSTRUCTIONS

6.1 Initial Setup Wizard

Upon first power-on, the receiver will guide you through an initial setup process. This typically includes:

- **Language Selection:** Choose your preferred language.
- **Network Configuration:** Connect to your Wi-Fi network or confirm Ethernet connection.
- **Satellite Scan:** Configure your satellite dish settings and perform a channel scan to find available channels.
- **Time Zone:** Set your local time zone.
- **Google Account Setup:** Log in with your Google account to access Google Play Store and other Android services.

6.2 Basic Navigation

Use the provided remote control to navigate the Android interface. The main buttons typically include:

- **Directional Pad (D-Pad):** For moving between menu items.

- **OK/Enter Button:** To select an item or confirm an action.
- **Back Button:** To return to the previous screen.
- **Home Button:** To go to the main Android home screen.
- **Volume Up/Down:** To adjust audio volume.
- **Channel Up/Down:** To change TV channels.

6.3 Using Android Features

As an Android-based receiver, the Next Q-play 4K offers access to various applications and services:

- **Google Play Store:** Download and install compatible applications, games, and streaming services.
- **Media Playback:** Play local media files from USB drives or TF cards using pre-installed media players.
- **Bluetooth Connectivity:** Connect Bluetooth devices such as headphones, speakers, or game controllers (BT V4.2).
- **Internet Browsing:** Use a web browser to access internet content.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the ventilation openings are not blocked to prevent overheating.
- **Software Updates:** Periodically check for system software updates through the Android settings menu to ensure optimal performance and security.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet faulty; Power adapter faulty.	Check power cable connection; Try a different outlet; Contact support if adapter is faulty.
No signal / No picture on TV	Incorrect HDMI input selected on TV; HDMI cable loose or faulty; Satellite dish not connected or misaligned.	Select correct HDMI input on TV; Reconnect HDMI cable or try a new one; Check satellite cable connection and dish alignment.
Remote control not working	Batteries depleted or inserted incorrectly; Obstruction between remote and receiver.	Replace batteries; Ensure correct battery polarity; Remove obstructions and point remote directly at receiver.
Cannot connect to Wi-Fi	Incorrect password; Router too far; Wi-Fi signal interference.	Verify Wi-Fi password; Move receiver closer to router; Check for other devices causing interference.

9. SPECIFICATIONS

Feature	Detail
Satellite Channel Capacity	20,000
Processor	Amlogic S905X3 (4-Core ARM Cortex-A55)
Graphics Processor	ARM Mali-G31 MP2 GPU
Flash Memory	16GB eMMC
RAM Memory	2GB LPDDR4
Operating System	Android 9
Bluetooth	BT V4.2
USB 2.0 Port	1
USB 3.0 Port	1
Ethernet (RJ45) Port	1 (10/100/1000M)
Built-in Wi-Fi	2.4G & 5G Dual Band Wi-Fi 2T2R / IEEE 802.11 b/g/n/ac
TF Card Reader	Yes (supports 1~32GB)
HDMI Output	Yes (4K Resolution)
Supported Internet Services	Google Play Store

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Next website. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: Next

Website: [Next Official Store \(Amazon\)](#)