

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Furologee](#) /

› [Furologee 47" Computer Desk User Manual](#)

Furologee B0BYSFN7N9

Furologee 47" Computer Desk User Manual

Model: B0BYSFN7N9

Brand: Furologee

1. INTRODUCTION

Thank you for choosing the Furologee 47" Computer Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure you get the most out of your new desk. Please read this manual thoroughly before assembly and use, and keep it for future reference.

2. IMPORTANT SAFETY INFORMATION

WARNING:

This desk is intended for adult and teen use. Ensure it is properly assembled and anchored to the floor for stability. Do not exceed the maximum weight recommendation of 150 pounds to prevent tipping or damage. Keep small parts away from children during assembly. Always use the provided tools and follow instructions carefully to avoid injury or damage to the product.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer service immediately.

- Desk tabletop with integrated power outlets and USB ports
- Metal frame components
- 2 Movable Monitor Stands
- Fabric File Cabinet
- Storage Drawer
- Flexible CPU Stand
- 2 Metal Side Hooks
- Assembly Hardware (screws, bolts, nuts, Allen wrench, screwdriver)
- Instruction Manual



Figure 3.1: Overview of all desk components and their respective dimensions.

4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward. Please follow the steps carefully. It is recommended to assemble the desk on a soft, clean surface to prevent scratches.

4.1. Preparation

- Unpack all components and lay them out on a clean, flat surface.
- Identify each part using the labels (A, B, C, etc.) and the hardware using the provided diagram.
- Ensure you have the included Allen wrench and screwdriver readily available.

4.2. Assembly Steps

1. **Assemble the Main Frame:** Connect the side frames to the crossbars using the specified screws. Do not fully tighten screws until all parts are aligned.
2. **Attach the Tabletop:** Carefully place the tabletop onto the assembled frame, aligning the pre-drilled holes.

Secure the tabletop with the appropriate screws.

3. **Install Monitor Stands:** Position the two movable monitor stands on the tabletop as desired. They are designed to be flexible for optimal screen placement.
4. **Assemble Storage Unit:** Construct the frame for the fabric file cabinet and storage drawer. Insert the fabric drawer and file cabinet into their designated slots.
5. **Attach CPU Stand:** The flexible CPU stand can be installed on either the inside or outside of the desk frame, or not assembled if not needed. Secure it in your preferred position.
6. **Add Side Hooks:** Attach the two metal side hooks to the desk frame for hanging headphones, backpacks, or other items.
7. **Final Tightening:** Once all components are in place and aligned, systematically tighten all screws to ensure the desk is sturdy and stable.



Figure 4.1: The Furologee computer desk fully assembled in a typical home office environment.



|| Flexible PC Tower

Install the pc tower on the inside/outside of the desk, or not assemble it according to your needs

Figure 4.2: Demonstrates the flexible placement of the PC tower stand, allowing for internal or external positioning.

Video 4.1: Official installation guide for the Furologee Desk with Power and Drawer, providing visual step-by-step assembly instructions.

5. OPERATING INSTRUCTIONS

5.1. Charging Station

The desk is equipped with a built-in charging station featuring 3 AC outlets (120V/12A) and 2 USB charging ports (5V/A2). Simply plug the desk's power cord into a wall outlet. You can then conveniently charge your phone, tablet, laptop, or power other devices directly from your desk.



47" Long Desk with Charging Station

3-Outlets and 2 USB Ports for smartphone, pc, laptop, etc.



3 AC Outlets
120V/12A



2 USB Ports
5V/A2



6.5FT
Power Cord

Figure 5.1: Detail of the integrated charging station with AC outlets and USB ports for convenient power access.

5.2. Movable Monitor Stands

The two monitor stands (each 18.9" x 7.1") are designed to be movable. You can adjust their position along the back of the desk to suit your ergonomic needs, raising your monitors to eye level to reduce neck and back strain. This also provides additional storage space underneath the monitors.

12 Movable Monitor Stands

Providing additional space for the monitor while reducing neck pain.



Figure 5.2: Demonstrates how the movable monitor stands improve ergonomics by raising screen height.

5.3. Storage and Organization

The desk includes a fabric file cabinet, a storage drawer, and two open shelves. Use these to organize your documents, office supplies, and personal items. The fabric file cabinet is suitable for letter/A4 size files, helping to keep your workspace tidy and dust-free.



Figure 5.3: The desk's integrated storage solutions, including the fabric file cabinet and storage drawer, for efficient organization.

Video 5.1: A demonstration of the computer desk's features, including the drawer, power outlet, and fabric file cabinet.

6. MAINTENANCE

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish. The E1 particleboard is waterproof and anti-scratch for easy cleaning.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Weight Distribution:** Distribute weight evenly across the desk surface and shelves to prevent strain on any single point.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Desk is wobbly/unstable	Screws are loose; uneven floor.	Tighten all assembly screws. Adjust the adjustable feet on the desk legs to level the desk on uneven surfaces.
Power outlets/USB ports not working	Desk power cord not plugged in; circuit breaker tripped.	Ensure the desk's power cord is securely plugged into a functioning wall outlet. Check your home's circuit breaker.
Drawers are stiff or not sliding smoothly	Misalignment; obstruction.	Ensure the fabric drawers are inserted correctly and nothing is obstructing their movement.

8. SPECIFICATIONS

Feature	Detail
Brand	Furologee
Model	B0BYSFN7N9
Product Dimensions	47.24" L x 18.9" W x 29.53" H
Color	Rustic Brown
Style	Country Rustic
Base Material	Metal
Finish Type	Wood (E1 Particleboard)
Special Features	Built-In Monitor Stand, Built-In USB Outlet, Fabric File Cabinet, Flexible CPU Stand, Adjustable Feet, 2 Metal Side Hooks
Power Outlets	3 AC Outlets (120V/12A)
USB Ports	2 USB Ports (5V/A2)
Monitor Stand Size	18.9" x 7.1" (each)
Weight Capacity	Up to 150 lbs (approx. 68 kg)

9. WARRANTY AND SUPPORT

Furologee provides customer service before and after purchase. If your items received are damaged, scratched, or missing parts, please contact us at any time, and we will provide you with satisfactory solutions within 24 hours. For further assistance or inquiries, please refer to the contact information provided with your purchase or visit the official Furologee store online.

- **Return Policy:** 30-day refund/replacement policy.
- **Protection Plans:** Optional 2-Year and 3-Year protection plans are available for purchase.

