
[Manuals.plus](#) /

› [Keebar](#) /

› Keebar Gooseneck Electric Kettle User Manual

Keebar XH-W081-GW

Keebar Gooseneck Electric Kettle User Manual

Model: XH-W081-GW

1. INTRODUCTION

Thank you for choosing the Keebar Gooseneck Electric Kettle. This manual provides important information for the safe and efficient operation of your new appliance. Please read it thoroughly before first use and retain it for future reference.



Image: The Keebar Gooseneck Electric Kettle in Matcha Green, featuring a wood-like grain finish handle and base.

EXTRA-SAFE TEMPERATURE CONTROLLER



Shut off promptly when the water reaches a boil



Boil Quickly



Auto-Off



Anti-Dry



Easy To Clean



1L



Stainless Steel



Image: The Keebar Electric Gooseneck Kettle shown in multiple color variations, part of the 'Universe Collection'.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or electric kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This kettle features an automatic shut-off function and boil-dry protection for enhanced safety.
- Ensure the lid is properly secured before boiling to prevent hot water or steam from escaping.
- The internal silicone lock is food-grade and designed to detect water temperature for auto-shutoff.



Image: Visual representation of the kettle's safety features: rapid boil, auto-off, anti-dry protection, and stainless steel construction.

NO PIPE – USER FRIENDLY

○ ● ○

The KEEBAR XH-W081 electric kettle steam pipe is specially designed inside the handle, which does not take up the volume inside the pot, making cleaning more convenient and safe, without worrying about scratching your hands.



Image: A diagram explaining the steam reduction design and automatic shut-off feature of the kettle.

3. PACKAGE CONTENTS

Your Keebar Gooseneck Electric Kettle package includes:

- 1 x Keebar Gooseneck Electric Kettle (0.8L capacity)
- 1 x Power Base
- 1 x User Manual (this document)

4. SETUP

1. **Unpack:** Carefully remove all packaging materials from the kettle and power base.
2. **Initial Cleaning:** Before first use, fill the kettle with water to the MAX line. Boil the water, then discard it. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a stable, flat, heat-resistant surface. Ensure the power cord is not dangling where it can be pulled or tripped over.
4. **Connect Power:** Plug the power base into a standard electrical outlet.

YOU DESERVE
A BETTER
MORNING COFFEE



Image: The Keebar Gooseneck Electric Kettle positioned on a kitchen counter, ready for use.

5. OPERATING INSTRUCTIONS

1. **Fill Kettle:** Open the lid and fill the kettle with fresh water. Do not fill below the MIN line or above the MAX line (0.8L). Overfilling may cause boiling water to spill out.
2. **Place on Base:** Place the kettle firmly onto the power base.

3. **Start Boiling:** Press the power switch located on the base or handle (depending on model variation) to begin the boiling process. The indicator light will illuminate.
4. **Automatic Shut-off:** The kettle will automatically turn off once the water reaches a rolling boil. The indicator light will extinguish.
5. **Pouring:** The gooseneck spout is designed for precise and controlled pouring, ideal for pour-over coffee or tea. Pour slowly and steadily.
6. **Re-boiling:** If you need to re-boil water immediately after it has boiled, wait a few seconds for the internal thermostat to reset before pressing the switch again.



○ ● ○

**MAKES YOU BE
A COFFEE MASTER**

**WOOD-LIKE GRAIN FINISH
HANDLE**

Image: A user demonstrating the precise pouring capability of the Keebar Gooseneck Electric Kettle for coffee brewing.

STEAM REDUCTION DESIGN & AUTO SHUT-OFF

○ ● ○

Inside the kettle is a small steam collector made of **food-grade** silicone that fixed 1 inch above the Max level line, through which steam goes into the pipe and induces boiling, thereby reducing steam release and preventing steam burns, while achieving automatic shut-off.



Image: A visual demonstrating the 0.8mm precise pouring feature of the kettle's gooseneck spout.

6. CLEANING & MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and optimal performance of your kettle.

- **Always unplug the kettle** from the power outlet and allow it to cool completely before cleaning.
- **Exterior Cleaning:** Wipe the exterior of the kettle and power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
- **Interior Cleaning:** The kettle is made from 100% stainless steel. For general cleaning, rinse the interior with water. For stubborn stains or mineral deposits (limescale), you can use a descaling solution or a mixture of vinegar and water. Fill the kettle with a 1:1 solution of white vinegar and water, let it sit for an hour (or boil for severe buildup), then rinse thoroughly several times.
- **Do not immerse** the kettle or power base in water or any other liquid.
- **Hand Wash Only:** This product is not dishwasher safe.
- The unique "no pipe" design inside the kettle makes cleaning easier and safer, preventing scratches.

Keebar

○ ● ○

ELECTRIC GOOSENECK KETTLE

The best grain, the finest roast, the most powerful flavor.



Image: An illustration highlighting the food-grade 304 stainless steel construction of the kettle's lid, spout, and interior.



Image: A diagram illustrating the "no pipe" interior design of the kettle, which simplifies cleaning.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in; power switch not pressed; kettle not properly seated on base; power outage.	Ensure plug is securely in outlet; press power switch; reseal kettle firmly on base; check household power.
Kettle turns off before boiling.	Insufficient water (boil-dry protection activated); mineral buildup.	Ensure water level is above MIN line; descale the kettle regularly.
Water leaks from spout or lid during boiling.	Kettle overfilled; lid not properly secured.	Do not fill above MAX line; ensure lid is firmly closed and correctly positioned.
Unusual noise during operation.	Mineral deposits (limescale) inside the kettle.	Descale the kettle.

8. SPECIFICATIONS

Brand: Keebar

Model Name: XH-W081-GW

Color: Matcha Green

Capacity: 0.8 Liters (approx. 0.8 Quarts)

Power: 1000W (Fast Boiling)

Material: 100% Stainless Steel (Food-grade 304)

Special Features: Boil Dry Protection, Automatic Shut-off, Precise Gooseneck Spout (0.8mm), Wood-like Grain Finish Handle

Product Dimensions: 8.38"L x 5.12"W x 10.53"H

Item Weight: 2.23 pounds

Care Instructions: Hand Wash

Country of Origin: China



Image: Detailed dimensions of the Keebar Gooseneck Electric Kettle.

9. WARRANTY & SUPPORT

Keebar offers a **1-year warranty** for this product. For any questions, concerns, or support needs, please do not hesitate to contact Keebar customer service. We are committed to providing 24/7 after-sales support.

For more information or to contact support, please visit the official Keebar store: [Keebar Official Store](#).