

[Manuals.plus](#) /

> [QUTWOB](#) /

> QUTWOB 52-inch Black Ceiling Fan with Remote Control (Model 52DY-1271BK) - Instruction Manual

QUTWOB 52DY-1271BK

QUTWOB 52-inch Black Ceiling Fan with Remote Control

MODEL: 52DY-1271BK

1. PRODUCT OVERVIEW

This manual provides instructions for the safe installation, operation, and maintenance of your QUTWOB 52-inch Black Ceiling Fan. This modern, 3-blade ceiling fan features a reversible DC motor and is designed for both indoor and outdoor use. It includes a remote control for convenient operation of its 6-speed settings and other functions.



Patio




Living room




Dining room


Image 1.1: The QUTWOB 52-inch ceiling fan is suitable for various indoor and outdoor spaces.



Living Room



Bedroom



Study Room



Dining Room



Corridor



Outdoor Patio

Image 1.2: Versatile installation options for different room types and outdoor patios.

2. SAFETY INFORMATION

Please read all instructions carefully before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- Ensure the power is disconnected at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.
- The mounting bracket must be securely fastened to a structural ceiling joist or outlet box rated for ceiling fan support.
- Do not bend the blade holders during installation or cleaning.
- Keep hands clear of the fan blades when the fan is operating.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- Ceiling Fan Motor Assembly
- 3 Fan Blades (ABS material)
- Downrods (various lengths: 5", 10", 20")
- Mounting Bracket
- Canopy
- Remote Control with Receiver
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual



Image 3.1: Main components of the ceiling fan, including downrods for adjustable height.

4. SETUP AND INSTALLATION

Installation of the QUTWOB ceiling fan is designed to be straightforward. Please refer to the detailed installation videos provided by the manufacturer for visual guidance.

4.1 Pre-Installation Steps

- Turn off power at the circuit breaker.
- Ensure the ceiling box is rated for ceiling fan support (at least 35 lbs).
- Select the appropriate downrod length for your ceiling height. The fan supports high, low, and angled ceilings (maximum 15°).

52" Adjustable Ceiling Fan




Image 4.1: Fan dimensions and compatibility with various ceiling types.

4.2 Assembly and Wiring

Follow the steps below and consult the installation videos for detailed visual instructions.

1. Attach the fan blades to the motor assembly using the provided screws.
2. Secure the chosen downrod to the motor assembly.
3. Mount the hanging bracket to the ceiling electrical box.
4. Hang the fan assembly from the mounting bracket.
5. Connect the electrical wires (live, neutral, ground) from the ceiling to the fan's receiver unit, then connect the receiver to the fan motor wires. Ensure all connections are secure.
6. Tuck the wiring neatly into the canopy and secure the canopy to the mounting bracket.

Your browser does not support the video tag.

Video 4.1: Official installation video demonstrating the assembly and wiring process.

Your browser does not support the video tag.

Video 4.2: Additional installation instructions for the ceiling fan.

5. OPERATING INSTRUCTIONS

Your QUTWOB ceiling fan is operated using the included remote control. Ensure the remote has working batteries.

5.1 Remote Control Functions




Image 5.1: Layout of the remote control for your QUTWOB ceiling fan.

- **Fan ON/OFF:** Press the power button to turn the fan on or off.
- **Speed Control (1-6):** Adjust the fan speed from 1 (lowest) to 6 (highest).
- **Forward/Reverse (F/R):** Changes the direction of blade rotation.
- **Timer Settings (1H, 4H, 8H):** Set the fan to automatically turn off after 1, 4, or 8 hours.
- **Natural Wind Mode:** Simulates a natural breeze by varying fan speeds.
- **Button Mute Function:** Silences the remote control's button press sounds.

5.2 Reversible DC Motor

The fan features a reversible DC motor, allowing for year-round comfort. Use the 'F/R' button on the remote to switch between modes.

- **Summer Mode (Counter-clockwise rotation):** Creates a downward airflow, producing a cooling effect.
- **Winter Mode (Clockwise rotation):** Creates an upward airflow, circulating warm air trapped near the ceiling.



Image 5.2: Reversible DC motor for optimal air circulation in summer and winter.



Image 5.3: Visual representation of summer and winter modes.

5.3 Quiet Operation and Energy Efficiency

The DC motor ensures quiet operation, with sound levels less than 30dB at maximum speed, providing a comfortable environment. It is also highly energy-efficient.

≤ 30dB Whisper Quiet at Minimum Speed

Give You a Quiet Comfortable Cool Environment

-  Low Noise
-  6 Wind Speeds
-  Timer Setting

Image 5.4: Fan features promoting quiet operation and multiple speed settings.




Image 5.5: The fan's energy efficiency compared to traditional models.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe the blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the power is off before cleaning.
- **Blade Inspection:** Periodically check the fan blades for any signs of damage or warping.
- **Tighten Screws:** Over time, screws may loosen. Periodically check and tighten all screws on the fan assembly and mounting bracket.

7. TROUBLESHOOTING

If you encounter issues with your QUTWOB ceiling fan, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power; Loose wiring; Remote control issue	Check circuit breaker; Verify wiring connections; Replace remote batteries or re-pair remote.
Fan does not move enough air	Incorrect rotation direction; Fan blades installed backwards	Check fan direction (use F/R button for summer/winter mode); Ensure blades are installed correctly.
Fan is noisy	Loose screws; Unbalanced blades	Tighten all screws; Check blade balance and adjust if necessary.
Remote control not working	Dead batteries; Receiver interference	Replace batteries; Ensure no obstructions between remote and receiver.

If some parts of the ceiling fan are damaged or lost during installation or transportation, please contact the

seller on the order page for a replacement.

8. SPECIFICATIONS

- **Brand:** QUTWOB
- **Model Name:** 52DY-1271BK
- **Color:** Black
- **Electric Fan Design:** Ceiling Fan
- **Power Source:** Corded Electric
- **Style:** No lights
- **Product Dimensions:** 52"D x 52"W x 15.7"H
- **Room Type:** Bedroom, Dining Room, Dorm Room, Living Room
- **Special Feature:** Adjustable Height, Adjustable Tilt
- **Recommended Uses For Product:** Air Circulation
- **Wattage:** 35 watts
- **Finish Type:** Matte Black
- **Number of Blades:** 3
- **Blade Length:** 65 Centimeters
- **Voltage:** 120V
- **Switch Type:** Remote
- **Included Components:** Remote
- **Indoor/Outdoor Usage:** Indoor, Outdoor
- **Control Method:** Remote
- **Efficiency:** High Efficiency
- **Is Cordless?:** No
- **Number of Power Levels:** 6
- **Size:** 52 inch
- **Item Weight:** 12.17 pounds
- **Mounting Type:** Ceiling Mount

9. WARRANTY AND SUPPORT

QUTWOB provides **12 months of trouble-free after-sales service** for the entire machine. If you have any problems during installation or use, please feel free to contact us directly through your order page for assistance.