



[Manuals.plus](#) /

> [TCL](#) /

> User Manual for TCL Tab 10 Series Tablet

## TCL TCL tab 10 SM6125

# User Manual for TCL Tab 10 Series Tablet

Model: TCL tab 10 SM6125

## 1. INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your TCL Tab 10 Series Tablet. Please read this manual thoroughly before using the device and keep it for future reference. Your TCL Tab 10 Series Tablet is designed for a wide range of uses, from entertainment to productivity, featuring a vibrant display and robust performance.



Image 1.1: Front and back view of the TCL Tab 10 Series Tablet, showcasing its sleek design and camera placement.

## 2. WHAT'S IN THE BOX

---

Upon opening the package, please ensure all items are present and in good condition:

- TCL Tab 10 Series Tablet

- 1X Type-C Cable
- Quick Start Guide (not included in this digital manual)
- Warranty Card (not included in this digital manual)

### 3. INITIAL SETUP

---

#### 3.1 Charging the Tablet

Before first use, fully charge your tablet. Connect the provided Type-C cable to the tablet's charging port and the other end to a compatible USB power adapter (not included) or a computer's USB port.




Image 3.1: Illustration of the tablet being charged, highlighting the 8000mAh battery and 18W fast charge capability.

#### 3.2 Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the TCL logo appears.

- **To Power Off:** Press and hold the Power button until the power options menu appears, then select "Power off".

### 3.3 Initial Configuration

Follow the on-screen prompts to complete the initial setup, including selecting your language, connecting to a Wi-Fi network, and signing in with your Google account.

## 4. OPERATING YOUR TABLET

---

### 4.1 Display and Navigation

The TCL Tab 10 features a 10.36-inch FHD+ display with 2K resolution (2000 x 1200 pixels). Navigation is primarily touch-based. Swipe, tap, and pinch to interact with the interface.



Image 4.1: The tablet's 10.36-inch 2K FHD+ display, showcasing the NXTVISION technology for eye comfort and vivid visuals.

### 4.2 Storage and Memory

Your tablet comes with 256GB of built-in ROM storage and 6GB of RAM. Storage can be expanded up to 512GB using a microSD card (sold separately).

# Keep All of What You Like

**6GB+256GB**, up to **512GB** with MicroSD Card

6GB  
RAM  
ROM  
256GB



\*microSD card is sold separately

Image 4.2: Visual representation of the tablet's 6GB RAM and 256GB ROM, expandable with a microSD card.

## 4.3 Camera Functions

The tablet is equipped with a 13MP rear camera with LED flash and an 8MP front-facing camera. Use the Camera app to capture photos and videos.

# Battery For All-Day Fun

**8000mAh** Battery, **18W** Fast Charge



Image 4.3: Depiction of the tablet's front 8MP and rear 13MP cameras, ideal for video calls and capturing moments.

## 4.4 Performance and Multitasking

Powered by a Qualcomm Snapdragon 665 Octa-Core processor and running Android 11, the tablet offers smooth multitasking and app performance.

# Clear Video Calls\*

Enjoy Video Calls with a Powerful Front-facing 8MP Camera

13MP  
Rear

Front  
8MP



\*This tablet only supports Type-C audio port.

Image 4.4: Illustrates the Qualcomm Snapdragon 665 Octa-Core processor and Android 11 operating system, enabling smooth performance.

## 5. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive cleaners or solvents.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the tablet regularly.
- **Software Updates:** Keep your tablet's software updated to ensure optimal performance and security.

## 6. TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Tablet does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
Wi-Fi connection issues.	Restart the tablet and your Wi-Fi router. Check if other devices can connect to the network. Forget and reconnect to the Wi-Fi network on the tablet.
Apps are slow or crashing.	Close background apps. Clear app cache (Settings > Apps > [App Name] > Storage > Clear cache). Restart the tablet. Ensure sufficient storage space is available.
Screen is unresponsive.	Perform a forced restart by holding the Power button for approximately 10-15 seconds.

## 7. TECHNICAL SPECIFICATIONS

---

Feature	Detail
Brand	TCL
Model Name	TCL tab 10
Item Model Number	TCL tab 10 SM6125
Operating System	Android 11
Screen Size	10.36 inches
Max Screen Resolution	2000 x 1200 Pixels (2K FHD+)
Processor	Qualcomm Snapdragon 665 Octa-Core (up to 2.0 GHz)
RAM	6 GB
Memory Storage Capacity	256 GB (expandable up to 512GB with microSD)
Graphics Coprocessor	Adreno 610
Wireless Type	802.11a/b/g/n/ac
Rear Webcam Resolution	13 MP
Front Webcam Resolution	8 MP
Battery Life (Average)	Up to 8 hours online video streaming / 5 hours online game play (8000mAh)
Item Weight	1.89 pounds
Product Dimensions	10 x 8 x 0.5 inches
Color	Space Gray

## 8. WARRANTY AND SUPPORT

---

This product is sold as a renewed item. For specific warranty information, please refer to the documentation provided by

the seller (eKings) or Amazon Renewed. Typically, Amazon Renewed products come with a 90-day refund/replacement policy.

For technical support or service inquiries, please contact the seller directly or refer to the official TCL support channels available on their website. Keep your purchase receipt and product serial number handy when seeking support.

**Seller Information:** eKings (Fulfilled by Amazon)

**Amazon Renewed Policy:** [Visit Amazon Renewed Store](#)

