



Manuals.plus /

› SHW /

› SHW 62-Inch Electric Height Adjustable Standing Desk User Manual

SHW OD-95H-N

SHW 62-Inch Electric Height Adjustable Standing Desk User Manual

Model: OD-95H-N

PRODUCT OVERVIEW

The SHW 62-Inch Electric Height Adjustable Standing Desk with Monitor Riser and Drawer in Walnut finish is designed to provide a versatile and ergonomic workspace. This desk allows for effortless transition between sitting and standing positions, promoting a healthier work environment.

Key Features:

- Electric Height Adjustment: Smoothly adjust the desk height from 28 inches to 45 inches.
- Spacious 62-Inch Work Surface: Ample space for multiple monitors and office essentials.
- Built-In Monitor Riser: Elevates monitors to eye level, reducing neck strain.
- Integrated Storage Drawer: Provides convenient storage for small items.
- Durable Construction: Features a metal base and engineered wood top with a laminated finish.

SAFETY INFORMATION

WARNING: This product can expose you to chemicals including formaldehyde, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

- Always follow the assembly instructions carefully.
- Keep fingers and other body parts away from moving parts during operation.
- Do not use the desk if it appears damaged or malfunctioning.
- Always ensure the desk is properly anchored to the floor to prevent tipping.

SETUP AND ASSEMBLY

Assembly of the SHW Electric Height Adjustable Standing Desk requires two people for optimal safety and ease. Please

ensure all components are present before beginning assembly.

Components Included:

- Cable Basket X 1
- Hook X 2
- Monitor Riser X 1
- Under-Desk Drawer Organizer X 1
- Under-Riser Mesh Drawer X 1
- iPad/iPhone holder X 2

Refer to the detailed assembly guide provided in the product packaging for step-by-step instructions. Ensure all connections are secure before use.



Figure 1: Product Dimensions. This diagram illustrates the overall dimensions of the desk, including its adjustable height range and surface area.

OPERATING INSTRUCTIONS

Electric Height Adjustment:

The desk features an electric motor for smooth height adjustments. Use the control panel located on the desk to raise or lower the desktop.

- **Up/Down Buttons:** Press and hold the up or down arrow buttons to continuously adjust the desk height. Release the button to stop at the desired height.
- **Memory Presets:** The control panel includes memory preset buttons (1, 2, 3, 4). To save a height setting, adjust the desk to your preferred height, then press and hold one of the preset buttons until the display flashes or beeps, indicating the height is saved. To recall a saved height, simply press the corresponding preset button.



Figure 2: Desk in use with accessories. This image demonstrates the desk's functionality with multiple devices and organized accessories.



Figure 3: Monitor Riser and Drawer Detail. A closer look at the monitor riser and the pull-out storage drawer, illustrating their design and utility.

MAINTENANCE

To ensure the longevity and optimal performance of your SHW Electric Height Adjustable Standing Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Motor Care:** The electric motor is designed for durability. Avoid overloading the desk beyond its weight capacity. Do not obstruct the movement of the desk legs during adjustment.
- **Cable Management:** Utilize the included cable basket to keep wires organized and prevent them from interfering with the desk's movement.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your SHW Electric Height Adjustable Standing Desk, refer to the following common troubleshooting tips:

- **Desk Not Moving:**

- Check if the power cord is securely plugged into both the desk and a working electrical outlet.
- Ensure there are no obstructions preventing the desk from moving up or down.
- If the control panel displays an error code, consult the full manual for specific error interpretations.

- **Uneven Movement:**

- Verify that the desk is placed on a level surface.
- Check that all leg components are properly assembled and tightened.

- **Noise During Operation:**

- A slight motor hum is normal. Excessive or unusual noises may indicate an issue. Ensure no cables or objects are caught in the moving parts.

For persistent issues or complex problems, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	SHW
Model Number	OD-95H-N
Product Dimensions (D x W x H)	25.6"D x 62"W x 28"H
Adjustable Height Range	28 Inches (Min) to 45 Inches (Max)
Color	Walnut
Style	Modern
Base Material	Metal
Top Material Type	Engineered Wood
Finish Type	Laminated
Special Features	Adjustable Height, Ergonomic, Memory Preset
Number of Drawers	2 (one integrated, one mesh under-riser)
Required Assembly	Yes
Recommended People for Assembly	2

WARRANTY INFORMATION

The SHW 62-Inch Electric Height Adjustable Standing Desk comes with a **Limited Warranty**. For specific details regarding coverage, duration, and terms, please refer to the warranty documentation included with your product or contact SHW customer support.

CUSTOMER SUPPORT

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact SHW customer support. You can find contact information on the official SHW website or through your purchase platform.

Additional resources may be available on the SHW Store on Amazon.