

## oiakus Handheld Garment Steamer

# oiakus Handheld Garment Steamer User Manual

Model: Handheld Garment Steamer

## 1. IMPORTANT SAFETY INSTRUCTIONS

---


Please read all instructions carefully before using the appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious personal injury.

- Always unplug the steamer from the electrical outlet when filling with water, cleaning, or when not in use.
- Do not immerse the steamer in water or other liquids.
- Use only distilled or demineralized water to prevent mineral buildup.
- Keep the steamer away from children and pets.
- Never direct steam at people, animals, or electrical appliances. Steam is hot and can cause burns.
- Do not operate the steamer with a damaged cord or plug.
- A slight steam emission may occur from the steam chamber after heating if water remains from previous use. This is normal and not a defect.
- A new steam brush may emit an odor during initial use. This is normal and will dissipate after a few uses as the internal components volatilize. Ensure good ventilation during initial use.

## 2. PRODUCT OVERVIEW AND COMPONENTS

---

Familiarize yourself with the parts of your oiakus Handheld Garment Steamer for optimal use.



**Image 2.1:** Labeled diagram showing the main components of the oiakus Handheld Garment Steamer, including the transparent water tank, power indicator, steam button, and removable brush head.



**Image 2.2:** Close-up view of the steamer's transparent water tank, steam button, and power indicator light, highlighting the user interface.

- **Transparent Water Tank:** Allows easy monitoring of water level.
- **Steam Button:** Press and hold to release steam. Release to stop.
- **Power Indicator Light:** Illuminates when the steamer is heating and ready for use.
- **Brush Head:** Removable attachment for brushing clothes and assisting with wrinkle removal.
- **Steam Outlet Holes:** Five-hole design for stable and large steam output.

### 3. SETUP

Follow these steps to prepare your garment steamer for first use.

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Water Tank:** Ensure the steamer is unplugged. Open the water tank cap and fill the transparent water tank with distilled or demineralized water using the provided measuring cup. Do not overfill. Close the cap securely.
3. **Attach Brush Head (Optional):** If desired, attach the brush head accessory to the steamer's nozzle. This is useful for thicker fabrics or for removing lint.
4. **Initial Use Preparation:** For the first use, or if the steamer has not been used for a long time, allow it to heat up and steam for a few minutes to clear any residue and ensure consistent steam output.

## 4. OPERATING INSTRUCTIONS

---

Learn how to effectively use your oiakus Handheld Garment Steamer for various applications.



**Image 4.1:** The steamer is suitable for a variety of fabrics including silk, cotton, wool, polyester, and linen, making it a versatile tool for home furnishing and clothing care.

## Ironing upgrade is not just ironing



**Image 4.2:** This diagram illustrates the versatility of the steamer, showing its use for ironing clothes, pressing seats, ironing curtains, pressing quilts, sterilizing sofas, and room humidification.

1. **Power On:** Plug the steamer into a suitable electrical outlet. The power indicator light will illuminate, indicating the steamer is heating up.
2. **Wait for Heating:** Wait for the power indicator light to turn off, which signifies that the steamer has reached its operating temperature and is ready to produce steam.
3. **Steaming Technique:** Hold the steamer upright. Press and hold the steam button to release steam. Move the steamer slowly over the fabric, keeping it a few inches away. For optimal results, maintain a spray interval of 2-3 seconds. Spraying too quickly may reduce the ironing effect as the temperature may not be sufficient.
4. **Fabric Suitability:** The steamer is suitable for most fabrics, including organic fabrics, cotton, wool, polyester, plush, silk, fiber, nylon, velvet, and linen.
5. **Versatile Use:** Use the steamer to remove wrinkles from clothes (suits, shirts, T-shirts), refresh household items like bed sheets, tablecloths, curtains, sofas, and even plush toys. The brush attachment can help penetrate thicker fabrics and remove lint.
6. **Finishing:** Once steaming is complete, release the steam button and unplug the steamer. Allow the garment to cool and dry before wearing or storing.

## 5. MAINTENANCE AND CARE

---

Proper maintenance ensures the longevity and optimal performance of your steamer.

- **Empty Water Tank:** After each use, ensure the steamer is unplugged and cooled. Empty any remaining water from the tank to prevent mineral buildup and odors.

- **Cleaning:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling (Periodically):** If you notice reduced steam output or mineral residue, descale the steamer by filling the tank with a mixture of equal parts white vinegar and water. Let it sit for 30 minutes, then steam until the tank is empty. Rinse thoroughly with clean water.
- **Storage:** Store the steamer in a cool, dry place, away from direct sunlight and moisture. Ensure the power cord is neatly wrapped and not kinked.

## 6. TROUBLESHOOTING

---

Refer to this section for solutions to common issues.

- **No Steam or Low Steam:**
  - Check if the water tank is empty. Refill if necessary.
  - Ensure the steamer is properly plugged in and the power indicator light has turned off, indicating it's ready.
  - Mineral buildup may be blocking steam vents. Perform descaling as described in the Maintenance section.
- **Water Leakage:**
  - A slight steam emission with some water droplets from the steam chamber after heating is normal if water remains from previous use.
  - Ensure the water tank cap is securely closed.
  - Do not tilt the steamer excessively during use.
- **Unpleasant Odor During First Use:**
  - This is normal for new appliances due to the volatilization of internal components. The odor will dissipate after a few uses. Ensure good ventilation.
- **Poor Ironing Effect:**
  - Ensure you wait for the power indicator light to turn off before steaming.
  - Maintain a spray interval of 2-3 seconds. Spraying too quickly will not allow the steam to reach optimal temperature for wrinkle removal.
  - For stubborn wrinkles, pass the steamer over the area multiple times.

## 7. SPECIFICATIONS

---

Technical details for your oiakus Handheld Garment Steamer.



**Image 7.1:** Diagram illustrating the physical dimensions of the oiakus Handheld Garment Steamer and its brush attachment, showing measurements in centimeters.

- **Model:** Handheld Garment Steamer
- **Brand:** oiakus
- **Material:** PC + ABS
- **Dimensions:** Approximately 33cm x 7cm x 9cm (Length x Width x Height)
- **Power:** 850W
- **Product Benefits:** Removes wrinkles, sanitizes, softens fabrics, refreshes garments, saves time.
- **Color:** Green (variant shown)

## 8. WARRANTY AND SUPPORT

---

Specific warranty details are not provided in the product information. For warranty claims, technical support, or further assistance, please contact the manufacturer or your retailer directly. Keep your purchase receipt as proof of purchase.