

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [BARBERBOSS](#) /

› BarberBoss QR-2088 T-Blade Hair Trimmer User Manual

## BARBERBOSS QR-2088

# BarberBoss QR-2088 T-Blade Hair Trimmer User Manual

Premium Grooming Kit for Men

## 1. PRODUCT OVERVIEW

The BarberBoss QR-2088 T-Blade Hair Trimmer is a professional-grade grooming tool designed for precise hair cutting and detailing. Its compact size, powerful motor, and versatile attachments make it ideal for achieving a neat and well-groomed appearance at home. This kit provides everything necessary for a complete grooming experience.




Image 1.1: BarberBoss QR-2088 T-Blade Trimmer highlighting its key features.

## 2. WHAT'S IN THE BOX

---

Your BarberBoss QR-2088 Grooming Kit includes the following components:

- BarberBoss QR-2088 T-Blade Hair Trimmer
- 3 Guide Combs (0.5 mm, 1 mm, 2 mm)
- USB Charging Cable
- Cleaning Brush



*Image 2.1: All components included in the BarberBoss QR-2088 grooming kit.*

## 3. SAFETY INSTRUCTIONS

---

Please read all safety instructions carefully before using the BarberBoss QR-2088 T-Blade Hair Trimmer to ensure safe operation and prevent injury or damage.

- Keep the appliance dry. Do not immerse the entire unit in water. The blade head can be rinsed under running water for cleaning, but ensure the main body remains dry.
- Do not use the trimmer near bathtubs, showers, basins, or other vessels containing water.

- Always unplug the trimmer from the power source before cleaning or performing maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not use the trimmer if the blade or cord is damaged. Contact customer support for assistance.
- Use only the provided USB charging cable.

## 4. SETUP

---

### 4.1 Charging the Trimmer

Before first use, fully charge the trimmer. A full charge provides up to 180 minutes of continuous operation.

1. Connect the small end of the USB charging cable to the charging port on the bottom of the trimmer.
2. Connect the larger end of the USB cable to a standard USB power adapter (not included) or a computer USB port.
3. The charging indicator light will illuminate (if present) to show that the trimmer is charging.
4. Once fully charged, disconnect the USB cable.



*Image 4.1: The BarberBoss QR-2088 T-Blade Hair Trimmer connected for USB charging.*

### 4.2 Attaching Guide Combs

To achieve desired cutting lengths, attach one of the three guide combs (0.5 mm, 1 mm, 2 mm).

1. Ensure the trimmer is turned off.
2. Align the guide comb with the trimmer blade and slide it firmly into place until it clicks.
3. To remove, gently pull the comb away from the blade.

## 5. OPERATING INSTRUCTIONS

---

The BarberBoss QR-2088 T-Blade Trimmer is designed for precise grooming of hair and facial hair.

## 5.1 Basic Trimming

1. Ensure your hair is clean and dry.
2. Select the desired guide comb (0.5mm, 1mm, or 2mm) and attach it securely. For closest trim, use without a comb.
3. Turn on the trimmer by pressing the power button.
4. Hold the trimmer with the blade flat against the skin and move it slowly against the direction of hair growth.
5. Use smooth, even strokes for consistent results.

## 5.2 Precision Detailing

The T-blade design is excellent for creating sharp lines and intricate designs.

1. Remove any guide combs for precision work.
2. Hold the trimmer at an angle to define hairlines, necklines, or beard edges.
3. Use light pressure and short, controlled strokes for detailed areas.



*Image 5.1: The BarberBoss QR-2088 T-Blade Hair Trimmer being used for detailing.*



*Image 5.2: Close-up of the trimmer's precision capabilities.*

## 6. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the life of your trimmer.

### 6.1 Cleaning the Blade

1. Turn off the trimmer and disconnect it from any power source.
2. Use the included cleaning brush to brush away loose hairs from the blade and inside the trimmer head.
3. For a more thorough clean, the blade head can be carefully rinsed under running water. **Do not submerge the entire trimmer body.**
4. Allow the blade to air dry completely before reattaching or storing the trimmer.



*Image 6.1: Rinsing the T-blade under water for cleaning.*



Image 6.2: The trimmer blade being cleaned with water.

## 6.2 Storage

Store the trimmer in a cool, dry place, away from direct sunlight and moisture. Ensure it is clean and dry before storing.

## 7. TROUBLESHOOTING

If you encounter any issues with your BarberBoss QR-2088 T-Blade Hair Trimmer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer fully using the USB cable.
Poor cutting performance.	Blades are clogged with hair.	Clean the blades thoroughly with the cleaning brush.
Trimmer makes unusual noise.	Hair caught in the motor or blade mechanism.	Turn off and clean the trimmer. If the noise persists, contact customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	BARBERBOSS
Model Number	QR-2088
Power Source	Battery Powered (Built-in Rechargeable)
Blade Material	Metal
Special Feature	USB Charging, Wireless USB Connection
Battery Life	Up to 180 minutes
Guide Combs	0.5 mm, 1 mm, 2 mm
Color	Blue
Target Audience	Men
Package Dimensions	18.9 x 15 x 7.6 cm
Weight	340 grams
Country of Origin	China

## 9. WARRANTY AND SUPPORT

BarberBoss is committed to providing high-quality personal care products. While specific warranty details are not provided in this manual, we stand by the quality of our products.



*Image 9.1: BarberBoss 100% Guarantee.*

For any questions, concerns, or support needs regarding your BarberBoss QR-2088 T-Blade Hair Trimmer, please contact BarberBoss customer service through the retailer's platform or the official BarberBoss website. Please have your product model number (QR-2088) and purchase information ready when contacting support.