

[Manuals.plus](#) /

> [Devoko](#) /

> Devoko Gaming Desk User Manual

Devoko 2TG

Devoko Gaming Desk User Manual

Model: 2TG | Dimensions: 140 × 60 cm

Brand: Devoko

INTRODUCTION

This user manual provides detailed instructions for the assembly, operation, and maintenance of your Devoko Gaming Desk. Please read this manual thoroughly before assembly and use to ensure proper setup and to maximize the lifespan of your product. This desk is designed to provide a comfortable and efficient workspace for gaming and general computer use.

SAFETY INFORMATION

To prevent injury or damage to the product, please observe the following safety precautions:

- Ensure all components are present and undamaged before beginning assembly.
- Assemble the desk on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly, as this may strip threads or damage components.
- Keep small parts and packaging materials away from children and pets.
- Do not exceed the maximum weight capacity of the desk. While not explicitly stated, distribute weight evenly.
- Avoid placing hot items directly on the desk surface without protection.
- Do not stand or sit on the desk.

PACKAGE CONTENTS

Verify that all the following components are included in your package:

- Desk tabletop sections (typically 2 or 3 sections for 140cm length)
- Desk legs (2)
- Support beams/frames

- Headphone hook
- Cup holder
- Large mouse pad
- Assembly hardware (screws, bolts, washers, Allen wrench)
- Instruction manual (this document)



Image: Devoko Gaming Desk with included accessories like headphone hook and cup holder.



Image: The large mouse pad included with the desk, showing its dimensions (80cm x 60cm).

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for certain steps.

- 1. Prepare the Workspace:** Clear an open area and lay down a soft cloth or cardboard to protect the desk components and your floor during assembly.
- 2. Attach Leg Frames to Support Beams:** Connect the horizontal support beams to the vertical leg frames using the provided screws and the Allen wrench. Ensure all connections are secure but do not fully tighten yet.
- 3. Assemble Tabletop Sections:** If your tabletop comes in multiple sections, align and connect them using the provided connectors and screws. The 140cm desk typically has two main tabletop sections.
- 4. Attach Tabletop to Frame:** Carefully place the assembled tabletop upside down on your protected surface. Align the pre-drilled holes on the tabletop with the holes on the leg frames and support beams. Secure the tabletop to the frame using the appropriate screws. Now, fully tighten all screws from previous steps, ensuring the desk is stable.
- 5. Install Accessories:**
 - **Headphone Hook:** Attach the headphone hook to the desired side of the desk using the designated mounting point.
 - **Cup Holder:** Attach the cup holder to the desired side of the desk.
- 6. Place Mouse Pad:** Unroll the large mouse pad and place it on the desk surface.
- 7. Final Check:** Once assembled, gently lift and move the desk to its desired location. Check all screws again to ensure they are tight and the desk is stable and level.



Image: Overview of the Devoko Gaming Desk showing its dimensions (140cm x 60cm x 75cm) and features like cable management holes.



Image: Close-up view of the integrated headphone hook, cup holder, and cable management grommets on the Devoko Gaming Desk.

OPERATING INSTRUCTIONS

The Devoko Gaming Desk is designed for straightforward use. Here are some guidelines for optimal experience:

- **Ergonomic Design:** The desk features an ergonomic curved front edge, designed to provide a comfortable resting position for your arms during extended use. Position yourself centrally to benefit from this design.
- **Cable Management:** Utilize the two integrated cable management grommets on the tabletop to route your computer and peripheral cables neatly, keeping your workspace organized and clutter-free.
- **Accessory Use:** The headphone hook and cup holder are designed for convenience. Use the headphone hook to store your headset when not in use, and the cup holder to securely hold your beverage, preventing spills on your electronics.
- **Mouse Pad:** The large, included mouse pad provides a smooth and consistent surface for your mouse, enhancing precision and comfort during gaming or work.

Plateau en fibre de carbone •
Facile à nettoyer

• Plateau ergonomique
Plus de confort




Image: Close-up of the desk surface highlighting the carbon fiber texture and the ergonomic curved edge for enhanced comfort.

• Des tables au design ergonomique




Image: Top-down view illustrating the ergonomic design of the desk, showing how it accommodates monitor arms and provides ample space for peripherals.

MAINTENANCE AND CARE

Proper care will ensure the longevity and appearance of your Devoko Gaming Desk:

- **Cleaning the Surface:** The carbon fiber textured surface is water-resistant and easy to clean. Use a soft, damp cloth with mild soap and water to wipe down the surface. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Wipe up spills immediately to prevent any potential damage, although the surface is designed to be water-resistant.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain desk stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or material degradation over time.
- **Weight Distribution:** Distribute heavy items evenly across the desk surface to prevent stress on any single point.

TROUBLESHOOTING

If you encounter any issues with your Devoko Gaming Desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose screws or uneven floor.	Ensure all assembly screws are fully tightened. Adjust the leveling feet (if present) on the bottom of the legs to compensate for uneven flooring.
Parts do not align during assembly.	Incorrect orientation of parts or screws overtightened prematurely.	Review the assembly instructions carefully. Loosen any previously tightened screws to allow for adjustment, then realign and retighten.
Scratches on the desk surface.	Sharp objects or abrasive cleaning.	Use coasters for drinks and avoid dragging sharp objects across the surface. Clean with soft cloths only. Minor scratches may be less visible due to the carbon fiber texture.

SPECIFICATIONS

- **Brand:** Devoko
- **Model Number:** 2TG
- **Color:** Black
- **Dimensions (L x W x H):** 140 cm x 60 cm x 75 cm (55.1 x 23.6 x 29.5 inches)
- **Product Weight:** 27 Kilograms (approx. 59.5 lbs)
- **Material:** Carbon Fiber (tabletop), Metal (frame)
- **Special Features:** Ergonomic design, Cable Management Grommets, Headphone Hook, Cup Holder, Large Mouse Pad
- **Assembly Required:** Yes



Image: Detailed dimensions of the Devoko Gaming Desk, showing length, width, and height.

CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or troubleshooting not covered in this manual, please contact Devoko customer service. Refer to your purchase documentation for specific contact details or visit the official Devoko website.

Devoko is committed to customer satisfaction. An installation manual is included with the product to facilitate assembly.