

Devoko 2TG

Devoko Gaming Desk 180cm x 60cm Instruction Manual

Model: 2TG

1. INTRODUCTION

Thank you for choosing the Devoko Gaming Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new gaming desk. Please read these instructions carefully before beginning assembly and retain them for future reference. This desk is designed to provide a comfortable and efficient workspace for gaming and computing activities.

2. SAFETY INFORMATION

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the desk. Refer to the 'Specifications' section for weight limits.
- Keep small parts away from children to avoid choking hazards.
- Avoid placing hot items directly on the desk surface without protection.
- Do not stand or sit on the desk.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact Devoko customer support.

- Desk Top Panels (3 sections)
- Desk Legs (2)
- Support Beams and Brackets
- Cup Holder
- Headphone Hook
- Large Mouse Pad
- Assembly Hardware (screws, bolts, washers, Allen wrench, screwdriver)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately one hour for a single person. It is recommended to have a second person for easier handling of larger components.

1. **Unpack and Organize:** Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches. Group similar hardware together.
2. **Attach Support Beams:** Secure the main support beams to the desk leg frames using the provided hardware. Ensure all connections are firm but do not overtighten initially.
3. **Assemble Desk Top:** The desk top consists of three sections. Carefully align and attach these sections to the support frame. Pay close attention to the orientation of the ergonomic curve. When tightening screws into the tabletop, apply gentle pressure to avoid damaging the carbon fiber surface or underlying material. Stop tightening once you feel resistance.
4. **Install Legs:** Attach the assembled leg frames to the desk top. Ensure the legs are stable and level.
5. **Attach Accessories:** Install the cup holder and headphone hook to the designated locations on the desk frame. These are typically mounted on the side edges.
6. **Final Tightening:** Once the desk is fully assembled and stable, go back and securely tighten all screws and bolts. Do not overtighten.
7. **Place Mouse Pad:** Position the large mouse pad on the desk surface as desired.




Figure 4.1: Fully assembled Devoko Gaming Desk, showcasing its spacious design and accessory placement.

5. OPERATING INSTRUCTIONS

Your Devoko Gaming Desk is designed for optimal comfort and functionality. Here's how to make the most of its features:

- **Ergonomic Design:** The desk features an ergonomic curved edge designed to provide comfortable arm and wrist support during extended use. Position yourself centrally to benefit from this design.
- **Spacious Surface:** The 180cm x 60cm carbon fiber tabletop provides ample space for multiple monitors, keyboards, mice, and other peripherals.
- **Cable Management:** Utilize the integrated cable pass-through grommets to route and organize your cables, keeping your workspace tidy and clutter-free.
- **Cup Holder:** Use the attached cup holder to securely store your beverages, preventing spills on your equipment.
- **Headphone Hook:** Hang your gaming headset on the dedicated hook when not in use, keeping it easily accessible and off the desk surface.



Figure 5.1: Detail of the practical accessories: cup holder, headphone hook, and cable pass-throughs.

• Des tables au design ergonomique




Figure 5.2: The ergonomic design of the desk surface, providing comfort and space for various setups.

6. MAINTENANCE

To ensure the longevity and appearance of your Devoko Gaming Desk, follow these simple maintenance guidelines:

- **Cleaning the Surface:** The carbon fiber surface is waterproof and scratch-resistant. Wipe the desk surface regularly with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the finish.
- **Hardware Check:** Periodically inspect all screws and bolts to ensure they remain tight. Re-tighten any loose hardware to maintain stability.
- **Avoid Excessive Moisture:** While the surface is water-resistant, avoid prolonged exposure to liquids. Clean up spills immediately.
- **Protect from Heat:** Use coasters or protective pads under hot items to prevent potential damage to the desk surface.



Figure 6.1: The durable carbon fiber surface is easy to clean and maintain.

7. TROUBLESHOOTING

If you encounter any issues with your Devoko Gaming Desk, refer to the following common problems and solutions:

- **Desk is Unstable/Wobbly:**
 - Ensure all assembly screws and bolts are fully tightened.
 - Check that the desk is placed on a level surface. Adjust the leveling feet (if present) on the bottom of the legs.
- **Parts Do Not Align During Assembly:**
 - Double-check the instruction manual to ensure you are using the correct parts for each step and that they are oriented correctly.
 - Loosen all screws slightly, adjust the parts into alignment, then re-tighten.

• **Scratches on Surface:**

- While the carbon fiber surface is scratch-resistant, it is not scratch-proof. Avoid dragging sharp objects across the surface.
- For minor scratches, specialized carbon fiber repair kits may be available, but consult customer support first.

If the problem persists or is not listed here, please contact Devoko customer support for assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Devoko
Model Number	2TG
Color	Black
Dimensions (L x W x H)	180 cm x 60 cm x 75 cm
Material	Carbon Fiber (tabletop)
Weight	27 Kilograms
Special Features	Ergonomic Design, Cup Holder, Headphone Hook, Cable Management

9. WARRANTY AND SUPPORT

Devoko is committed to customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any questions, concerns, or assistance with your Devoko Gaming Desk, please contact our customer support team through the retailer where you purchased the product or visit the official Devoko website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question