

[Manuals.plus](#) /

› [LORTSYBAB](#) /

› LORTSYBAB 2-in-1 Baby Stroller Instruction Manual

LORTSYBAB 2-in-1 Baby Stroller

LORTSYBAB 2-in-1 Baby Stroller Instruction Manual

Model: 2-in-1 Baby Stroller (Grey)

INTRODUCTION

Thank you for choosing the LORTSYBAB 2-in-1 Baby Stroller. This manual provides essential information for the safe assembly, operation, and maintenance of your stroller. Please read it thoroughly before use and retain it for future reference.

This stroller is designed for infants and toddlers from 0 to 36 months old, with a maximum weight recommendation of 50 pounds.

IMPORTANT SAFETY WARNINGS

- Always use the wrist strap when pushing the stroller to prevent it from rolling away.
- Ensure all locking mechanisms are engaged before placing a child in the stroller.
- Never leave your child unattended in the stroller.
- Always use the 5-point harness to secure your child.
- Do not overload the storage basket; refer to specifications for weight limits.
- Avoid placing hot liquids or heavy items on the handle.
- Keep children clear of moving parts during adjustment or folding.
- This stroller is not compatible with car seats.

SETUP AND ASSEMBLY

The LORTSYBAB 2-in-1 Baby Stroller requires minimal assembly. Follow these steps to prepare your stroller for use.

1. Unfolding the Stroller

To unfold the stroller, release the folding latch and lift the handle until the frame locks into place. Ensure all components

are securely engaged before use.

Foldable design for easy carrying and storage



Image: Three steps illustrating the unfolding process of the stroller.

2. Wheel Installation

Attach the EVA rubber wheels by pushing them onto the axles until they click securely into place. Verify that all wheels rotate freely and are firmly attached.

Suspension EVA Wheels



Suitable for all types of road



One-step Brake



Image: Detail of the suspension EVA wheels and the one-step brake system.

3. Attaching the Seat/Bassinet

The stroller features a 2-in-1 convertible seat/bassinet. Attach the unit to the frame by aligning the connectors and pressing down until it locks. Ensure it is securely fastened before placing your child inside.



Image: Stroller in bassinet mode, demonstrating the footmuff attachment.

OPERATING INSTRUCTIONS

1. Adjusting the Seat/Bassinet Mode

The 2-in-1 design allows for multiple configurations:

- **Sleeping Bassinet Mode (180°):** Ideal for newborns. Adjust the backrest to a flat, horizontal position.
- **Semi-Recline Mode (135°):** Suitable for infants who can partially support their head.
- **Sitting Mode (100°):** For older babies and toddlers who can sit upright independently.

To adjust the backrest, locate the adjustable belt under the sleeping basket and tighten or loosen it to achieve the desired angle.



Image: Stroller demonstrating sleeping, semi-recline, and sitting modes, with canopy adjustment.

2. Reversible Seat Functionality

The seat can be reversed to face either outwards or towards the parent. To reverse the seat, disengage the seat unit from the frame, turn it 180 degrees, and re-attach it securely.

- **Face Outside:** Allows the child to observe their surroundings.
- **Face Inside:** Facilitates interaction between parent and child.

Reversible Baby Stroller



FACE OUTSIDE

Encourage Your Baby
to Observe the Outside World



FACE INSIDE

Convenient for You to
Communicate with Your Baby

Image: Stroller with seat in face-outside and face-inside configurations.

3. Canopy Adjustment

The three-section canopy can be adjusted to provide optimal sun protection and comfort for your child in various weather conditions. Extend or retract the canopy as needed.

4. Braking System

The stroller is equipped with a one-touch brake system on the rear wheels. Press the brake pedal down to engage the brakes and lift it up to release. Always engage the brake when the stroller is stationary.

5. Front Wheel Operation

The front wheels can rotate 360° for easy maneuverability. To lock the front wheels in a straight position for rougher terrain, push the locking mechanism downwards. To unlock for swivel, pull it upwards.

6. Folding the Stroller

The stroller features a one-hand quick folding design for convenient storage and transport. Locate the folding mechanism on the handle, engage it, and fold the stroller until it latches. Ensure the stroller is fully collapsed before lifting or storing.



One Key to Fold Stroller Easily



One-hand Quick Folding

Image: Detail of the one-hand quick folding button and the stroller stored in a car trunk.

7. Harness System

Always secure your child using the 5-point safety harness. Adjust the straps to fit snugly around your child without being too tight. Ensure the shoulder straps are at the correct height for your child's shoulders.

MAINTENANCE

- **Cleaning:** The fabric components, including the footmuff, are removable and washable. Refer to the care label for specific washing instructions. Wipe the frame and plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners.
- **Storage:** Keep the stroller in a dry place to prevent rust and mildew. Avoid prolonged exposure to direct sunlight, which can fade fabrics.

- **Wheels:** Regularly check the wheels for debris and ensure they rotate smoothly. Lubricate axles if necessary.
- **Inspections:** Periodically inspect all parts for wear, damage, or loose fasteners. Discontinue use if any part is damaged.



Image: Removable and washable footmuff for easy cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller does not fold easily.	Folding mechanism not fully disengaged or obstructed.	Ensure the one-hand folding button is pressed completely. Check for any obstructions in the folding path.
Wheels are stiff or squeaky.	Debris in wheel axles or lack of lubrication.	Clean wheels and axles. Apply a silicone-based lubricant if necessary.
Stroller pulls to one side.	Front wheels locked or unevenly inflated (if applicable).	Ensure front wheels are unlocked for swivel. Check for any damage to wheels or frame.
Harness is difficult to buckle/unbuckle.	Buckle mechanism is dirty or damaged.	Clean the buckle with a damp cloth. If damaged, contact customer support.

SPECIFICATIONS

Feature	Detail
Model	2-in-1 Baby Stroller
Age Range	0-36 months
Maximum Weight Recommendation	50 Pounds
Item Weight	20.2 Pounds

Feature	Detail
Item Dimensions (L x W x H)	32"L x 23"W x 42"H
Folded Size	9.9"L x 18.4"W x 29"H
Frame Material	Aluminum
Fabric Type	Linen
Tire Material	EVA rubber
Harness Type	5 Point
Number of Wheels	4
Additional Features	Adjustable Canopy, Reversible Seat
Included Components	EVA rubber wheels, roomy storage basket



Image: Detailed dimensions of the stroller in use and folded.

INSTRUCTIONAL VIDEOS

Watch these official videos for visual guidance on using your LORTSYBAB stroller.

Lortsybab Bassinet Stroller Overview

Your browser does not support the video tag.

Video: This video provides a general overview of the Lortsybab bassinet stroller, showcasing its features and functionality.

WARRANTY INFORMATION

Specific warranty details are not provided in this manual. Please refer to the product packaging or the LORTSYBAB official website for comprehensive warranty information. Retain your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues, please contact LORTSYBAB customer support through the retailer where the product was purchased or visit the official LORTSYBAB brand store online.

LORTSYBAB Brand Store: [Visit Store](#)

