



[Manuals.plus](#) /

- › [WLIVE](#) /
- › WLIVE Farmhouse TV Stand (Model ADSG031DHS) Instruction Manual

WLIVE ADSG031DHS

WLIVE Farmhouse TV Stand (Model ADSG031DHS) Instruction Manual

Rustic Brown 58-inch Entertainment Center

1. PRODUCT OVERVIEW

The WLIVE Farmhouse TV Stand, model ADSG031DHS, is a rustic brown entertainment center designed to accommodate televisions up to 65 inches. This unit measures approximately 58.87 inches in width, 14.96 inches in depth, and 27 inches in height. It features a spacious tabletop, two open shelves, and two storage cabinets with corrugated acrylic doors. The design incorporates vintage metal handles, blending traditional and contemporary aesthetics. The stand is constructed from high-quality engineered wood, ensuring stability and durability.



Figure 1: WLIVE Farmhouse TV Stand, Rustic Brown.



PRODUCT SIZE



Max.
Weight
Capacity

Tabletop:**110IB**
Each Partition:**22IB**



Figure 2: Product dimensions and weight capacities. The tabletop supports up to 110 lbs, and each internal partition supports up to 22 lbs.



Figure 3: The TV stand is suitable for televisions up to 65 inches.

2. SAFETY INFORMATION

WARNING: This product requires proper assembly to ensure stability. Do not exceed the top load capacity of 110 lbs. Keep away from water to prevent damage. Securely install the TV stand to prevent tip-over, especially if a TV is placed on it. Keep small children away from the product to prevent injury from small parts or sharp edges.

- Always place the TV stand on a flat, level, and stable surface.
- Do not allow children to climb on or play with the TV stand.
- Distribute weight evenly across the shelves and tabletop.
- Use wall anchor kits (if provided) to secure the stand to the wall, preventing accidental tipping.

3. SETUP AND ASSEMBLY

This TV stand is designed for straightforward assembly. All necessary screws and hardware are pre-sorted and clearly marked for easy identification. While one person can assemble the unit, two people are recommended for faster and easier

completion.

3.1 Before You Begin

- Unpack all components and verify against the parts list in your included manual.
- Ensure you have a clean, spacious area for assembly.
- Gather basic tools such as a screwdriver (a magnetic screwdriver may be included).
- Remove the transparent protective film from the acrylic doors before use to reveal the glossy finish.

3.2 Assembly Steps (General Guidelines)

1. Attach the base and side panels according to the provided diagrams.
2. Install the fixed shelves and back panels.
3. Assemble the adjustable shelves and insert them into the desired positions.
4. Attach the corrugated acrylic doors and their handles.
5. Ensure all connections are secure and stable.

Your browser does not support the video tag.

Video 1: A brief overview of the assembly process for the TV stand. This video demonstrates the general steps involved in putting the unit together.

4. OPERATING INSTRUCTIONS

4.1 Adjustable Shelves

The TV stand features adjustable shelves within its compartments. These shelves can be repositioned to accommodate various equipment sizes, such as game consoles, cable boxes, or DVD collections. To adjust, carefully remove the shelf, reposition the shelf pins to the desired height, and reinsert the shelf.

ADJUSTABLE SHELVES



Figure 4: The TV stand includes adjustable shelves for flexible storage.

4.2 Corrugated Acrylic Doors

The storage cabinets are equipped with corrugated acrylic doors. These doors provide a semi-transparent look, subtly concealing contents while allowing for remote control signal reception. The design ensures functionality without compromising aesthetics.

CORRUGATED ACRYLIC DOORS

Not Affect Signal
Reception



Figure 5: Corrugated acrylic doors allow for signal reception from remote controls.

4.3 Cable Management

The TV stand includes designated openings for cable management, helping to keep wires organized and out of sight. Route all power and signal cables through these openings to maintain a tidy appearance and prevent tangles.

KEEP MESSY WIRES WELL ORGANIZED



Figure 6: Integrated cable management helps organize wires.

5. MAINTENANCE

To maintain the appearance and longevity of your WLIVE Farmhouse TV Stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent water damage or staining.
- **Protective Film:** As noted during setup, ensure the transparent protective film on the acrylic doors has been removed.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Retighten if necessary to maintain stability.

6. TROUBLESHOOTING

If you encounter any issues with your TV stand, consider the following common solutions:

- **Instability/Wobbling:** Ensure the TV stand is placed on a level surface. Check and tighten all screws and connections. If applicable, use the provided wall anchor kit to secure the stand to the wall.
- **Doors Not Closing Properly:** Verify that the hinges are correctly installed and adjusted. Check for any obstructions within the cabinet or door frame.
- **Missing Parts:** If any parts were missing upon unboxing, refer to the Warranty and Support section to contact customer service for assistance.
- **Damage During Shipping:** If the product arrived damaged, document the damage with photographs and contact customer support immediately.

7. SPECIFICATIONS

Model Number	ADSG031DHS
Material	Engineered Wood, Acrylic
Color	Rustic Brown
Product Dimensions (W x D x H)	58.87 x 14.96 x 27 inches

Item Weight	60.5 pounds
Maximum Top Load Capacity	110 lbs
Maximum Shelf Load Capacity (each partition)	22 lbs
Recommended TV Size	Up to 65 inches
Special Feature	Adjustable Shelves

Your browser does not support the video tag.

Video 2: A promotional video showcasing the features and design of the WLIVE TV Stand.

8. WARRANTY AND SUPPORT

WLIVE is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this document, a professional after-sales team is available to assist with any concerns or issues you may encounter.

8.1 Contacting Support

For assistance with assembly, missing parts, product defects, or any other inquiries, please contact WLIVE customer support through the retailer's platform where the product was purchased. Have your model number (ADSG031DHS) and purchase information ready to expedite the support process.

You can also visit the official WLIVE store for more information: [WLIVE Store on Amazon](#)