

DUODUOGO S12

DUODUOGO S12 10-inch Android 12 Tablet User Manual

Model: S12

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your DUODUOGO S12 10-inch Android 12 Tablet. Please read it thoroughly before operating the device to ensure optimal performance and longevity. The DUODUOGO S12 is a high-performance tablet featuring a 10.1-inch HD IPS display, powered by an Octa-Core 2.0 GHz processor. It comes with 4GB RAM and 64GB internal storage, expandable up to 512GB via a Micro SD card. Key features include Wi-Fi 6 (supporting 5G and 2.4G networks), Bluetooth 4.3, GPS, FM radio, and an 8MP rear camera with a 5MP front camera. A 6000mAh battery with QC 3.0 fast charging ensures extended usage.

2. SAFETY INFORMATION

- Do not expose the tablet to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the tablet to strong impacts.
- Use only the provided charger and accessories to prevent damage and ensure safety.
- Keep the tablet away from water and other liquids.
- Do not attempt to disassemble or repair the tablet yourself. Contact qualified service personnel for assistance.
- Dispose of the tablet and its battery responsibly according to local regulations.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all items listed below are present and in good condition:

- DUODUOGO S12 Tablet
- USB-C Charging Cable
- Power Adapter (QC 3.0 compatible)
- SIM Ejector Tool
- User Manual



The DUODUOGO S12 tablet's package contents, showing the tablet, a USB-C charging cable, a power adapter, a SIM ejector tool, and the user manual.

4. DEVICE LAYOUT AND COMPONENTS

Familiarize yourself with the physical features of your DUODUOGO S12 tablet:

DUODUOGO S12



Weight: 523g

Android 12

Bluetooth 4.3

A detailed diagram of the DUODUOGO S12 tablet, highlighting its 10.1-inch IPS screen, Octa-Core CPU, 4GB RAM, 64GB ROM, 5MP front camera, 8MP rear camera, 6000mAh battery, 2.4GHz+5GHz Dual WiFi, expandable storage up to 512GB, 523g weight, Android 12, and Bluetooth 4.3. Dimensions are shown as 242mm length, 161mm width, and 10.5mm thickness.

- **10.1-inch IPS HD Display:** Main screen for interaction.
- **5MP Front Camera:** Located on the front bezel, used for video calls and selfies.
- **8MP Rear Camera:** Located on the back, for taking photos and videos.
- **Power Button:** Typically on the side, used to turn the device on/off or wake/sleep the screen.
- **Volume Buttons:** Adjust audio levels.
- **USB Type-C Port:** For charging and data transfer.
- **Micro SD Card Slot:** For expanding storage.
- **Speakers:** For audio output.

5. SETUP

5.1 Initial Charging

Before first use, fully charge your tablet. Connect the USB-C cable to the tablet's charging port and the power adapter to a wall outlet. The tablet supports QC 3.0 fast charging, allowing it to reach full charge in approximately 1.5 hours.

6000mAh Battery

Support up to 6 – 7 hours, with QC 3.0 Fast Charge



The DUODUOGO S12 tablet emphasizing its 6000mAh battery, providing 6-7 hours of usage, and its support for QC 3.0 fast charging via a Type-C port.

5.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the DUODUOGO logo appears.
- **To Power Off:** Press and hold the Power button until a power menu appears on the screen. Select 'Power off'.
- **To Restart:** From the power menu, select 'Restart'.

5.3 Initial Configuration

Upon first power-on, the tablet will guide you through the initial setup process:

1. Select your preferred language.
2. Connect to a Wi-Fi network. This is crucial for downloading updates and setting up your Google account.
3. Sign in with your Google account or create a new one.
4. Follow the on-screen prompts to complete the setup, including setting up screen lock, Google services, and more.

5.4 Inserting a Micro SD Card

To expand the tablet's storage:

1. Locate the Micro SD card slot on the side of the tablet.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place the Micro SD card into the designated slot on the tray.
4. Insert the tray back into the tablet until it clicks into place.

Large Storage & High Speed




4GB
RAM



64GB
ROM



512GB
TF Expansion



An image illustrating the DUODUOGO S12 tablet's storage capabilities (4GB RAM, 64GB ROM, 512GB TF expansion) and its Octa-Core processor for high performance.

6. OPERATING INSTRUCTIONS

6.1 Basic Navigation (Android 12)

Your DUODUOGO S12 tablet runs on Android 12, offering an intuitive user experience:

- **Touch:** Tap an icon to open an app or select an item.
- **Swipe:** Drag your finger across the screen to scroll through pages or content.
- **Pinch-to-Zoom:** Use two fingers to zoom in or out on images and web pages.
- **Home Screen:** Swipe up from the bottom to access the app drawer. Swipe down from the top for quick settings and notifications.

Latest Android 12 System



The DUODUOGO S12 tablet showcasing the Android 12 operating system, with icons for Wi-Fi 6, Bluetooth, GPS, and popular apps like YouTube, Google Chrome, and Facebook.

6.2 Wi-Fi Connectivity (Wi-Fi 6)

The tablet supports Wi-Fi 6 for faster and more stable internet connections:


1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi on.
3. Select your desired network from the list and enter the password if required.

Wi-Fi 6 : Up to 9.6Gbps

Wi-Fi 6



2.4Ghz WIFI



A visual comparison showing the faster data transfer speeds of Wi-Fi 6 (up to 9.6Gbps) compared to standard 2.4GHz WiFi on the DUODUOGO S12 tablet, illustrated with a gaming scenario.

6.3 Bluetooth Pairing

To connect Bluetooth devices:

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth on.
3. Ensure your Bluetooth device is in pairing mode.
4. Select the device from the 'Available devices' list to pair.

6.4 Camera Usage

The tablet features an 8MP rear camera and a 5MP front camera:

1. Open the **Camera** app.
2. Tap the shutter button to take a photo.

3. Switch between front and rear cameras using the camera icon.
4. Select video mode to record videos.



An image demonstrating the DUODUOGO S12 tablet's 5MP front camera for video calls and an 8MP rear camera for capturing photos, with example usage scenarios.

6.5 GPS Functionality

The built-in GPS allows for navigation even without an internet connection (with pre-downloaded offline maps). Enable location services in **Settings > Location** to use GPS with mapping applications.

7. MAINTENANCE

7.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- Do not use harsh chemicals, abrasive cleaners, or aerosol sprays.

- If necessary, slightly dampen the cloth with water or a screen-specific cleaning solution.

7.2 Software Updates

Regularly check for and install software updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to **Settings > System > System update**.

7.3 Battery Care

- Avoid fully discharging the battery frequently.
- Do not leave the tablet charging for excessively long periods after it's full.
- Store the tablet in a cool, dry place if not used for an extended period.

8. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Solution
Tablet does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again. If unresponsive, perform a forced restart by holding the power button for 10-15 seconds.
Wi-Fi connection issues.	Check if Wi-Fi is enabled in settings. Restart your router and the tablet. Ensure you are within range of the Wi-Fi signal. Verify the Wi-Fi password.
Slow performance.	Close unused applications. Clear cache for frequently used apps. Check available storage and free up space if necessary. Restart the tablet.
Apps crashing or freezing.	Force close the app (Settings > Apps > [App Name] > Force stop). Clear the app's cache and data. Reinstall the app. Ensure the tablet's software is up to date.
Battery drains quickly.	Reduce screen brightness. Disable unused features like Bluetooth, GPS, or Wi-Fi when not needed. Close background apps. Check battery usage in settings to identify power-hungry apps.

9. SPECIFICATIONS

Detailed technical specifications for the DUODUOGO S12 Tablet:

Feature	Specification
Brand	DUODUOGO
Model Number	S12
Operating System	Android 12
Processor	Octa-Core 2.0 GHz (MT8183)
RAM	4 GB

Feature	Specification
Internal Storage	64 GB
Expandable Storage	Up to 512 GB via Micro SD card
Screen Size	10.1 Inches
Display Type	IPS HD (1280*800 resolution)
Rear Camera	8 MP
Front Camera	5 MP
Battery Capacity	6000 mAh
Charging	USB Type-C, QC 3.0 Fast Charge
Wi-Fi	Wi-Fi 6 (2.4G + 5G)
Bluetooth	Bluetooth 4.3
GPS	Integrated GPS
Other Features	FM Radio, 4G Cellular Technology (as per specifications)
Dimensions	242mm x 161mm x 10.5mm
Weight	523g
Model Year	2023

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official DUODUOGO website. If you encounter issues not covered in this manual, please contact DUODUOGO customer service for further assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question