Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hikity 4f7738af-a529-42a9-90cb-4290627021cc

Hikity Portable Wireless CarPlay Android Auto Screen User Manual

Model: 4f7738af-a529-42a9-90cb-4290627021cc

Brand: Hikity

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Hikity Portable Wireless CarPlay Android Auto Screen. Please read this manual thoroughly before using the device to ensure proper functionality and safety. This device enhances your driving experience by integrating smartphone features like navigation, music, and calls directly onto its 7-inch touchscreen.



Image: The Hikity Portable Wireless CarPlay Android Auto Screen shown with its included accessories, including a phone, a suction cup mount, and a dashboard mount.

2. What's in the Box

Verify that all items are present in the package:

- 7 Inch Smart Screen Player
- 2 Universal Mounts (Suction Cup Mount and Dashboard Mount)
- Camera Power Cable (for optional rear camera connection, camera not included)
- Cigarette Lighter Plug (Power Cord)
- 3M AUX Cable
- Bracket Fixing Sticker



Image: A visual representation of the product dimensions and a detailed list of all components included in the packaging.

3. Key Features

- **Wireless Connectivity:** Supports wireless Apple CarPlay and Android Auto for seamless integration with your smartphone.
- **Smart Airplay:** Built-in AirPlay function allows streaming music, movies, and photos from iOS devices.
- **Bluetooth Hands-Free Calling & Music Playing:** Enables safe hands-free calls and wireless music streaming.
- **Multiple Audio Outputs:** Features built-in microphone, Bluetooth, AUX connection, and FM Transmitter for versatile audio output options.
- **Navigation via Phone:** Utilizes your phone's maps through CarPlay, Android Auto, or AirPlay for real-time traffic updates and directions.
- **7-inch Capacitive Touchscreen:** High-definition display (1024x600) for clear visuals and responsive touch interaction.

- **Easy Installation:** Designed for dashboard or windshield mounting without complex tools or car disassembly.
- **Voice Control:** Compatible with voice assistants for navigation, calls, and music control.
- **Mirror Link Function:** Synchronize your phone screen (Android/iPhone) to the device.

4. Setup and Installation

4.1 Mounting the Device

Choose between dashboard or windshield mounting using the provided universal mounts.

1. **Dashboard Mounting:** Attach the dashboard mount to a clean, flat surface on your dashboard using the adhesive base. Secure the smart screen player to the mount.
2. **Windshield Mounting:** Attach the suction cup mount to a clean area on your windshield. Secure the smart screen player to the mount.

Ensure the mount is firmly secured before attaching the device. The rotatable stand allows for angle adjustment.



Image: Illustrations demonstrating the easy installation process, showing both dashboard and windshield mounting options, and the flexibility of the rotatable stand.

4.2 Power Connection

Connect the provided cigarette lighter plug to your vehicle's 12V power outlet and the other end to the device's TYPE-C port. The device will power on automatically when the vehicle's ignition is turned on.

4.3 Audio Output Setup

The device offers four audio output options:

- **Built-in Speaker:** For direct audio output from the device.
- **Bluetooth:** Connect to your car's Bluetooth system for audio output.
- **AUX Connection:** Use the provided 3M AUX cable to connect the device's AUX output to your car's AUX input.
- **FM Transmitter:** Transmit audio to your car's FM radio.



Image: A close-up view of the AUX port on the device, illustrating how to connect an external audio cable for sound output through your car's speakers.

5. Operating Instructions

5.1 Wireless CarPlay & Android Auto

The device supports wireless CarPlay for iOS devices and wireless Android Auto for Android devices. This allows you to access navigation, music, messages, and calls directly from the screen.

- Ensure Bluetooth and Wi-Fi are enabled on your smartphone.
- On the device, select the CarPlay or Android Auto icon.
- Follow the on-screen prompts to pair your phone.



Image: The screen demonstrating wireless CarPlay and Android Auto functionality, showing navigation and music playback, with a smartphone indicating wireless connectivity.

5.2 Bluetooth Functionality

For hands-free calling and music streaming:

- Go to the Bluetooth menu on the device.
- Enable Bluetooth on your phone and search for the device (e.g., "Hikity Carplay").
- Pair your phone. Once connected, you can make/receive calls and play music wirelessly.



Image: The device displaying its Bluetooth calling interface and the FM transmission settings, highlighting hands-free communication and radio integration.

5.3 FM Transmission

To output audio through your car's FM radio:

1. Select the FM Transmitter option on the device.
2. Choose an unused FM frequency on the device.
3. Tune your car's FM radio to the same frequency.
4. Ensure the included power adapter is used, as it contains the FM antenna.

5.4 Voice Control

Utilize voice commands for safer operation:

- Activate your phone's voice assistant (Siri, Google Assistant) through the device.
- Use commands for navigation, making calls, playing music, and other operations.



Image: The device interface highlighting its intelligent voice control capabilities, with icons for Siri and Google Assistant, and examples of voice commands.

5.5 Mirror Link Function

To mirror your smartphone screen:

- **For iPhone:** Connect your iPhone to the device's Wi-Fi (Wi-Fi Name: CARLINK-17CCE9, Password: "12345678"). Then, select "SmartScreen" in your iPhone's screen mirroring control center.
- **For Android:** Connect your phone via Bluetooth (Name: T86-17CCE9). Open the "TCLink" application on your phone and connect it to CARLINK-17CCE9.



Image: A visual guide explaining the Mirror Link function for both iPhone and Android, detailing the connection steps to synchronize your phone's display to the screen.

5.6 TF Card Slot

While this specific model (no TF Card variant) does not include a TF card, the device is equipped with a TF card slot for potential future use or for other variants that support local media playback from a TF card.



Image: A detailed view of the TF (TransFlash) card slot on the device, indicating its location for media expansion.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the screen and device body. Do not use abrasive cleaners or solvents.
- **Temperature:** Avoid exposing the device to extreme temperatures (hot or cold) for prolonged periods.
- **Storage:** If storing the device for an extended period, disconnect it from power and store it in a cool, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	No power from cigarette lighter; loose connection.	Check cigarette lighter fuse; ensure power cable is securely connected.
No audio output.	Incorrect audio output setting; volume too low.	Verify selected audio output (Built-in Speaker, BT, AUX, FM); increase volume on device and car stereo.
CarPlay/Android Auto not connecting.	Bluetooth/Wi-Fi off on phone; incorrect pairing.	Ensure phone's Bluetooth and Wi-Fi are on; re-pair the device following instructions in section 5.1.
FM transmission static/poor quality.	Interference; incorrect frequency; power adapter not used.	Select a clear, unused FM frequency; ensure the original cigarette lighter power adapter is used.
Touchscreen unresponsive.	Temporary software glitch.	Restart the device by disconnecting and reconnecting power.

8. Specifications

- **Model Number:** 4f7738af-a529-42a9-90cb-4290627021cc
- **Screen Size:** 7 inches (18 cm)
- **Display Resolution:** HD 1024 x 600
- **Connectivity Technology:** Auxiliary, Bluetooth
- **Controller Type:** Android (compatible with iOS via CarPlay)
- **Special Features:** Airplay, Wireless Android Auto, Wireless Apple CarPlay, Mirror Link
- **Compatible Devices:** Android/iPhone Smartphones
- **Audio Output Mode:** Stereo
- **Surround Sound Channel Configuration:** Speakers, Bluetooth, Headphones, FM Transmitter
- **Item Weight:** 1.41 pounds
- **Color:** Black
- **Manufacturer:** Hikity
- **Country of Origin:** China

9. Warranty and Support

Hikity provides quality assurance for its products. For any technical assistance, warranty claims, or customer support, please contact Hikity customer service.

Customer Support Email: hikityservices@163.com

Please have your product model number and purchase details ready when contacting support.




Image: A customer service representative, symbolizing available support for product inquiries.

© 2024 Hikity. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZ4JN22C

More documents and user manuals: **https://manuals.plus/**