Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy BZR93-W

SoBuy BZR93-W Bathroom Cabinet with Laundry Basket - Instruction Manual

Model: BZR93-W | Brand: SoBuy

Product Overview

The SoBuy BZR93-W Bathroom Cabinet is a compact and modern storage solution designed for bathrooms. It features a high-quality MDF (E1) construction, ensuring robustness, durability, and moisture resistance. This cabinet includes a practical laundry basket and a small drawer for accessories, helping to keep your bathroom organized. Its space-saving design and anti-tip mechanism provide both functionality and safety.

- **High-Quality Material:** Constructed from durable and moisture-resistant MDF (E1).
- **Practical Laundry Solution:** Keeps dirty laundry out of sight yet easily accessible.
- **Versatile Storage:** Features a small drawer for toiletries and accessories.
- **Safety and Stability:** Equipped with an anti-tip mechanism for secure wall attachment.
- **Easy Assembly:** Comes with clear instructions for quick and straightforward setup.

1. Setup and Assembly

Your SoBuy BZR93-W Bathroom Cabinet is delivered disassembled and carefully packaged. Assembly is required. Please follow the included assembly guide for a simple and quick installation process.

1.1 Unpacking

- Carefully open the packaging and remove all components.
- Verify that all parts listed in the assembly instructions are present.
- Place all parts on a soft, clean surface to prevent scratches during assembly.

1.2 Assembly Steps

Refer to the detailed assembly instructions provided in the package. The instructions include diagrams and step-by-step guidance for assembling the cabinet, drawer, and laundry basket mechanism.



Image 1: The SoBuy BZR93-W Bathroom Cabinet installed in a bathroom, showing its compact design next to a sink.

1.3 Wall Mounting for Stability

For enhanced stability and safety, especially in households with children or pets, it is highly recommended to secure the cabinet to the wall using the provided anti-tip mechanism. This prevents accidental tipping.

- Locate the anti-tip hardware in your package.
- Follow the specific instructions in the assembly guide for attaching the cabinet to a suitable wall surface.
- Ensure the wall anchors are appropriate for your wall type.

2. Operating Instructions

2.1 Using the Laundry Basket

The lower compartment of the cabinet features a tilt-out door that conceals a fabric laundry basket.

- To access the laundry basket, gently pull the handle on the lower door. The door will tilt forward, allowing easy

access to the removable fabric basket.

- Place dirty laundry directly into the fabric basket.
- To close, push the door back until it latches securely.
- The fabric basket can be removed for easy transport of laundry to your washing machine.



Image 2: The laundry basket compartment open, showing the removable fabric basket.

2.2 Using the Storage Drawer

The upper section of the cabinet includes a small drawer, ideal for storing smaller bathroom accessories, toiletries, or other personal items.

- Pull the handle to open the drawer.
- Organize your items neatly within the drawer.
- Push the drawer back in until it is fully closed.



Image 3: The top drawer open, revealing neatly folded towels and other bathroom essentials.

3. Care and Maintenance

To ensure the longevity and appearance of your SoBuy BZR93-W Bathroom Cabinet, follow these simple care instructions:

- **Cleaning:** Wipe the cabinet surfaces with a soft, dry cloth. For stubborn marks, a slightly damp cloth followed immediately by a dry cloth can be used. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Moisture:** Although the cabinet is moisture-resistant, avoid prolonged exposure to excessive water. Wipe up any spills immediately.
- **Laundry Basket:** The fabric laundry basket can be spot cleaned with a mild detergent and water. Allow it to air dry completely before placing it back into the cabinet.
- **Inspection:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.

4. Troubleshooting

4.1 Cabinet Instability

If the cabinet feels unstable or wobbly:

- **Check Assembly:** Ensure all screws and connectors are fully tightened according to the assembly instructions.
- **Wall Mounting:** Verify that the anti-tip mechanism is correctly installed and securely fastened to a sturdy wall. This is crucial for preventing tipping.
- **Level Surface:** Ensure the cabinet is placed on a flat, level surface. Adjust the feet if necessary to eliminate wobbling.

4.2 Drawer Not Sliding Smoothly

If the drawer is difficult to open or close:

- **Check Rails:** Inspect the drawer slides for any obstructions or debris. Clean them if necessary.
- **Alignment:** Ensure the drawer is correctly aligned on its rails. Remove and reinsert the drawer if it seems misaligned.
- **Overloading:** Avoid overloading the drawer, as this can cause it to stick or become difficult to operate.

5. Product Specifications

Brand	SoBuy
Model Number	BZR93-W
Color	White
Material	MDF (E1)
Product Dimensions (D x W x H)	30P x 34l x 90H cm (30 x 34 x 90 cm)
Item Weight	13 Kilograms
Maximum Weight Capacity	20 Kilograms
Number of Drawers	1
Number of Doors	1 (for laundry basket)
Storage Options	Removable laundry basket
Assembly Required	Yes
Mounting Type	Wall Mount (anti-tip mechanism included)
Care Instructions	Clean with a dry cloth





Image 4: Detailed dimensions of the SoBuy BZR93-W Bathroom Cabinet, showing height, width, and depth measurements.

6. Warranty Information

SoBuy products are designed for quality and durability. For specific warranty details, please refer to the documentation included with your product or contact SoBuy customer support.
If you are not satisfied with the product or encounter any issues, you may contact SoBuy for return information.

7. Customer Support

For any questions, concerns, or assistance with your SoBuy BZR93-W Bathroom Cabinet, please do not hesitate to contact SoBuy customer support.

- **Assembly Manual:** A manual is included in every package. You can also scan the QR code on the packaging or contact us to receive a copy.
- **Shipping:** This item can be shipped via UPS, DHL, or DPD. If you prefer a specific carrier, please contact us before shipment.
- **Returns:** If you do not like the product or encounter any problems, you can contact us to obtain a return label.

SoBuy is committed to responding to your needs and questions.

© 2024 SoBuy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZ4MZS5B

More documents and user manuals: **https://manuals.plus/**