



Manuals.plus /

› Fastrack /

› Fastrack Urban Camo Quartz Analog Watch Model NT3295QM01 Instruction Manual

Fastrack NT3295QM01

Fastrack Urban Camo Quartz Analog Watch - Model NT3295QM01

Instruction Manual

[Overview](#)

[Features](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. PRODUCT OVERVIEW

Welcome to your new Fastrack Urban Camo Quartz Analog Watch. This timepiece combines a unique camouflage-inspired black dial with a functional day-date display and a sophisticated copper brown stainless steel strap. Designed for the modern individual, it offers both style and practicality.



Image 1: Front view of the Fastrack Urban Camo Quartz Analog Watch with brown metal strap and black dial.

2. KEY FEATURES

- **Urban Camo Texture:** The black dial features a subtle, unique camouflage-inspired pattern.
- **Day-Date Display:** Conveniently shows both the day of the week and the date.
- **Durable Construction:** Features a copper brown stainless steel strap and case for rugged sophistication.
- **Clear Readability:** Warm-toned hands and indices provide a subtle contrast against the black dial for easy time reading.
- **Analog Display:** Classic analog timekeeping.
- **Water Resistance:** 50 meters (5 ATM), suitable for short periods of recreational swimming, but not diving or snorkeling.
- **Battery Powered:** Operates on a Lithium Polymer battery (included).



Image 2: Angled view of the watch, highlighting the strap and dial texture.

3. INITIAL SETUP

3.1 Setting the Time

1. Pull the crown (the small knob on the side of the watch) out to the second click position.
2. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time. Ensure you account for AM/PM when setting the time, as the date will change at midnight.
3. Once the time is set, push the crown back into its normal position.

3.2 Setting the Day and Date

1. Pull the crown out to the first click position.
2. Turn the crown clockwise to adjust the date.
3. Turn the crown counter-clockwise to adjust the day.
4. Adjust the day and date to the day before the current day and date. For example, if today is Tuesday the 15th, set it to Monday the 14th.

5. Pull the crown out to the second click position.
6. Turn the crown clockwise to advance the time until the correct day and date appear. Continue turning until the current time is set. This ensures the day and date change at midnight, not noon.
7. Push the crown back into its normal position.

3.3 Strap Adjustment

The metal strap may require adjustment to fit your wrist comfortably. It is recommended to have this adjusted by a professional watchmaker or jeweler to avoid damage to the strap or watch.

Your browser does not support the video tag.

Video 1: A quick guide to understanding watch dial sizes and wrist measurement for optimal fit.

4. OPERATING YOUR WATCH

Your Fastrack Urban Camo watch is designed for straightforward use. Once the time, day, and date are set, the watch will operate continuously. The quartz movement ensures accurate timekeeping.

4.1 Day-Date Function

The day and date indicators will automatically advance at midnight. If the watch stops or the day/date is incorrect after a period of non-use, refer to the "Setting the Day and Date" section for re-adjustment.

5. CARE AND MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and dirt. For the metal strap, a slightly damp cloth can be used, followed by immediate drying.
- **Water Resistance:** This watch is water-resistant up to 50 meters (5 ATM). It is suitable for everyday use and can withstand splashes or brief immersion in water. However, it is not recommended for showering, bathing, diving, or snorkeling. Avoid operating the crown or pushers when the watch is wet.
- **Temperature:** Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect its accuracy and lifespan.
- **Chemicals:** Keep the watch away from chemicals such as solvents, detergents, perfumes, and cosmetics, which can damage the case, strap, or seals.
- **Battery Replacement:** When the watch battery runs low, it is recommended to have it replaced by an authorized Fastrack service center or a qualified watch technician to ensure proper sealing and water resistance.



Image 3: Back view of the watch, showing the stainless steel case back and water resistance marking.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Battery depleted.	Replace the battery at an authorized service center.
Incorrect time/date	Time/date not set correctly or adjusted after a long period of non-use.	Refer to the "Setting the Time" and "Setting the Day and Date" sections.
Condensation inside the watch	Exposure to extreme temperature changes or compromised water resistance.	Immediately take the watch to an authorized service center for inspection.
Strap discomfort	Strap not properly sized for your wrist.	Have the strap adjusted by a professional.

7. PRODUCT SPECIFICATIONS

Brand: Fastrack
Model: NT3295QM01
Model Name: Camo
Display Type: Analog
Movement: Quartz
Case Material: Stainless Steel
Strap Material: Metal (Copper Brown Stainless Steel)
Dial Color: Black (Urban Camo Texture)
Special Features: Day and Date Display, Second Hand
Water Resistance Depth: 50 Meters (5 ATM)
Power Source: Battery Powered (1 Lithium Polymer battery included)
Item Weight: 200 g
Product Dimensions: 14 x 7 x 10 cm
Country of Origin: India




Image 4: Side view of the watch, showing the case thickness and crown.

8. WARRANTY AND SUPPORT

Your Fastrack Urban Camo Quartz Analog Watch comes with a standard manufacturer's warranty. For specific details regarding the warranty period and coverage, please refer to the warranty card included with your purchase or contact Fastrack customer support.

An optional **1 Year Extended Warranty Plan by Onsitego** is available for purchase, providing additional coverage for 12 months. Please check the product detail page or your purchase documentation for more information on this extended warranty.

For any service, repairs, or technical assistance, please contact an authorized Fastrack service center. Using unauthorized service providers may void your warranty.