

[Manuals.plus](#) /

› [Lionsgate](#) /

› John Wick: Chapter 4 Blu-ray User Guide

Lionsgate B0BZ5C5XNJ

John Wick: Chapter 4 Blu-ray User Guide

Model: B0BZ5C5XNJ

PRODUCT OVERVIEW

This guide provides instructions for the proper use and care of your John Wick: Chapter 4 Blu-ray disc. This Blu-ray edition includes the critically acclaimed film and is designed for playback on compatible Blu-ray players.



Image: Front cover of the John Wick: Chapter 4 Blu-ray disc. It features Keanu Reeves as John Wick, holding a pistol, against a red and neon-lit background. The title "JOHN WICK CHAPTER 4" is prominently displayed in neon blue.

SETUP

To begin watching John Wick: Chapter 4, follow these simple steps:

1. **Prepare Your Player:** Ensure your Blu-ray player is connected to your television or display device and powered on.
2. **Insert the Disc:** Gently hold the Blu-ray disc by its edges to avoid touching the playback surface. Insert the disc into the disc tray or slot of your Blu-ray player with the label side facing up.
3. **Close Tray:** If your player has a disc tray, close it. The player should automatically detect the disc and begin loading.

OPERATING INSTRUCTIONS

Once the disc has loaded, you will typically see the main menu. Use your player's remote control to navigate.

- **Play Movie:** Select "Play Movie" or "Start" from the main menu to begin playback of John Wick: Chapter 4.
- **Scene Selection:** Use the "Scene Selection" or "Chapters" option to jump to specific parts of the film.
- **Audio/Subtitles:** Access the "Audio" or "Language" menu to select your preferred audio track (e.g., English) and subtitle options (if available).
- **Special Features:** Explore the "Special Features" section for bonus content, such as behind-the-scenes footage or interviews.

MAINTENANCE AND CARE

Proper care will ensure the longevity and optimal performance of your Blu-ray disc:

- **Handling:** Always hold the disc by its outer edges or the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If the disc becomes dirty, gently wipe it with a soft, lint-free cloth (e.g., microfiber) from the center outwards. Do not use abrasive materials or harsh chemicals.
- **Storage:** Store the disc in its original case when not in use to protect it from dust, scratches, and direct sunlight.
- **Temperature:** Avoid exposing the disc to extreme temperatures or high humidity.

TROUBLESHOOTING

If you encounter issues during playback, consider the following:

- **Disc Not Playing:**
Ensure the disc is inserted correctly (label side up). Clean the disc if there are visible smudges or dust. Try playing another Blu-ray disc to confirm your player is functioning correctly.
- **Skipping or Freezing:**
This is often caused by dirt or scratches. Clean the disc thoroughly. If the issue persists, the disc may be damaged.
- **No Audio/Video:**
Check all cable connections between your Blu-ray player and your TV/audio system. Ensure the correct input source is selected on your TV. Verify audio settings on your player and TV.
- **Region Code Error:**
This Blu-ray is Region Free. If you encounter a region error, ensure your player is also region-free or compatible with Region A, B, or C discs. Most modern players are multi-region compatible.

SPECIFICATIONS

Feature	Detail
Product Title	John Wick: Chapter 4

Format	Blu-ray, DVD-Vidéo, Digital Copy
ASIN	B0BZ5C5XNJ
UPC	031398339489
Runtime	2 hours and 49 minutes
Number of Discs	2
Language	English (and potentially others based on disc content)
Release Date	June 9, 2023
Dimensions	17.4 x 13.79 x 1.4 cm; 90.72 grams

WARRANTY AND SUPPORT

As a media product, this Blu-ray disc typically does not come with a traditional manufacturer's warranty for performance beyond initial functionality. If your disc is defective upon receipt, please contact the retailer from whom you purchased it for assistance with a return or exchange.

For general inquiries about the film content, please refer to official movie websites or fan communities. For technical support related to your Blu-ray player, please consult your player's user manual or the manufacturer's support resources.