

RECHOO G1000

RECHOO G1000 Rechargeable Flashlight Instruction Manual

Model: G1000

1. INTRODUCTION

Thank you for choosing the RECHOO G1000 Rechargeable Flashlight. This high-lumens, portable, and durable tactical flashlight is designed for various uses, including camping, hiking, emergencies, and everyday tasks. This manual provides essential information for proper setup, operation, and maintenance to ensure optimal performance and longevity of your device.



Figure 1: RECHOO G1000 Rechargeable Flashlight and included Type-C charging cable.

2. WHAT'S IN THE BOX

Upon unboxing, please ensure all the following components are present:

- G1000 Rechargeable Flashlight (1 unit)
- Type-C Rechargeable Cable (1 unit)
- Built-in Rechargeable Battery (pre-installed)

3. SETUP AND INITIAL CHARGE

Your RECHOO G1000 flashlight comes with a built-in high-capacity rechargeable battery. For optimal performance, it is recommended to fully charge the flashlight before its first use.

1. Locate the Type-C charging port on the flashlight. It is typically covered by a protective rubber flap to

ensure water resistance.

2. Gently open the rubber flap to expose the Type-C port.
3. Connect the included Type-C charging cable to the flashlight's port.
4. Plug the other end of the USB cable into any compatible USB power source (e.g., laptop, power bank, car charger, or wall adapter).
5. The indicator light on the flashlight will illuminate red while charging. Once fully charged, the indicator light will turn green.
6. A full charge typically takes 3-4 hours.
7. Once charging is complete, disconnect the cable and securely close the rubber flap to maintain water resistance.



Figure 2: USB Rechargeable Flashlight with charging indicators (red for charging, green for full).

4. OPERATING INSTRUCTIONS

Power On/Off and Lighting Modes

The RECHOO G1000 features a tactical switch design with 3 lighting modes:

1. **First Press:** Activates High brightness mode (1000 Lumens Max Output).
2. **Second Press:** Switches to Medium brightness mode.
3. **Third Press:** Activates Strobe mode.
4. **Fourth Press:** Turns the flashlight OFF.

The flashlight is designed to illuminate anywhere with ease, providing powerful light for various situations.



Figure 3: Zoomable feature and 3 lighting modes.

Zoom Function

The flashlight features a zoomable head, allowing you to easily adjust the beam from a wide floodlight to a narrow, focused beam.

- To zoom in (narrow beam), gently pull the flashlight head outwards.
- To zoom out (wide beam), push the flashlight head inwards.




Figure 4: Super Bright G1000 Rechargeable Flashlight in use, showing 1000 LM Max Output and 328 FT Beam Distance.

5. MAINTENANCE

To ensure the longevity and proper functioning of your RECHOO G1000 flashlight, follow these maintenance guidelines:

- **Cleaning:** Wipe the flashlight body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The flashlight is IP65 waterproof, meaning it is protected from dust and low-pressure water jets. Ensure the Type-C charging port's rubber flap is securely closed when not charging to maintain water resistance. Avoid submerging the flashlight in water.
- **Battery Care:** The built-in battery is not removable or replaceable. To prolong battery life, avoid fully depleting the battery frequently and recharge it regularly.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.

ALL WEATHER RESISTANCE

DESIGN FOR USE UNDER EXTREME CONDITIONS



Figure 5: All Weather Resistance of the RECHOO G1000 Flashlight.

6. TROUBLESHOOTING

If you encounter any issues with your RECHOO G1000 flashlight, please refer to the following common solutions:

Problem	Possible Cause	Solution
Flashlight does not turn on.	Battery is depleted.	Charge the flashlight using the provided Type-C cable until the indicator light turns green.
Light is dim or flickers.	Low battery.	Recharge the flashlight.
Charging indicator light does not turn on.	Charging cable or power source issue.	Try a different Type-C cable or USB power source. Ensure the cable is properly connected.

Problem	Possible Cause	Solution
Cannot cycle through modes.	Switch malfunction.	Contact customer support for assistance.

If the problem persists after attempting these solutions, please refer to the Warranty & Support section for further assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	RECHOO
Model	G1000
Light Source Type	LED
Brightness	1000 Lumens (Max Output)
Lighting Modes	High, Medium, Strobe
Power Source	Battery Powered (Built-in Rechargeable Battery)
Battery Cell Composition	NiMH (3.7V/1200mAh 18650 implied Li-ion from reviews)
Charging Port	Type-C USB
Runtime	4 hours (on full brightness)
Material	Aluminum
Water Resistance Level	IP65 Waterproof
Product Dimensions	1.25"D x 1.25"W x 4.72"H
Item Weight	0.23 Pounds (approx. 3.68 ounces)

8. WARRANTY & SUPPORT

RECHOO provides excellent after-sales service for all its products. Your RECHOO G1000 flashlight comes with a Limited Warranty.

If you have any problems with your flashlight, require technical assistance, or need to inquire about warranty claims, please do not hesitate to contact RECHOO customer service. They aim to reply within 24 hours.

For more information or to explore other RECHOO products, please visit the official [RECHOO Store](#).

