

[Manuals.plus](#) /

› [BlueFinger](#) /

› BlueFinger Wireless Gaming Keyboard and Mouse Combo User Manual

BlueFinger B0BZ8KV86G

BlueFinger Wireless Gaming Keyboard and Mouse Combo User Manual

Model: B0BZ8KV86G

PRODUCT OVERVIEW

The BlueFinger Wireless Gaming Keyboard and Mouse Combo provides a high-performance, cable-free solution for your computing and gaming needs. Featuring advanced 2.4GHz wireless transmission, vibrant RGB rainbow backlighting, and ergonomic design, this combo ensures a comfortable and responsive user experience. The keyboard is a compact 87-key tenkeyless (TKL) layout, saving desk space without sacrificing essential functions. Both devices are equipped with rechargeable batteries and smart power-saving features for extended use.



Figure 1: BlueFinger Wireless Gaming Keyboard and Mouse Combo

SETUP INSTRUCTIONS

1. Unpacking and Initial Inspection

- Carefully remove all components from the packaging.
- Verify that all items are present: 1x Gaming Keyboard, 1x Gaming Mouse, 1x Gaming Mouse Pad, and 1x USB Receiver.
- Inspect the devices for any visible damage.

2. Connecting the Devices

The keyboard and mouse share a single 2.4GHz USB receiver for a stable, lag-free wireless connection. The USB receiver is conveniently stored in the bottom compartment of the mouse.

1. Locate the USB receiver in the bottom of the mouse.
2. Plug the USB receiver into an available USB port on your computer (Laptop, Personal Computer, Xbox, PS4, PS5, etc.).
3. Turn on the keyboard and mouse using their respective power switches. The devices should automatically connect to your computer.



Figure 2: Connecting the 2.4GHz USB Receiver to a computer. The receiver is stored in the mouse.



Figure 3: Diagram illustrating the 2.4GHz wireless connection range of up to 10 meters.

1. Keyboard Functions

- **Backlighting Control:** The keyboard features 7 colors + RGB Rainbow lighting.
 - Press **FN + Scroll Lock** key to turn on/off keyboard backlight.
 - Press **FN + Home** key to enter breathing mode.
 - Adjust 4 levels of backlight brightness and breathing speed.
- **Multimedia Keys:** The 87-key layout includes 12 multimedia shortcut keys for quick access to various functions.
- **Windows Key Lock:** Press **Fn + Win** to lock the Windows Key, preventing accidental presses during gaming.



Figure 4: Keyboard showcasing 7 gorgeous rainbow backlighting options.



Figure 5: Different lighting modes and colors available on the keyboard.



Figure 6: Compact keyboard layout highlighting 12 multimedia shortcut keys and the Fn+Win key lock.

2. Mouse Functions

- **Buttons:** The mouse features 6 buttons: Click (Left/Right), Menu, Scroll Wheel, Forward, Backward, and DPI.
- **LED Lighting:** The mouse has a built-in 7-color cyclic gradual lighting effect.
- **DPI Adjustment:** 4 adjustable DPI levels: 800/1200/1600/2000. Press the DPI button to cycle through settings.



Figure 7: Detailed diagram of the gaming mouse features, including buttons, LED indicator, and USB receiver location.



Figure 8: Illustration of the four adjustable DPI settings for the mouse.

CHARGING AND POWER MANAGEMENT

Both the keyboard and mouse are equipped with rechargeable batteries and smart power-saving features to maximize battery life.

- **Battery Capacity:** Keyboard: 2000mAh, Mouse: 800mAh.
- **Charging:** Use the provided Type-C cable to charge the devices. The long battery life allows for over 40 hours of continuous use with backlighting on.
- **Power Switches:** Each device has a separate power switch and a dedicated backlit switch to conserve power when not in use.
- **Smart Power Saving:**
 - Keyboard backlight automatically turns off after 7 minutes of inactivity.
 - Mouse automatically turns off after 1 minute of inactivity.
 - Both devices enter sleep mode after a period of inactivity. Click any key or move the mouse to reactivate.



Figure 9: Keyboard and mouse being charged via Type-C cable, showing battery indicators.



Figure 10: Diagram illustrating the USB-C charging capability for both the keyboard and mouse.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For deeper cleaning, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- **Keycap Cleaning:** The keycaps are detachable for easier cleaning. Gently pull them upwards to remove. Ensure the keyboard is powered off before removing keycaps.
- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.
- **Mouse Pad Care:** The mouse pad features a smooth exquisite cloth surface and a non-slip rubber base. It can be wiped clean with a damp cloth.



Figure 11: Illustration showing a detachable keycap, allowing for easier cleaning and maintenance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Keyboard/Mouse not responding	Low battery, USB receiver disconnected, device powered off, out of range.	Charge devices fully. Ensure USB receiver is securely plugged in. Turn on power switches. Move devices closer to the receiver (within 33ft/10m).
Backlight not working	Backlight turned off, low battery.	Press FN + Scroll Lock to toggle backlight. Charge the keyboard.

Problem	Possible Cause	Solution
Mouse cursor erratic or unresponsive	Dirty sensor, unsuitable surface, low battery.	Clean the mouse sensor. Use on a clean, flat surface (mouse pad recommended). Charge the mouse.
Connection lag or instability	Interference, distance from receiver.	Move devices closer to the receiver. Avoid placing receiver near other wireless devices or large metal objects.

SPECIFICATIONS

Feature	Detail
Brand	BlueFinger
Model	B0BZ8KV86G
Connectivity Technology	2.4 GHz Wireless
Keyboard Layout	87 Keys (Tenkeyless)
Keyboard Backlight	7 Colors + RGB Rainbow, 4 Brightness Levels, Breathing Mode
Mouse DPI	800/1200/1600/2000 (Adjustable)
Battery (Keyboard)	2000mAh Lithium Metal (Included)
Battery (Mouse)	800mAh Lithium Metal (Included)
Charging Port	Type-C
Compatible Devices	Laptop, Personal Computer (Windows 10/8/7/XP/VISTA, Mac OS X), Xbox, PS4, PS5
Item Weight	2.01 pounds
Package Dimensions	14.68 x 8.9 x 1.93 inches
Country of Origin	China

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your product packaging or visit the official BlueFinger website. Additional protection plans may be available for purchase through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question