

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Shark](#) /

› [Shark Professional Steam Pocket Mop SE460 User Manual](#)

Shark SE460

Shark Professional Steam Pocket Mop SE460 User Manual

Model: SE460

1. INTRODUCTION

This user manual provides comprehensive instructions for the safe and effective operation, assembly, and maintenance of your Shark Professional Steam Pocket Mop, Model SE460. Please read this manual thoroughly before first use and retain it for future reference.

The Shark Professional Steam Pocket Mop is designed for deep cleaning and sanitizing sealed hard floors using super-heated steam. Its sanitizing steam blaster helps remove stuck-on messes.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using your steam mop.

- Always ensure the appliance is unplugged before filling or emptying the water tank.
- Do not leave the steam mop unattended while powered on.
- Keep the steam mop away from children and pets.
- Use only distilled or demineralized water in the water tank. Tap water may cause mineral buildup.
- Do not direct steam at people, animals, or electrical outlets.
- Do not immerse the steam mop in water or other liquids.
- Use only Shark-approved accessories and replacement parts.
- Inspect the power cord and plug for damage before each use. Do not use if damaged.
- Always allow the mop to cool completely before storing.

3. WHAT'S IN THE BOX

Verify that all components are present in your package:

- Shark Professional Steam Pocket Mop (Main Unit)
- Washable Steam Pocket Pad (Quantity: 1)
- 22' Power Cord (Integrated)






Image 1: The Shark Professional Steam Pocket Mop SE460 with its washable steam pocket pad attached.

4. ASSEMBLY

Your Shark Professional Steam Pocket Mop requires minimal assembly:

1. Insert the handle assembly into the main body of the steam mop until it clicks securely into place.
2. Attach a clean Washable Steam Pocket Pad to the mop head. The pad features elastic loops and a hook-and-loop fastening system to ensure a snug fit.



Image 2: Illustration showing the two-sided cleaning capability of the Steam Pocket Pad, highlighting how it can be flipped for extended cleaning.

5. SETUP AND OPERATION

5.1 Filling the Water Tank

1. Ensure the steam mop is unplugged from the electrical outlet.
2. Open the water tank cap, typically located on the front or side of the main unit.
3. Carefully fill the water tank with distilled or demineralized water. Do not overfill.
4. Close the water tank cap securely.

5.2 Attaching the Steam Pocket Pad

Place the mop head onto the floor. Align the Washable Steam Pocket Pad with the mop head and secure it using the elastic loops and hook-and-loop fasteners. Ensure the pad is flat and covers the entire mop head surface.

5.3 Powering On and Selecting Steam Modes

1. Plug the power cord into a grounded electrical outlet.
2. Press the power button to turn on the steam mop. The indicator light will illuminate.
3. Select your desired steam mode using the steam control button:
 - **Dust Mode:** For light cleaning and dusting.
 - **Mop Mode:** For everyday cleaning and tougher messes.
4. Allow approximately 30 seconds for the mop to heat up and produce steam.



INTELLIGENT STEAM CONTROL[®]

Two steam modes—Dust for light cleaning
and Mop for everyday cleaning.

Image 3: Close-up of the Shark Steam Mop's control panel, showing the power button and the steam control button with "Dust" and "Mop" settings.

5.4 Cleaning Hard Floors

The Shark Professional Steam Pocket Mop is safe for use on all sealed hard floors, including stone, tile, hardwood, and marble.



Image 4: Visual representation indicating the Shark Steam Mop is safe for various sealed hard floor types: stone, tile, hardwood, and marble.

1. Once steam is ready, begin mopping by moving the unit forward and backward over the floor surface.
2. For sanitization, hold the mop head over the area for at least 15 seconds.
3. The swivel steering feature allows for easy maneuvering around furniture and into tight spaces.



DEEP CLEAN WITH THE POWER OF STEAM

Image 5: A person using the Shark Steam Mop on a hardwood floor, demonstrating its deep cleaning capability with visible steam.



**DELIVERS POWERFUL
CLEANING ON TOUGH MESSSES**

Image 6: The Shark Steam Mop effectively cleaning a tough, dried stain on a tiled floor, illustrating its powerful cleaning action.



Image 7: Graphic indicating the Shark Steam Mop's ability to sanitize 99.9% of bacteria, with a background of various microorganisms.



SWIVEL STEERING

Maneuvers easily to clean edges and hard-to-reach places.

Image 8: The Shark Steam Mop demonstrating its swivel steering capability, allowing it to maneuver easily for cleaning edges and hard-to-reach areas.

6. MAINTENANCE

6.1 Cleaning the Steam Pocket Pads

The Washable Steam Pocket Pads are designed for repeated use. After each cleaning session:

1. Remove the pad from the mop head.
2. Machine wash the pad separately with warm water using liquid detergent. Avoid bleach and fabric softeners, as these can damage the pad's fibers.
3. Tumble dry on a low setting or air dry.
4. Do not wash pads with other lint-producing materials.



Image 9: Close-up of the Steam Pocket Dirt Grip Washable Pads, emphasizing their design for double-sided cleaning and reusability.

6.2 Emptying and Storing the Water Tank

After each use, or before storing for an extended period:

1. Unplug the steam mop and allow it to cool completely.
2. Open the water tank cap and carefully empty any remaining water into a sink.
3. Close the cap.

6.3 Storage

Store the steam mop in a cool, dry place. Ensure the power cord is neatly wrapped around the cord hooks on the handle.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|--------------------------------|--|---|
| No steam or very little steam. | Water tank is empty. Mop not heated sufficiently. Mineral buildup in system. | Refill water tank. Allow 30 seconds for heating. Use distilled water to prevent buildup. Contact support if issue persists. |
| Mop leaves streaks on floor. | Dirty mop pad. Too much detergent residue on floor. | Replace or wash mop pad. Ensure floor is free of cleaning product residue before steaming. |
| Mop is difficult to push. | Mop pad is too wet or worn. | Ensure pad is correctly attached. Replace worn pads. |

8. SPECIFICATIONS

- **Brand:** Shark
- **Model Name:** Shark Professional Steam Pocket Mop
- **Model Number:** SE460
- **Power Source:** Electric
- **Form Factor:** Upright
- **Special Feature:** Manual Steam Control
- **Surface Recommendation:** Sealed Hard Floors (Stone, Tile, Hardwood, Marble)
- **Included Components:** 22' power cord, Shark Professional Steam Pocket Mop, Washable Steam Pocket Pad
- **Item Weight:** 5.89 pounds
- **Package Dimensions:** 28.5 x 6.5 x 6.5 inches
- **UPC:** 752830199972

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the warranty card included with your product or visit the official Shark website. You may also contact Shark customer service directly for assistance with product operation, parts, or troubleshooting beyond this manual.

Please have your model number (SE460) and purchase date available when contacting support.